

Understand US Activity

L61530

Notices and Trademarks

**Copyright 1999 by Honeywell Inc.
Revision 09 Date 10/15/99**

Honeywell IAC courseware is subject to change without notice.

FLEXTRAINING courseware is copyrighted and all rights are reserved by Honeywell Inc. These materials are intended solely for use in conjunction with Honeywell products. The materials comprising the courseware may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without the prior, express written consent of Honeywell Inc.

Honeywell and **TotalPlant** are U.S. registered trademarks of Honeywell, Inc.

Other brand or product names are trademarks of their respective owners.

This module supports **TotalPlant** Solution (TPS) system network.

TPS is the evolution of TDC 3000^X.

Honeywell Inc.
Industrial Automation and Control
Automation College
2820 West Kelton Lane
Phoenix, AZ 85053-3028
1-800 852-3211

Table of Contents

Module Introduction	1
Purpose	1
Module Objective	3
Objectives	3
Peer Node Communications	5
Peer Nodes	5
Area Manager Tasks	5
Activities During Station Load or Area Change	5
Invoke User-Defined Schematic Upon Area Change	6
Loading Standard Displays	7
&DSY Directory	7
List of Memory-Resident Standard Displays	7
Display Access	8
Loading Errors	9
Loading Schematics and Free Format Logs	11
Area Pathname Catalog	11
Purpose of Memory-Resident Schematics/Logs	14
Determining the Displays that Have Been Loaded Into Memory	14
Schematic Redundancy	17
Prior Display Function	19
Description	19
Configuration Procedure	19
Extra Schematic Memory	21
Description	21
NCF Entry	22
Heap	22
ME00 and ME01	22

Memory-resident Files	23
Conceptual Diagram of US Memory	24
Custom Systems.....	25
Example	26
How to Determine Current ME01 Usage	26
Mw, Kw, and Sectors	27
\$EMEMORY Examples	27
Requirements.....	29
Written Exercise.....	29
Board Memory	30
Written Exercise Answers	31
Memory-Resident Files Error Message	32
 RTJ Buffer Size	 35
Guidelines	35
Memory Requirement	36
 New US/GUS PSDP Parameters for Alarm Overview	 37
Description	37
Parameters	39
Area Configuration and Alarm Display.....	41
Other US PSDP Parameters	41
 Alarm Handling	 43
System and Console Alarms	46
Alarm Acknowledge	48
 Lab Exercise.....	 51
Lab Exercise 1	51

Acronyms

GUS	Global User Station
HM	History Module
ME00	Memory device \$Memory
ME01	Memory device \$EMEMORY
NCF	Network Configuration File
PSDP	Processor Status Data Point
PAJ	Process Alarm Journal
RTJ	Real Time Journals
US	Universal Station

Parameters

ALENBST	Alarm Enable State
---------	--------------------

Tables

Table 1	Schematic Redundancy Methods	17
Table 2	Board Memory	30
Table 3	New US PSDP Parameters.....	39
Table 4	Description of ALENBST.....	43

Figures

Figure 1 Universal Display/Native Window Loading.....	8
Figure 2 R500 Pathname Catalog Example	13
Figure 3 R500 Schematic/FFL Titles Display.....	15
Figure 4 Schematic Redundancy.....	18
Figure 5 Universal Station Configuration—Page 2	21
Figure 6 Partial \$EMEMORY Listing of Memory-Resident Files	23
Figure 7 US Memory Diagram.....	25
Figure 8 \$EMEMORY Command	26
Figure 9 \$EMEMORY Examples	28
Figure 10 Status Notification (Aux Node Status) Journal.....	33
Figure 11 RTJ Buffer Size	35
Figure 12 Area Relative Unit Numbers.....	38
Figure 13 Area Configuration and Alarm Display.....	41
Figure 14 Example—ALENBST on Detail Display	44
Figure 15 Alarm Enable State Definition.....	45
Figure 16 System and Console Alarms	46
Figure 17 Unit Assignment Display	47
Figure 18 Console-Wide Silencing	48
Figure 19 Ownership of Alarm Silence and Acknowledgment	49

Module Introduction

Purpose

The purpose of this course module is to give you an understanding of

- what occurs during a US node or GUS Native Window load or Area change,
- how to configure the pathname catalog for optimum performance,
- how US memory is allocated, and
- the R500 alarm overview PSDP parameters.

Module Objective

Objectives

Given a Universal Station or GUS Native Window, be able to

- Recognize loading errors caused by memory resident schematics or free format logs.
- List the rules and recommendations that should be considered when configuring the Area Pathname Catalog.
- Configure Extra Schematic Memory
- Utilize PSDP alarm parameters in a custom display.
- Identify the effects of disabling point, console, and system alarms.
- Define the scope of alarm acknowledgment from a US/GUS.

Peer Node Communications

Peer Nodes

Peer Universal Stations or GUS Native Windows on the LCN are defined as stations that are

- loaded and running the operator or universal personality,
- in the same console,
- loaded with the same Area and Area database version,
- using the same NCF version.

Area Manager Tasks

The Area Manager subsystem in the US/GUS is a function set responsible for managing the area database during node startup and during subsequent area changes. The Area Manager task has three basic responsibilities:

1. Copying standard abstracts, button configuration, custom schematics, and free format logs into the memory resident volume during startup.
2. Requesting data from peer nodes for use in the local US or Native Window area database during startup.
3. Controlling the transfer of area database data during an area change.

Activities During Station Load or Area Change

When a Universal Station or Native Window is loaded or its Area database is changed:

1. The Area Manager sends out a request for peer data to an existing peer within the console.
2. The request is received by the Area Manager in the peer node.
3. The message containing the following peer data is returned to the requesting node:
 - Last 10 group definitions,
 - Overview display suppression data,
 - Report scheduling data,
 - Report printer assignments,
 - Unit assignments,
 - Real Time Journal active/suppress status,
 - Real Time Journal printer number.
4. The above peer data is copied to the requestor's existing Area database in memory.

Invoke User-Defined Schematic Upon Area Change

In R520 or later, the user can define a schematic to be automatically displayed after an area change. The schematic must have the file name AREACHnn.DO (where nn is the area number to which the station is being changed). This file must be located in the area directory &Dnn.

If no AREACHnn.DO is specified in the area directory, then the Console Status and Assignment Display will be shown when the station's area is changed.

Loading Standard Displays

&DSY Directory

Displays are loaded into US or GUS LCNP memory from the &DSY directory from either the History Module or from removable media.

List of Memory-Resident Standard Displays

The Universal Station (US) or GUS LCNP memory is loaded first with this group of standard displays:

1. Top Two Lines (includes system time and station number)
2. Console Status Display
3. Standard System Status Display
4. LCN Node Status Displays
5. Mount Media Display
6. Group Display
7. Process Module Display
8. Status Detail Display

In addition to these standard displays, the customized System Status display is loaded, if configured.




Figure 1 Universal Display/Native Window Loading

Display Access

When the System Status display (Console Status display on R4xx) appears after a node load, you can call up *any operating display or schematic*, even though the loading is not complete. If the display is not in memory yet, it is immediately copied into memory by a separate function and as a temporary file. This applies to the Operator and Universal Personalities.

If you attempt to call up a memory-resident display before it has been loaded into the station memory, the display callup time is slightly slower than if the display is already in memory; however, within minutes the display resides in permanent memory and the callup time is normal.

Loading Errors

On R400 and later, if any of the standard displays are not copied into memory, the Console Status display indicates “WARNING.”

On R500 and later, the System Status display also indicates “WARNING.”

The node Status Detail display indicates whether all standard displays were copied to memory.

Loading Schematics and Free Format Logs

Area Pathname Catalog

In the Area Pathname Catalog, the user specifies what additional displays and/or logs are to be memory-resident. The user-specified displays/logs are loaded from the pathnames the user also specifies in the Area Pathname Catalog (see Figure 2).

The Area Pathname Catalog has three sections.

Section	Description
1. Button Configuration File	<p>For the Universal Station to be able to load the Button Configuration file, its pathname must be entered.</p> <p>NOTE: The Button File must be on the same physical media as the stations' Area database file.</p>
2. <i>Pathnames</i> to Schematics and Free Format Logs	<p>There are up to 20 possible pathnames in the Area Pathname Catalog:</p> <p style="padding-left: 40px;">R500 and later = 20 pathnames Before R500 =10 pathnames</p> <p>These pathnames are used by the US/GUS to locate the named memory resident displays and logs when loading the Area database into station memory.</p> <p>The station also uses the pathnames to search for nonmemory-resident schematics and FFLs or GUS display builder .pct files when called up during normal online operations.</p>

3. <i>Names of Memory-Resident Schematics and Free Format Logs</i>	<p>In this section of the catalog you enter the names of "classic" (picture editor) schematics and/or logs that are to be loaded into the US/GUS's memory when the Area database is loaded.</p> <p>The schematic/log object files must reside in one of the pathnames listed in the Area Pathname Catalog.</p> <p>As shown in Figure 2, a <input type="checkbox"/> FFL target appears to the right of each name entry port. The <input type="checkbox"/> FFL target must be selected if a Free Format Log file name is entered.</p> <p>Although the Area Pathname Catalog contains ports for 36 (before 500) or 200 (R500 and later) schematics/logs, the actual number that can be loaded depends on the amount of memory in the station and the size of the schematics/logs.</p> <p>In a standard configuration, there are 72 K words of station memory available for schematics and logs.</p> <p>In R500 and later, additional station memory may be allocated for memory resident schematics and logs.</p>
--	--

Loading Sequence

The US/GUS searches the pathnames from left to right and top to bottom. Memory-resident schematics and free format logs are loaded from left to right and top to bottom as specified in the Pathname Catalog.

Optimum Performance

For optimum performance, it is best to do the following:

1. For quickest station load and schematic access, place the most important and most frequently displayed "classic" schematics and free format logs in directories on the "fast search" user volume. Each History Module can have a fast search volume which is the first user volume configured on each HM. Each of these volumes can have 63 directories.
2. To ensure that the nonmemory-resident schematics and FFLs are retrieved as quickly as possible, specify the paths to these directories as the first search paths in the Pathname Catalog.

Equipment List Considerations

It is important to note that an Equipment List declare file is not bound to a custom display object file, as are subpictures, for example. Instead, it is accessed at runtime and, therefore, must be located by using the Area Database Pathname Catalog as a search path. You must be aware of the fact that in the case of the Equipment List declare file (.QO), the US searches the catalog in *reverse order*.

If it is taking a considerable amount of time to display Equipment List custom displays, check the pathname catalog.

Selecting a target that references the Equipment List .QO file, causes the station to search the Area Database Pathname Catalog in reverse order.

To prevent a long access time, you must configure your pathname catalog to accommodate the reverse search. The following table describes how to configure your pathname catalog for Equipment list.

IF ...	THEN...
.QO and .DO files are in the same directory	Configure the directory at the beginning <i>and</i> at the end of the catalog.
.QO and .DO files are in the different directories.	Configure the .DO directory at the beginning and the .QO directory at the end of the catalog.

23 May 13:35:31 1

PED >>>>> POINT:\$OABSTR AREA:01 PAGE 02 OF 04

MEMORY RESIDENT SCHEMATIC OR FFL FILE NAMES
(LOADED LEFT TO RIGHT, TOP TO BOTTOM):

FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL
FFL	FFL	FFL	FFL	FFL	FFL	FFL	FFL

F1=PED
F2=RECALL DIS

23 May 94 13:33:26 1

PED >>>>> POINT:\$OABSTR AREA:01 PAGE 01 OF 04

PATHNAME CATALOG CONFIGURATION

BUTTON CONFIGURATION FILE: VOLUME ID
FILE NAME

SCHEMATIC OR FFL PATHNAMES (DEVICE>VOLUME)
(SEARCHED LEFT TO RIGHT, TOP TO BOTTOM):

NET>PICT	NET>DISP	NET>HMV1	NET>LOG1
NET>LOG2	NET>DIA1	NET>8D01	NET>TLK1
NET>FUN	NET>JIMK	NET>DIAG	

MEMORY RESIDENT SCHEMATIC OR FFL FILE NAMES
(LOADED LEFT TO RIGHT, TOP TO BOTTOM):

REACT1	FFL	FFL	FFL	FFL	FFL	FFL	FFL
PRIMMOD	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL
	FFL	FFL	FFL	FFL	FFL	FFL	FFL

F1=PED F3= F5=OVERWRITE F7=RECON F9 =WLK BACK F11=TAB
F2=RECALL DISP F4= F6= F8=PED STATUS F10=WRITE F12=LOAD

33531-A

Figure 2 R500 Pathname Catalog Example

Purpose of Memory-Resident Schematics/Logs

There are two reasons for memory-resident schematics and free format log files:

1. Quick call-up of commonly used schematics or logs.
2. Availability of essential or critical schematics or logs in case of HM failure.

Note: Only picture editor graphics may be memory-resident.

Determining the Displays that Have Been Loaded Into Memory

To determine the displays that have been loaded into the US/GUS memory, call up the Schematic/FFL Titles display:

1. Press [SYSTEM MENU]
2. Select ORGANIZATIONAL SUMMARY MENU
3. Select SCHEMATIC/FFL TITLES

Display Colors: Yellow—Memory-resident displays/logs
 Cyan—Displays/logs that were configured for memory residency,
 but were not actually loaded.

SELECT SUMMARY08 Aug 96 17:36:441

ORGANIZATIONAL SUMMARY MENU

UNIT POINT SUMMARY

HIWAY BOX POINT SUMMARY

POINT USAGE LIST

UNIT POINT ATTRIBUTE SUMMARY

AREA POINT ATTRIBUTE SUMMARY

LCN NODE POINT SUMMARY

UCN DEVICE POINT SUMMARY

UCN DEVICE MODULE PT SUMMARY

AREA TITLES

UNIT TITLES

GROUP TITLES

UNIT TREND TITLES

SCHEMATIC/FFL TITLES

CANCEL

PRINT

09 Apr 96 08:20:571

TITLE SUMMARY - SCHEMATIC/FFL

LAST PAGE 1

DISPLAY TIME 08:20:56

PATHNAMES FOR SCHEMATIC SEARCH

NET>PIC1

NET>LOG2

NET>TLK1

NET>DEMO

NET>PIC2

NET>LOG3

NET>STAT

NET>TOMK

NET>PIC3

NET>LOG4

NET>STRT

NET>RUBY

NET>PIC4

NET>DOCS

NET>SHDN

NET>JPT

NET>LOG1

NET>DIA1

NET>TRNG

\$F1>BKUP

SCHEMATIC/FFL TITLES (Yellow means memory-resident)

AIR_HT_A

BFBP

BWWT

MU_H2O

PH_TEMP

AIR

AIR_HT_B

BFP_A

COST_PMP

MU_PMP

PRFORM

AUX_BLR

BFP_B

CSDT_SYS

SBAC_A

WT_SAMPS

B_FW_FL

BWCP

CIRC_PMP

SBAC_B

GE_TEMPS

A_U_C_S

BFPL

FD_FANS

FW_STUP

HP_HTRS

34500

Figure 3 R500 Schematic/FFL Titles Display

Schematic Redundancy

It is a good idea to configure several options for schematic access to ensure they are always available in the event of HM failure.

Table 1 describes the ways schematic redundancy can be handled.

Table 1 Schematic Redundancy Methods

Method	Description
Have schematics reside in the station's memory	Memory-resident schematics provide faster callup time, but are redundant in the sense that they will be loaded in station memory and will also be present on the HM.
Duplicate files on two different HMs.	<p>If the system has multiple HMs, create two directories (each with unique names) on two of the HMs, then duplicate the schematic object files in each directory.</p> <p>When entering the schematic/log pathnames in the Area Pathname Catalog, include both directory names.</p> <p>If one HM fails and the directory cannot be found, the US/GUS searches for the other directory. The search can take up to 8 seconds.</p>
Include a directory that "points" to a removable media drive.	Copy the critical schematic object files onto a floppy or cartridge disk, and make the disk available for insertion in the drive in case of HM failure.




Figure 4 Schematic Redundancy



ATTENTION

ATTENTION—If you maintain multiple copies of schematics, make sure you have good update procedures in place in case a schematic is modified.

Prior Display Function

Description

Before R510, a Universal Station read any non-memory resident Picture Editor display into memory every time it was involved. After Release 510, the last three most recently invoked displays are kept in US/GUS memory to reduce their call-up time:


Configuration Procedure

One consequence of keeping the last three prior displays in memory is that when building a new custom schematic the engineer will typically want to check its operation and revise it. After making changes, the changed schematic is usually compiled to an HM.

In R510 and later systems, to clear the old display out of US/GUS memory and read in the latest revision of the custom display, two methods are provided:

- The Clear Screen function on the System Menu clears the screen *and* the prior display *if* that display was a custom schematic.
- The Clear Screen actor also clears the screen *and* the prior display *if* that display was a custom schematic. In order to use the actor, you might want to add it to one of the configurable buttons.
- Invoking the Picture Editor also clears memory.

Note: an area change does not clear this memory location.



REFERENCE—Additional information can be found in the following manuals in binder TPS 3032-2:

The Clear Screen actor (CLR_SCRN) is described in Section 2 of the *Actors Manual*.

Section 4 of the *Picture Editor Data Entry manual* explains how to clear the prior schematic from US memory.

Extra Schematic Memory

Description

In R500 and later, the External Schematic Memory NCF entry can be used to allocate additional memory in a Universal Station for memory-resident user Picture Editor schematics and free format logs. You can install additional memory in the station beyond the size required for the personality, then use a new NCF entry to allocate all or a portion of the space for memory-resident schematics and logs.

The area of US memory used for memory-resident displays/logs is named ME01. The new NCF entry can be used to expand the size of ME01 beyond its minimum size. The minimum size of ME01 is the space required to store Honeywell's memory-resident &DSY displays and the base amount for user memory-resident files.

NCF Display

Figure 5 shows page 2 of the Universal Station NCF configuration. The entry you use to allocate additional memory appears at the bottom of the display:

EXTERNAL CUSTOM SCHEMATIC MEMORY (KILOWORDS)

19 May 94 09:16:45 1

UNIVERSAL STATION NODE
PAGE 2 OF 2 ON-LINE

NODE 1

ENTER EXTERNAL LOAD MODULE NAMES & ASSOCIATED PERSONALITY-TYPES:

NAME ---	PERS.	NAME ---	PERS.	NAME ---	PERS.	NAME ---	PERS.
DPBASE	OPR						
DPEQLT	OPR						
MSF	JP						
UPBASE	JP						
UPEQLT	JP						

ADDITIONAL MODULE MEMORY (WORDS)

TOTAL (MODULES PLUS ADDITIONAL MEMORY)

MAXIMUM EXTERNAL MODULE MEMORY (WORDS)

FURTHER EXTERNAL DIRECTIVES?

EXTERNAL CUSTOM SCHEMATIC MEMORY (KILOWORDS)

OPR

UP

7780

15771

8276

16416

YES NO

YES NO

0

0

F1=CHECK F3=SET OFFLINE F5=ABORT F7=NEXT ITEM F9=PACK NCF
F2=INSTALL F4=PRINT

33423

Figure 5 Universal Station Configuration—Page 2

Release R610
10/99

Understand US Activity L61530.09
Honeywell Inc.

21

NCF Entry

The possible entries for External Custom Schematic Memory are

ALL = Maps all additional US memory (above what is required for the personality) as memory-resident file space.

If you enter ALL, then you can add additional memory to the station at any time, and the node administrator will map it as memory-resident file space without requiring an NCF change.

nn = If you enter a specific number of kilowords, that amount of additional memory is mapped as memory-resident file space and the remainder is released to heap. If your entry is more than is available, at load time the station allocates as much as possible.

The default NCF entry is zero Kw. If you don't configure External Schematic Memory, any additional memory is available as heap.

External Schematic Memory can be changed as an *online* NCF change.

Heap

Heap refers to dynamically allocated node memory. Each task in the node goes and gets a number of blocks of heap memory as needed, then releases the memory when the task terminates.

The dictionary defines the word "heap" as a pile of things. Heap memory can be thought of as a "pile" of memory that is not used for fixed structures or other files that are loaded at load time. Tasks borrow memory from the heap and then put it back.

The term "heap eater" refers to a task that gets memory but does not put it back. Users who observe this condition should request Honeywell technical assistance.

ME00 and ME01

Memory-resident files are stored in a file system in the US referred to as ME01 (memory device \$MEMORY). Another file system in the US is ME00 (memory device \$MEMORY). Before R500, the Honeywell supplied &DSY memory-resident displays and the user's memory-resident displays and logs resided in ME00. In R500, all memory-resident displays reside in ME01.

Memory-resident Files

You can use the following Command Processor command to list the names of the files in ME01:

```
LS $EMEMORY>MRnn>*. *
```

where nn = node number (can specify only local node)

Figure 6 is a partial example listing. Remember that the standard Honeywell displays are in ME01 along with the user's schematics/logs. Page to the end of the listing to see the user schematics/logs.

\$EMEMORY>MR01>*. * 05/23/94 14:40:26															
DEVICE	DIR	FILENAME	EXT	TYP	P	VER	TIME	STAMP	#	RECS	RECSIZ	#BLKS	BLKSIZ	START	END
-----	---	-----	--	-	-	--	-----	-----	-----	-----	-----	-----	----	----	-----
\$EMEMORY	MR01	DISPLAY1	SV	C		--	05/23/94	14:15	-----	-----		270	----	62	331
\$EMEMORY	MR01	DISPLAY2	SV	C		--	05/23/94	14:15	-----	-----		270	----	332	601
\$EMEMORY	MR01	DISPLAY3	SV	C		--	05/23/94	14:15	-----	-----		270	----	602	871
\$EMEMORY	MR01	TOP2LINE	DO	C	*	4	03/01/94	11:53	-----	-----		2	----	872	873
\$EMEMORY	MR01	\$SS_STAT	DO	C	*	4	03/01/94	11:52	-----	-----		6	----	874	879
\$EMEMORY	MR01	FLOPPYH	DO	C	*	4	03/01/94	11:52	-----	-----		8	----	880	887
\$EMEMORY	MR01	BUTTON	KO	L		3	05/23/94	10:53		1	-----	1	4	888	888
\$EMEMORY	MR01	DETTITLE	DO	C	*	4	03/01/94	11:52	-----	-----		3	----	893	895
\$EMEMORY	MR01	DTGRPCHG	DO	C	*	4	03/01/94	11:52	-----	-----		1	----	896	896
\$EMEMORY	MR01	DTCHANGE	DO	C	*	4	03/01/94	11:52	-----	-----		2	----	897	898
\$EMEMORY	MR01	\$DCGPCHG	DO	C	*	4	03/01/94	11:51	-----	-----		3	----	899	901
\$EMEMORY	MR01	OS_TOP	DO	C	*	4	03/01/94	11:52	-----	-----		38	----	902	939
\$EMEMORY	MR01	CON_ASGN	DO	C	*	4	03/01/94	11:52	-----	-----		35	----	940	974
\$EMEMORY	MR01	NODE_STS	DO	C	*	4	03/01/94	11:52	-----	-----		50	----	975	1024
\$EMEMORY	MR01	GROUP	DO	C	*	4	03/01/94	11:52	-----	-----		1	----	1025	1025
\$EMEMORY	MR01	MOD_GRP	DO	C	*	4	03/01/94	11:52	-----	-----		42	----	1026	1067
\$EMEMORY	MR01	\$STSDTL1	DO	C	*	4	03/01/94	11:52	-----	-----		31	----	1068	1098
\$EMEMORY	MR01	DTDACRG1	DO	C	*	4	03/01/94	11:52	-----	-----		18	----	1099	1116
\$EMEMORY	MR01	DTDACRG2	DO	C	*	4	03/01/94	11:52	-----	-----		19	----	1117	1135
\$EMEMORY	MR01	DTDACNRG	DO	C	*	4	03/01/94	11:52	-----	-----		14	----	1136	1149

Figure 6 Partial \$EMEMORY Listing of Memory-Resident Files

Conceptual Diagram of US Memory

Figure 7 shows the following items in a conceptual diagram of US memory:

- memory required for personality
 - personality image (PI) files
 - custom systems (optional external load module software)
 - minimum ME01 (default size required for memory-resident Honeywell standard abstracts from &DSY and base amount for user-memory resident files)
 - minimum heap
- additional space for ME01 (user-configurable)
- ME00 (contains only the user's Areann.DA file and several Honeywell journal manager files)

As shown in Figure 7, the size of ME01 expands to meet the user's NCF request. The amount of available heap expands if the user releases any additional memory to heap.

The term "external" in reference to External Customer Schematic Memory pertains to memory external to ME00; that is, ME01.




Figure 7 US Memory Diagram

Custom Systems

In R500 and later, Honeywell allocates the following space for External Load Module software in the “custom systems” area of US memory:

- OPR - 250 K
- UNP - 300 K

Example

As an example of how to configure External Schematic Memory, assume we have added two Mw (2000 Kw) of additional memory to a station that previously had four Mw.


We will enter 1250 Kw into the NCF configuration for EXTERNAL CUSTOM SCHEMATIC MEMORY. The result is that 1250 Kw of the additional memory is mapped for memory-resident files and 750 Kw is released to heap.

How to Determine Current ME01 Usage

You can use the following Command Processor command at the station in question to see how much space is currently being used for ME01:

```
LS $EMEMORY -D
```

The command can display only the local node's information. The command lists TOTAL SECTORS available in ME01 and SECTORS IN USE (see Figure 8).



```
01 Sep 99 16:25:10 4
USER PATH : NET>TEST>

LS $EMEMORY -D

VOLUME: MR10
VOLUME DESC:
MAX FILES: 312
TOTAL SECTORS: 5128
SECTORS IN USE: 3559
VOLUME SUBSTATE: INITIALIZED
DIRECTORY: NOT MEMORY RESIDENT
AVL SUPPORTED ON VOLUME: NONE
ACCESS LEVEL: NETWORK_READ_WRITE
FILE DESCRIPTORS: DISABLED
MAX DIRECTORIES: 63
CURRENT DIRECTORIES ASSIGNMENT: * NONE *

Catalog Complete
```

Figure 8 \$EMEMORY Command

Mw, Kw, and Sectors

Use the following information to interpret the \$EMEMORY display:

1 sector = 1 block

8 sectors = 8 blocks = 1 K words

1000 K words = 1 Mw

1 Mw = 8000 blocks (32 schematics at maximum size) = 8000 sectors

NOTE: In R500, the maximum size of a custom schematic display increased from 150 blocks (\approx 19 K words) to 250 blocks (32 K words).

\$EMEMORY Examples

Figure 9 shows three different examples of LS \$EMEMORY, showing results when the NCF entry set to zero, 1000 Kw, and ALL. The SMCC REV/CONFIG display shows that the station has 8 Mw of memory.

TOTAL SECTORS:
 NCF entry x 8 (sectors/Kw)
 - Baseline before NCF entry

Total Sectors Available in ME01

SMCC shows this US with 8 Mw
 (Assume the US is running UNP
 (requires 6 Mw))

EXAMPLE 1:
 NCF Entry = 0 Kw
 5128 = baseline
 (minimum default size of ME01)

EXAMPLE 2:
 NCF entry = 1000 Kw
 13128
 -5128 (baseline)
 8000 sectors
 1000 Kwords = 1 Mw
 8 | 8000

EXAMPLE 3:
 NCF entry = All
 15368
 -5128 (baseline)
 10,240 sectors
 1280 Kwords = 1.2 Mw
 8 | 10,240

The screenshot shows the 'REV / CONFIG STATUS' window with the following data:

SLT #	ORU/DEVICE TYPE	BOARD STATUS	DEVICE STATUS	HW VER	HW REV	FU VER	FU REV	FW TYPE	COMMENTS
1	K2LCN-8MW	GOOD	GOOD	4	S	0	C	1	
	RS232								
	CLOCK								
	K2LCN-LCN	GOOD	GOOD	2	A	0	R	1	MEDIA GOOD
	LCN-A		GOOD						
	LCN-B		GOOD						
3	EPDG/SCSI	GOOD		2	F	1	N	1	
		GOOD		2	F	1	N	1	
	PRT-5		GOOD						
	KBD		GOOD						
	CURSOR		GOOD						

SOFTWARE = 61.2 (VERSION.REVISION)
 For Information On Functions And Options Displayed On This Menu,
 Position The Cursor On The Desired Target And Press HELP.

EXAMPLE 1:
 TOTAL SECTORS: 5128
 SECTORS IN USE: 3559
 VOLUME SUBSTATE: INITIALIZED
 DIRECTORY: NOT MEMORY RESIDENT
 AVL SUPPORTED ON VOLUME: NONE
 ACCESS LEVEL: NETWORK_READ_WRITE
 FILE DESCRIPTORS: DISABLED
 MAX DIRECTORIES: 63
 CURRENT DIRECTORIES ASSIGNMENT: * NONE *
 Catalog Complete

EXAMPLE 2:
 TOTAL SECTORS: 13128
 SECTORS IN USE: 1319
 VOLUME SUBSTATE: INITIALIZED
 DIRECTORY: NOT MEMORY RESIDENT
 AVL SUPPORTED ON VOLUME: NONE
 ACCESS LEVEL: NETWORK_READ_WRITE
 FILE DESCRIPTORS: DISABLED
 MAX DIRECTORIES: 63
 CURRENT DIRECTORIES ASSIGNMENT: * NONE *
 Catalog Complete

EXAMPLE 3:
 TOTAL SECTORS: 15368
 SECTORS IN USE: 3564
 VOLUME SUBSTATE: INITIALIZED
 DIRECTORY: NOT MEMORY RESIDENT
 AVL SUPPORTED ON VOLUME: NONE
 ACCESS LEVEL: NETWORK_READ_WRITE
 FILE DESCRIPTORS: DISABLED
 MAX DIRECTORIES: 63
 CURRENT DIRECTORIES ASSIGNMENT: * NONE *
 Catalog Complete

Figure 9 \$EMEMORY Examples

Requirements

The maximum amount of total mappable memory in a station depends on whether it uses an EPDG, PDG, or TPDG.

- A station with a EPDG board can use up to 7.25 Mw of installed memory.
- A station with a TPDG or PDG board can use up to 7.50 Mw of installed memory.

Listed below are the memory requirements for each personality, the maximum amount of memory that is usable by the station, and the amount of additional ME01 space that can be allocated for External Schematic Memory.

	<u>Required Memory</u>	<u>Maximum Mappable Memory</u>	Maximum Available for Additional ME01 Space
OPR w/EPDG	4 Mw	up to 7.25 Mw	3.25 Mw (3250 Kw)
OPR w/PDG	4 Mw	up to 7.50 Mw	3.50 Mw (3500 Kw)
UNP w/EPDG	6 Mw	up to 7.25 Mw	1.25 Mw (1250 Kw)
UNP w/PDG	6 Mw	up to 7.50 Mw	1.50 Mw (1500 Kw)
UXS w/TPDG	8 Mw	up to 7.50 Mw	0 Mw

Written Exercise

1. How much usable memory is available in a station with the hardware installation shown below? (Use Table 2 to determine the amount of memory on each board.)

EPDG	Mappable Memory=_____Mw
EMEM	
EMEM	
EMEM	
LLCN	
HPK-3	

2. If this station has the OPR personality loaded, how much memory is required by the personality? _____Mw
3. With the OPR loaded, how much of this station's memory can be used for External Schematic Memory? _____Mw or _____Kw
4. How much usable memory is available in a station with the hardware shown below?

EPDG	Mappable Memory=_____Mw
K4LCN-8	

5. If this station has the UNP personality loaded, how much memory can be used for External Schematic Memory? _____Mw or _____Kw

Board Memory

Table 2 shows the amount of memory available on the various types of LCN node processor boards and the two types of external memory boards that can be used in addition to the processor memory.

Table 2 Board Memory

Processor Board		External Memory Boards	
Type	Memory Size	Type	Memory Size
HMPU*	2 Mw	EMEM (Rev. E or higher) QMEMn	1 Mw
HPK2-2*	2 Mw		n = 2, 3, or 4 Mw
HPK2-3	3 Mw		
K2LCNn*	n = 2, 3, 4, 6, or 8 Mw	These processors cannot address external memory boards.	
K4LCNn**	n = 4, 8, or 16 Mw		
* 68020			
** 68040			

Written Exercise Answers

Example 1

1.

EPDG	
EMEM	(1 Mw)
EMEM	(1 Mw)
EMEM	(1 Mw)
LLCN	
HPK-3	(3 Mw)

Mappable Memory = 6 Mw

2. *OPR personality requires 4 Mw*

3. *Available External Schematic Memory = 2 Mw or 2000 Kw*

Example 2

4.

EPDG	
K4LCN-8	(8 Mw)

Mappable Memory= 7.25 Mw

5. *Available External Schematic Memory = 1.25 Mw or 1250 Kw*

Memory-Resident Files Error Message

There is a configuration error message related to the External Schematic Memory NCF entry. If you enter a specific number of kilowords, the NCF configurator does not validate that the station has enough memory to satisfy your entry and it does not limit your entry.

If there is not enough memory available to satisfy the NCF request, an error message similar to the one shown in Figure 10 is recorded at load time in the Status Notification (aux node) Event History Journal:

Not enough ME01 space (A 1280 KW) to fill request (R 3000 KW)

where:

A 1280 KW = Actual amount of memory currently *available* for the External Schematic Memory function.

R 3000 KW = Amount of memory *requested* in the NCF entry.

If the requested memory is not available at load time, the node allocates as much memory as possible, allowing you to configure a memory size in anticipation of a future node memory upgrade.




Figure 10 Status Notification (Aux Node Status) Journal

RTJ Buffer Size

In R500 and later, the Universal Station/Native Window Real Time Journal (RTJ) buffer can be increased from 100 to 400 events. Increasing the buffer size minimizes loss of event printouts caused by buffer overflow during a process upset.

If there is overflow of the buffer and events are lost, they are lost only to the RTJ. The RTJ will print a message stating that there was overflow and some events were “lost” (not printed). The events will still be in history on the HM if the HM is configured for journaling of those units. Figure 11 shows the NCF selection for RTJ buffer size. 100 is the default.

07 Apr 14:06:41 2
 PAGE 1 OF 11 ON-LINE

CONSOLE DATA

NCF INSTALL TIME 09 Sep 94 11:07:08 FILE VERSION 50 REVISION 4
 NCF SOURCE NET>&ASY>NCF.WF CONFIGURATOR 50 4

FAST RAISE/LOWER RATE ☒ 2 ☐ 3 ☐ 5 ☐ 10 PERCENT PER INCREMENT
 PRINTER PAGE LENGTH PRINTER PAGE WIDTH
 TREND PEN DELAY
 CL MESSAGE CONFIRMATION-AFTER-ACKNOWLEDGEMENT
 PRINTED TREND FORMAT
 REAL TIME JOURNAL SIZE
 REAL TIME JOUR. HEADER/TRAILER MESSAGES
 CONTACT CUTOFF ALARMS ON ALARM SUMMARY

F1=CHECK F3=SET OFFLINE F5=ABORT F9=PACK NCF
 F2=INSTALL F4=PRINT

33431

Figure 11 RTJ Buffer Size

Guidelines

If the Real Time Journal is an important part of your operating philosophy and it would be detrimental to lose any printed events, select the 400-event buffer. If your system is very small or does not have many alarms, or if the RTJ is not important the 100-event buffer will be adequate.

Memory Requirement

A buffer size of 400 requires an additional 21.3 Kwords of heap space in each US/GUS. If the large buffer does not “fit” into the US/GUS memory, it defaults to 100 events and sends the following message to the Status Notification RTJ and event history journal:

```
RTJ buffer size has been reduced from 400 to 100 due to memory  
allocation
```

The error message occurs only in abnormal situations where the node is so short of memory that tasks are not working properly. Shortage of memory should not occur but if it does, the error message may be helpful to the troubleshooter analyzing the situation; however, the RTJ buffer size reduction is just a symptom of a larger problem.

New US/GUS PSDP Parameters for Alarm Overview

Description

Universal Station (R500 and later) or Global User Station (R510 and later) PSDP parameters are available for read-only access to the following information for a specified unit in the local station's Area.

- Unit ID
- Unit Composite Alarm Status
- Unit Alarm Count
- Unit Assignment State
- Unit Assignment State
- Unit Assignment State
- Unit Lost Event Recovery State

Using these parameters, the information that is shown on the unit annunciator boxes of the Alarm Summary and Alarm Annunciator displays, as well as information from the unit assignment display, can be shown on custom schematics. In addition, a count of alarms at each priority level on each unit can be shown on custom schematics.

The PSDP parameters require the area-relative unit number (see Figure 12) and the local node number; however, if you want to provide a complete alarm overview schematic, the PSDP parameters provide access to additional information (assignment state, system alarm state, console alarm state, and lost event recovery state).

Figure 12 shows the Area-relative unit index numbers as they appear in the Area Unit Assignment configuration display.




Figure 12 Area Relative Unit Numbers

Parameters

Each of the new PSDP parameters is an array of 36 values, as indexed by the Area relative unit number. Table 3 defines each parameter (where ii = the Area relative unit index number, and nn = the local US node number).

When adding these values to a custom schematic, the system display database parameter \$MY_PNA can be used to access the local station's node number.

Table 3 New US PSDP Parameters

Parameter	Definition
\$PRSTSnn.UNIT_ID(ii)	Unit ID—This parameter of type string returns the 2-character user-configured Unit ID, as defined in the NCF Unit Names. If the Unit is not configured, “garbage” is returned. This will be fixed in a maintenance release to return blanks.
\$PRSTSnn.UNACKEM(ii) \$PRSTSnn.UNACKHI(ii) \$PRSTSnn.UNACKLO(ii) \$PRSTSnn.ACKEM(ii) \$PRSTSnn.ACKHI(ii) \$PRSTSnn.ACKLO(ii)	Unit Alarm Counter—These parameters of type integer return the number of alarms (0-600) for a specified alarm status category in the specified unit. If the Unit is not configured, the counters are zero. The unit alarm count is also available using the following Picture Editor collector: \$UNITCNT(Unit ID, \$ALRMSTS:nnnnnnnn)
\$PRSTSnn.UNITSTAT(ii)	Unit Composite Alarm Status—This parameter returns a state of the enumeration \$ALRMSTS indicating the current composite alarm status of the specified unit. The states are listed below in order of precedence: UNACKEM UNACKHI UNACKLO ACKEM ACKHI ACKLO If all the counters are zero, the status is NOALARM. If the Unit is not configured, the status is NOTCONFIG The composite Unit alarm status is also available using the following Picture Editor collector: \$UNITSTS (“Unit ID”)

ii=Area relative unit number (index number of unit)

nn=US node number

Parameter	Definition
\$PRSTSnn.UNITSYS(ii)	<p>Unit System Alarm Status—This parameter returns a state of the enumeration ALENBST, indicating if the process alarms for the unit will be annunciated system-wide:</p> <p>ENABLE (alarms are annunciated, historized, and journaled.)</p> <p>DISABLE (alarms are not annunciated. The process alarm event history collection and RTJ are not affected.)</p> <p>INHIBIT (alarms are not annunciated, and the process alarm event history collection and RTJ are stopped.)</p> <p>If the Unit is not configured, the status is DISABLE.</p>
\$PRSTSnn.UNITCONS(ii)	<p>Console Alarm Status—This parameter returns a state of the enumeration ALENBST, indicating if the process alarms for the unit will be annunciated on the stations in the local console:</p> <p>ENABLE (alarms are annunciated)</p> <p>DISABLE (alarms are not annunciated)</p> <p>If the Unit is not configured, the status is DISABLE.</p>
\$PRSTSnn.UNITASSG(ii)	<p>Unit Assignment Status—This parameter returns a state of the enumeration UNITASGN, indicating if the unit is under the control of the local area:</p> <p>NO (unit is not assigned)</p> <p>YES (unit is assigned)</p> <p>If the Unit is not configured, the status is @ @ @.</p>
\$PRSTSnn.UNITRECV(ii)	<p>Unit Lost Event Recovery Status—This parameter returns a state of the enumeration \$UNITREC, indicating the current unit alarm recovery state:</p> <p>NOLOST (no lost events)</p> <p>RECVREQD (event recovery has been requested)</p> <p>LOSTEVT (lost events exist, but no recovery has been requested)</p> <p>RECINPRG (event recovery is in progress)</p> <p>If the Unit is not configured, the status is NOLOST.</p>
ii = Area relative unit number (index number of unit) nn = US node number	

Area Configuration and Alarm Display

The Area Configuration and Alarm display (ARCFGALM) from the PERFMENU shows the value of the alarm overview PSDP parameters for each unit in the area. The Area relative index number for each unit is shown here also.

22 Jul 96 11:52:09 2

ARCFGALM - AREA RELATED UNIT CONFIGURATION AND ALARMING DATA

THIS DISPLAY PROVIDES DATA ON AN AREA'S UNIT CONFIG,
 ALARMING ENABLE/DISABLE STATUS, AND NUMBERS OF ACK'D
 AND UNACK'D ALARMS FOR EACH UNIT CONFIGURED/ASSIGNED.

SELECT
FOR US
NODE # \$PRSTS02

PERFMENU
DISPLAY

AREA UNIT INDX	CFG UNIT	UNIT ASGN	UNIT SYS STAT	UNIT CONS STAT	UNIT ALARM STATUS	UNIT RECOVERY STATUS	# ACKD EMRG	# ACKD HIGH	# ACKD LOW	# UNACK EMRG	# UNACK HIGH	# UNACK LOW
1	A2	YES	ENAB	ENAB	ACKHI	NOLOST	0	1	12	0	0	0
1	A4	YES	ENAB	ENAB	ACKLO	NOLOST	0	0	12	0	0	0
1	A6	YES	ENAB	ENAB	ACKLO	NOLOST	0	0	14	0	0	0
1	AL	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
1	H2	YES	ENAB	ENAB	UNACKLO	NOLOST	0	1	9	0	0	1
1	H4	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
1	H6	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
1	P2	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
1	P4	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
1	P6	YES	ENAB	ENAB	NOALARM	NOLOST	0	0	0	0	0	0
2												
3												
4												
5												
6												
7												
8												
9												
10												
11												
12												
13												
14												
15												
16												
17												
18												
19												
20												
21												
22												
23												
24												
25												
26												
27												
28												
29												
30												
31												
32												
33												
34												
35												
36												
37												
38												
39												
40												
41												
42												
43												
44												
45												
46												
47												
48												
49												
50												

^UNIT_ID ^UNITSYS ^UNITSTAT ^UNITRECV
 ^UNITASSG ^UNITCONS

432 2 MESSAGES
 PARAMETERS

Figure 13 Area Configuration and Alarm Display

Other US PSDP Parameters

\$PRSTSnn.CURRDSP

In R600 and higher, a US/GUS PSDP parameter, \$PRSTSnn.CURRDSP (where nn is the station node number) will indicate the standard or Picture Editor schematic currently invoked at that node. If the display is a custom schematic, it will show its filename. If the display is a standard display, it will show its name (for example, CON_ASGN or SYS_MENU).

This parameter may allow the user to:

1. Track the displays that are most used.
2. Determine the displays that are no longer used.
3. Determine the sequence of displays invoked by the operator.
4. Find the name of the schematic that is currently being displayed.
5. Associate the schematic source filename on each schematic.

\$PRSTSnn.USKEYACC

In R610 and higher, a US/GUS PSDP parameter, \$PRSTSnn.USKEYACC (where nn is the station node number) provides the ability to read from and write to the keylevel access parameter of any US/GUS on an LCN.

Any time the hardware key is changed, this PSDP parameter will reflect the value of the hardware key.

Any time the key access is changed using Picture Editor actors (KEYENG, \$KEYCHG), this PSDP parameter will reflect that change until the next time the key access is changed, either through the hardware key or another actor.

When the station is reloaded, this PSDP parameter returns to its default value.

Alarm Handling

This section discusses the following topics:


- alarm handling by the serving and receiving nodes,
- alarm enable states,
- console alarm states, and
- system alarm states.

ALENBST

In Figure 14, the parameter “ALENBST” has been selected on a point’s Detail display.

Table 4 Description of ALENBST

ALENBST	Description
ENABLE	Allows the configured priority for this point to take place upon entering the alarm state.
DISABLE	Allows indication of the alarm on the screen, but the alarm is not sent to the alarm summary or the Real Time Journal (RTJ). Disabled alarms that go into alarm are reported to the Process Alarm Journal and logged.
INHIBIT	Does not allow the alarm to be displayed on the screen or be logged by either the RTJ or Process Alarm Journal. An indication of “INH” appears on the group and detail displays of the point that is set to the “INHIBIT” alarm state.



34502

Figure 14 Example—ALENBST on Detail Display




Figure 15 Alarm Enable State Definition

System and Console Alarms

As shown in Figure 17, the Unit Assignment Display is accessed from the Console Status Display by selecting the **UNIT DISPLAY** target. The Unit Assignment display provides targets to disable alarm annunciation, either console-wide or system-wide:

System Alarm State—The **DISABLE**, **ENABLE**, **INHIBIT** targets listed under the System Alarm State heading affect all points in a selected unit the same way as the “ALENBST” parameter affects the individual points. As shown in Figure 16, the System Alarm States are handled by the data owner.

Console Alarm State—As shown in Figure 17, the **disable** target listed under the Console Alarm State is used to disable alarms on a console-basis only, assuming that one area is loaded in the console.

For example, disabling the console alarm state for Unit AL prevents alarms in Unit AL from annunciating on the US/GUSs loaded with the same Area database within the same console as the US/GUS from which the state was disabled. The actual data owner is not affected; that is, ALENBST is not changed.





Figure 16 System and Console Alarms



ATTENTION

*When alarms are enable, disabled, or inhibited **by using the System Alarm State targets on the Unit Assignment display, the action is system-wide.***



SELECT FUNCTION 11 Dec 97 15:14:17 1 -

CONSOLE STATUS AND ASSIGNMENT LOCAL STA ADB: 08Dec97 10:12:10:811

CONSOLE	STN	NODE	TYPE	STATUS	AREA	PERIPHS	PRTRS	DRIVES	PENS	ACCESS	MAINT
* 1	1		UNVL	OK	:HCU	OK	1	1, 2		ENGR	
2	2		UNVL	OK	:HCU	OK		3, 4		ENGR	YES

Name of the Area loaded into Stations 1 and 2.

Buttons: ENB AUTO LOAD/DMP, LOAD/DUMP, ACCESS CHG, AREA CHG, UNIT DISPLAY, STATUS DETAIL, SHUT DOWN, MAINT INFO, PRTR ASSIGN, PERIPH STATUS, ENTER

1

CONSOLE	AREA	UNIT	ASSIGN	CONSOLE	ALARM	STATE	SYSTEM	ALARM	STATE
1	4	A4	YES	ENABLE	ENABLE				
		A1	YES	ENABLE	ENABLE				
		S4	YES	ENABLE	ENABLE				
		A3	YES	ENABLE	ENABLE				

UNIT ASSIGNMENT

YES NO

CONSOLE ALARM STATE

ENABLE DISABLE

SYSTEM ALARM STATE

ENABLE DISABLE INHIBIT

33510-B

Figure 17 Unit Assignment Display

Alarm Acknowledge

Operator silence and acknowledgement of alarms can be performed from one station in a console. All stations in that console, loaded with the same Area:

- receive the silence/acknowledge, and
- show the alarms as being acknowledged on the alarm displays.

NCF Configurable Alarm Option—R410 and later:

Cross-Console Acknowledgement

When a point alarm is acknowledged at a station, the alarm is acknowledged at all USs on the LCN that are loaded with the same Area, regardless of the console.

The silence key's scope is console only. In R510 and later, an NCF System-Wide Values option allows for console-wide silencing of horns (Figure 18). When this option is configured, pressing the Silence key from any station in the console will silence the horn at any other station in the console, regardless of the area.

Not configuring this option enables silencing of horns based on area within the console.

07 Sep 97 00:33:22 2

CONSOLE DATA PAGE 3 OF 12 OFF-LINE

ALARM MANAGEMENT CONFIGURATION

RED COLOR ALARM PRIORITY ☐ LOW ☐ HIGH ☒ EMERGENCY

PRIORITY INDICATORS ON ALARM DISPLAYS ☐ CHARACTERS ☒ SYMBOLS

ALARM PRIORITY COLORS ☐ RED, YELLOW ☒ 3 COLORS (USER SELECTABLE)

THREE COLOR ALARM PRIORITY:

EMERGENCY ☒ RED ☐ YELLOW ☐ MAGENTA ☐ GREEN ☐ BLUE ☐ CYAN ☐ WHITE

HIGH ☐ RED ☒ YELLOW ☐ MAGENTA ☐ GREEN ☐ BLUE ☐ CYAN ☐ WHITE

LOW ☐ RED ☐ YELLOW ☐ MAGENTA ☐ GREEN ☐ BLUE ☐ CYAN ☒ WHITE

LOW PRIORITY ALARMS IN AREA ALARM SUMMARY ☒ YES ☐ NO

INITIAL ALARM SUMMARY SORT STATE ☒ CHRONOLOGICAL ☐ PRIORITY

AUDIBLE ALARM ANNUNCIATION SUPPRESSION TIME-OUT (SECONDS)

ALARM SUMMARY FREEZE TIME-OUT (SECONDS)


AREA-BASED PROCESS ALARM ACKNOWLEDGE? ☒ YES ☐ NO

CONSOLE-WIDE SILENCE BUTTON? ☒ YES ☐ NO

F1=CHECK F3=SET OFFLINE F5=ABORT F9=PACK NCF F11=TAB
F2=INSTALL F4=PRINT

34967

Figure 18 Console-Wide Silencing

**Figure 19 Ownership of Alarm Silence and Acknowledgment**

Lab Exercise

Lab Exercise 1

Create Custom Alarm Schematic and Invoke Upon Area Change

1. Create two directories on a cartridge:

&Dnn (where nn is the area number on your partition sheet)
&DSY

2. Copy all files from the NET to your cartridges:

```
CP NET>&Dnn>*.* $Fn>&Dnn=  
CP NET>&DSY>*.* $Fn>&DSY>=
```

3. Working from the area database on your cartridge, determine your area-relative unit index number by reconstituting the Area Data Base Unit Assignment display for your area.
4. From the Picture Editor, create a custom alarm graphic using the GUS/GUS PSDP alarm parameters. Include the following:

Unit ID

Unit Alarm counters

Unit system alarm status

Name the file AREACHnn (where nn is your area number).

5. Copy the AREACHnn.DO to \$Fn>&Dnn (where nn is your area number).

Change the area at your station from your cartridge. Verify that your custom alarm schematic is invoked upon the area change.

LAST PAGE

Honeywell

