



BATCH TERMINAL CONTROLWARE INSTALLATION HANDBOOK

**2780 EMULATION
3780 EMULATION
200 USER TERMINAL (MODE 4A) EMULATION**

**CDC® COMPUTER SYSTEMS:
CYBER 18-05/5M/10/10M/20**





BATCH TERMINAL CONTROLWARE INSTALLATION HANDBOOK

**2780 EMULATION
3780 EMULATION
200 USER TERMINAL (MODE 4A) EMULATION**

**CDC® COMPUTER SYSTEMS:
CYBER 18-05/5M/10/10M/20**

LIST OF EFFECTIVE PAGES

New features, as well as changes, deletions, and additions to information in this manual, are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

PAGE	REV	PAGE	REV	PAGE	REV	PAGE	REV	PAGE	REV
Cover	--								
Title Page	--								
ii	H								
iii/iv	H								
v/vi	D								
vii	H								
viii	F								
1-1	B								
2-1	H								
3-1	G								
3-2	B								
4-1	B								
4-2	A								
5-1	F								
5-2	G								
5-3	G								
5-4	F								
6-1	H								
6-2	H								
6-3	H								
6-4	H								
7-1	A								
8-1	F								
8-2	H								
8-3	H								
8-4	E								
8-5	G								
8-6	A								
A-1	G								
A-2	G								
A-3	A								
B-1 thru B-3	F								
C-1	F								
D-1	F								
D-2	G								
Comment Sheet	H								
Cover	-								



PREFACE

This manual describes the controlware installation procedures necessary for the user to install the CDC® CYBER 18 batch terminal products. The manual is intended for use by individuals involved in terminal installation and terminal field maintenance. The hardware and controlware descriptions herein are supplied only to provide a brief background and as an aid in configuring

batch terminal installations for the field installation and maintenance of the controlware products available for use in CYBER 18 batch terminals.

This manual should be used in conjunction with the following publications:

<u>Publication</u>	<u>Publication Number</u>
CYBER 18 Computer Systems Site Planning Kit	96768510
CYBER 18 Computer Systems with Core Memory Installation Manual	39451500
CYBER 18-05/10 Computer Systems Hardware Maintenance Manual, Volumes 1 and 2	96767500 96767600
CYBER 18-05/10/20 Computer Systems Batch Terminal Controlware Operators Guide	96768920

Field maintenance personnel should require only the latter three manuals. Additional information may be found in the following publications:

<u>Publication</u>	<u>Publication Number</u>
CYBER 18-05/10/20 Computer Systems Batch Terminal Controlware Reference Manual	96768910
CYBER 18 Computer Systems Operational Diagnostic System (ODS) Reference Manual	39452100
CYBER 18 Computer Systems Operational Diagnostic System (ODS) Instant	39451600

This product is intended for use only as described in this document. Control Data cannot be responsible for the proper functioning of undescribed features or parameters.



CONTENTS

1. CONTROLWARE PACKAGES	1-1	5. SELECTION CARD	5-1
2. TERMINAL PRODUCT/EQUIPMENT CROSS-REFERENCE	2-1	Selection Card Location	5-1
Card Reader/Line Printer	2-1	Selection Card Punching	5-1
Controlware	2-1	2780/3780 Emulation Selection-Card Punching	5-1
Hardware Options	2-1	200 User Terminal Emulation Selection-Card Punching	5-3
3. CARD DECK STRUCTURE AND FUNCTIONS	3-1	6. CONTROLWARE INSTALLATION	6-1
Loader	3-1	CLA Interrupt and Equipment Code Installation Preparation	6-1
Selective-Loader Common Routine	3-1	Controlware Installation Procedures	6-2
Error Reporting Overlay	3-1	Controlware Loading	6-2
Selection-Card-Read Overlay	3-1	Terminal Verification After Loading	6-3
Selection Card	3-2	7. PATCH CARDS	7-1
Controlware	3-2	Format	7-1
Move-Loader Overlay	3-2	8. MAINTENANCE UTILITIES, MEMORY DUMP AND HANG 1 ERROR MESSAGE DISPLAY	8-1
Loader-Cleanup Overlay	3-2	Maintenance Utilities	8-1
Patch-Processing Overlay	3-2	Display Core	8-1
Patch Card(s)	3-2	Error Message	8-2
End-Of-Loader Card	3-2	Modify Core	8-2
4. SYSTEM IDENTIFICATION	4-1	Error Message	8-2
Hardware Identification	4-1	TRACE	8-2
Controlware Identification	4-1	Error Message	8-4
		Crash Dump	8-4
		Memory Dump	8-4
		Hang 1 Error Message	8-5

APPENDIXES

A Loader Error Messages and Reporting	A-1	C Hardware Error Message Listing	C-1
B Hexadecimal Code Conversions	B-1	D Terminal Configuration Sheet	D-1

FIGURES

4-1 Controlware Deck	4-2	6-2 Example of Controlware Load Display, Including Hardware Error Reporting	6-4
5-1 Card Deck Layout and Selection Card Placement	5-1	8-1 General Memory Format	8-1
Selection-Card Punching	5-2	8-2 Typical Example of Trace Output	8-3
6-1 1811-1 CYBER 18 Batch Terminal Decal Layout	6-1	8-3 Crash Dump Routine Keypunch Listing	8-5
6-1.1 722-10 Batch Terminal Switch Settings	6-2	8-4 Sample Portion of Memory Dump	8-6
		D-1 Terminal Configuration Sheet	D-2

TABLES

3-1	Controlware Card Deck Structure	3-1	5-2	200 User Terminal Emulation Selection-Card Punching	5-3
4-1	Tape Unit Configuration Possibilities	4-1	B-1	ASCII/BCD/Hexadecimal Card-Punch Code Conversions	B-1
5-1	2780/3780 Emulation Selection-Card Punching	5-2			

There are three different controlware packages available for use with CYBER 18 batch terminals, each controlware package reflecting a different type of computer system to which a batch terminal may be connected. The three types are:

- A system using 200 User Terminals
- A system using IBM 2780 terminals
- A system using IBM 3780 terminals

The controlware installation packages are punched-card decks and are loaded into the terminal controller via the card reader prior to terminal operation.

The controlware information for all three types of installation decks is structured so that it can be easily tailored to suit a particular terminal installation. Tailoring is accomplished through the use of a selection card

that is punched prior to the initial installation of the controlware and that is used to match the controlware loaded to the terminal's hardware configuration. Section 4 of this manual describes the procedures for identifying the system requirements for a particular terminal. Section 5 describes the procedure and format for punching the selection card. Section 6 gives detailed instructions for installing the controlware in the terminal controller.

In addition to the offline functions contained in the terminal controlware package, a complete set of offline diagnostics, run under control of the operational diagnostic system (ODS), is available as separate, peripheral-unit card decks. Using the diagnostics contained on these decks in conjunction with the system maintenance manuals, a support person can quickly and efficiently troubleshoot, isolate, and correct nearly any hardware malfunction occurring within the terminal equipment.



This section provides a product number/equipment number cross-reference listing for use in identifying the equipment configurations of various terminal installations. The listing gives the product number and then the equipments included within that product. To simplify the listing, the part numbers for the cabling equipment required to interconnect the various equipments have been omitted. Reference throughout this manual to a CYBER 18-05 or 18-10 assumes either an 18-05 or 18-5M and 18-10 or 18-10M.

The communications console consists of the following 120 vac, 50/60 Hz equipment:

- 18-05/10 Basic Central Processing Unit (AA136-A)
- 1882-8 8K-Word Memory Module (BT219-A)
- 1828-1 Card Reader/Line Printer Controller (FH301-A)
- 1843-1 Communication Line Adapter (FJ441-A)
- 1828-2 Card Reader/Line Printer/Communication Line Adapter Controller (FC109-A, FC539-A)
- 1811-1 Keyboard Display (CC614-C/D)
- 1811-1 Keyboard Display Memory Expansion (XA150-A)
- 1811-2 Keyboard Display (CC555-G/H, CA150-A/C)
- 18-05/10 Basic Operators Panel (GH508-A)
- 722-10 Conversational Display Terminal

CARD READER/LINE PRINTER

A CYBER 18 batch terminal configuration includes one card reader and one line printer from the following available types:

CARD READER

- 1829-30 300/600 cpm switched to 300 cpm (120 vac, 50/60 Hz) (CB104-K, CB104-L)
- 1829-60 300/600 cpm switched to 600 cpm (120 vac, 50/60 Hz) (CB104-K, CB104-L)

LINE PRINTER

- 1827-30 300 lpm (120 vac, 50/60 Hz) (CL408/CL411)
- 1827-32 300 lpm (120 vac, 50/60 Hz) (CT105-B)
- 1827-60 600 lpm (110 vac, 50/60 Hz) (CT103-A)
- 1827-90 900 lpm (110 vac, 50/60 Hz) (CT106-A)

CONTROLWARE

A CYBER 18 batch terminal has the following controlware options:

- 200 User Terminal (Mode 4A) Emulation Controlware Card Deck (MD426-A)
- 2780 IBM Terminal Emulation Controlware Card Deck (MD427-A)
- 3780 IBM Terminal Emulation Controlware Card Deck (MD428-A)

HARDWARE OPTIONS

A batch terminal can have the following hardware options:

- 1832-4 Magnetic Tape Controller (one required per terminal using magnetic tape transports) (FA107-A)
- 1832-4 Seven- or Nine-Track Magnetic Tape Transport Translator (BW812-A)
- 1860-72 Seven-Track Magnetic Tape Transport (120 vac, 50/60 Hz) (BW101)
- 1860-92 Nine-Track Magnetic Tape Transport (120 vac, 50/60 Hz) (BW303-A)
- 1882-8 8K-Word Memory Module Increment (to 32K in a terminal) (BT219-A)
- 1860-1 Seven-Track Magnetic Tape Subsystem
- 1860-2 Dual Seven-Track Magnetic Tape Subsystem
- 1860-3 Nine-Track Magnetic Tape Subsystem
- 1860-4 Dual Nine-Track Magnetic Tape Subsystem



This section describes the general structure of the controlware card decks used with the batch terminals. Table 3-1 lists an actual and a functional part breakdown of the controlware card deck. The actual breakdown column indicates the card groupings into which the deck can physically be divided, and the functional column indicates the functions that occur for the actual deck parts. The following paragraphs describe functions of the different parts of the controlware card deck.

TABLE 3-1. CONTROLWARE CARD DECK STRUCTURE

Actual Deck Parts	Deck Function
Loader	Selective-loader common package Error reporting overlay Selection-card-read overlay
Selection Card	Selection card
Controlware	Move-loader overlay Selective-loader overlay Controlware for applications package Loader cleanup overlay Patch processing overlay
Patch Card(s)	Patches
End-of-Loader Card	End-of-loader card

LOADER

The loader card deck consists of:

- Selective-loader common routine
- Hardware error reporting overlay routine
- Selection-card-read overlay routine

The loader card deck is separated from the rest of the controlware card deck by the selection card.

SELECTIVE-LOADER COMMON ROUTINE

The selective-loader common routine provides common functions for the selective-loader overlay cards interspersed throughout the controlware portion of the deck.

†On the 1811-1 CRT only

The system uses overlay routines for loading each device's controlware because placing the entire loader in memory at one time requires too much memory area. The loader overlays for each function run one-at-a-time in an area of memory reserved for that purpose. Once an individual overlay has accomplished its task of loading its associated controlware, it is replaced by the overlay for the next portion of controlware to be loaded. When the entire controlware deck is loaded, the memory area used by the loader routines is released for use by the operating system as memory buffer areas.

The function of the selective-loader common routine is to control and coordinate the activities of the loader overlays. The overlays, in turn, determine where and how a given controlware routine is to be loaded into memory and then build a routine address table (RAT) so that the operating system can readily locate and use the controlware routines. This form of loader is necessary to incorporate controlware flexibility into the system; that is, it is required to allow a given applications routine to be loaded or not loaded, depending upon the hardware configuration of the terminals.

An additional feature of the selective-loader common routine is that it monitors the controlware load process and enables the display of load-status messages on the display screen.

ERROR REPORTING OVERLAY

During terminal operation, the system maintains a hardware error log. On subsequent controlware loads, the error reporting overlay routine accesses the error log and displays the information contained therein on the display screen. If terminal power is not turned off in the interim, the error log maintains hardware error information for all periods of terminal operation between subsequent controlware loads. Once controlware loading is completed, a printout of the error log information appearing on the display screen† may be made by pressing the US key or the CONTROL US key (display-to-print control). An example of such a printout is included in section 5 of this manual.

SELECTION-CARD-READ OVERLAY

The selection-card-read overlay routine reads in and interprets the terminal configuration information punched on the selection card. The routine is then used to determine whether a given portion of the controlware should be loaded or not loaded by making comparisons between the information read in from the selection card and the header information preceding each controlware routine.

SELECTION CARD

The selection card is a single card in the controlware deck that contains information defining the configuration of a specific terminal installation. The card can be made to match a specific terminal installation in only one manner: by initially coming as a blank card and being punched to reflect a particular terminal installation. The card is initially punched by terminal service personnel when they install a terminal, but it may be replaced by a new selection card to reflect a different terminal configuration at any time. Procedures for punching the selection card are included in section 5.

CONTROLWARE

The controlware portion of the card deck contains:

- A move-loader overlay
- The selective-load overlay routines (described under Loader, above)
- The actual monitor, applications, and utility routines
- The loader-cleanup overlay
- The patch-processing overlay

MOVE-LOADER OVERLAY

The move-loader overlay moves the selective loader routines up to the high end of the uppermost 8K-word memory module available in the system. The number of 8K-memory modules is placed in column 1 of the selection card image in core. After the loader has been moved, memory is cleared up to the beginning of the loader.

LOADER-CLEANUP OVERLAY

The loader-cleanup overlay performs some final loading and housekeeping activities.

PATCH-PROCESSING OVERLAY

The patch-processing overlay routine enables any patch cards to be read that are included at the back of the deck, moves the patch information contained on the cards to the designated area of memory, and releases the memory area used by the loader so that it becomes available for use by the operating system as a memory buffer area.

PATCH CARD(S)

Patch cards may be included at the end of a controlware card deck to correct problem areas without requiring a complete reassembly of the deck. The patch cards contain a code indicating which routine is to be patched, an address indicating where in the routine the patch should begin, a hexadecimal count of the number of memory words to be patched, and the patch codes themselves (see section 7).

END-OF-LOADER CARD

The end-of-loader card informs the system that the end of the controlware deck has been reached and that the load process is complete.

Because there are a number of hardware and controlware combinations available for configuring a batch terminal, this section identifies the basic combinations and indicates how to determine exactly what terminal configuration is being installed. This information is necessary to correctly punch the controlware selection card and to assure that the user is getting the correct system.

There are three different controlware options available for use in batch terminals:

- 200 User Terminal emulation controlware
- 2780 emulation controlware
- 3780 emulation controlware

In addition, there are a number of hardware configurations for the terminal. For example, there are terminals without magnetic tape capabilities (i.e., no magnetic tape controller and smaller memory), there are terminals with magnetic tape capabilities but no magnetic tape transports, and there are terminals with both magnetic tape capabilities and one or more magnetic tape transports.

Table 4-1 indicates the various tape transport possibilities for different terminal configurations. The table is to be used in the following manner:

1. Ask all of the questions posed in the table and answer them yes (Y) or no (N).
2. Match your answers with the vertical Y or N columns.
3. Move down the matching column until an X is encountered.
4. Move across from the X to determine the terminal's product configuration (hyphens indicate that the corresponding question is irrelevant).

Although table 4-1 does not specifically identify a particular terminal configuration, it does indicate the various tape transport product configurations available. Each terminal configuration using tape transports can use between one and three transports and has three available memory sizes (16K, 24K, or 32K words).

HARDWARE IDENTIFICATION

While all possible memory and tape transport hardware combinations may never be used and are not all relevant to selection-card preparation, terminal installation personnel must be aware of all possible combinations to ensure that the user has the proper terminal configuration

TABLE 4-1. TAPE UNIT CONFIGURATION POSSIBILITIES


Conditions	1	2	3	4	5
Terminal controller has greater than 8K of memory	N	Y	Y	Y	Y
7-track tape transport in terminal	-	N	Y	N	Y
9-track tape transport in terminal	-	N	-	Y	Y
Tape capability not used	-	X	-	-	-
Terminal with 1860-72 tape transports	-	-	X	-	-
Terminal with 1860-92 tape transports	-	-	-	X	-
Terminal with 1860-72 and 1860-92 tape transports	-	-	-	-	X

installed to meet his requirements. Section 2 of this manual contains a product versus equipment number cross-reference listing. This listing, used in conjunction with the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual and a listing of user requirements, should enable installation personnel to verify that a particular user's requirements have been met. The verification process consists of inspecting the various pieces of hardware to ensure that the equipment numbers correspond with the desired product configuration. A list of equipment numbers, product numbers, and quantities of each equipment and product should be made as a quick reference for punching the selection card.

CONTROLWARE IDENTIFICATION

Figure 4-1 is an illustration of a controlware deck. The first card is an identification card bearing the part number of the controlware; it is usually a different color than the rest of the deck. The part number, controlware equipment number, and proof number are written on the top of the deck. This information identifies the deck and also acts as a guide for re-establishing the proper sequence of the deck if the deck is accidentally dropped.

When a deck is first received, it should be accompanied by controlware identification sheets (specifically requested when ordering a new deck). These sheets contain deck identification information (part number, equipment



0257

Figure 4-1. Controlware Deck

number, and revision level), product usage information, a brief description of the deck's structure, a list of related materials (manuals, etc.), deck-ordering information, and initial installation documentation procedures for engineering support services.

If the controlware identification sheet and the controlware identification card are not available (e.g., re-installation of an old deck), the correctness of the deck can be verified by comparing the information written across the top of the deck to the controlware identification tag inside the terminal controller near the terminal equipment number tag. Section 2 of this manual also identifies controlware decks via a listing of their equipment numbers and their respective product-emulation types.

This section describes how to locate and punch the controlware-deck selection card. Since the 2780/3780-emulation punching procedures differ slightly from those of the 200 User Terminal emulation selection card, both procedures are described.

There are two principal sources for obtaining the information required for punching a selection card: notes made during installation of the terminal hardware and requirements specified by the terminal user. Appendix D contains a terminal-configuration sheet for listing the selection-card punching parameters of an individual terminal.

the cards in the deck are not marked as to sequence all of the way through. The portion of the deck starting about five cards after the selection card and running up to about five cards from the end of the deck is punched with binary-sequence numbers in column 79; the rest of the deck is not marked as to sequence.

SELECTION CARD LOCATION

All cards in the controlware portion of a controlware deck except the selection card (section 2) have punches in rows 7 and 9 of the first card column. These 7 and 9 punches facilitate locating the selection card as illustrated in figure 5-1.

CAUTION

A controlware card deck has a specific sequence. This sequence cannot be altered or the deck does not load properly. Furthermore,

SELECTION CARD PUNCHING

2780/3780 EMULATION SELECTION-CARD PUNCHING

The 2780/3780 emulation selection cards are punched as illustrated in table 5-1. Note that there is a slight difference in the punching of columns 23 through 30 of the 2780 and 3780 emulation selection cards. Figure 5-2 contains examples of selection-card punching for various terminal types, both with and without magnetic tape transports.




Figure 5-1. Card Deck Layout and Selection Card Placement

TABLE 5-1. 2780/3780 EMULATION SELECTION-CARD PUNCHING

Column	Character	Meaning
1	1, 2, 3, or 4 or Blank	Indicates the number of 8K-word memory modules in the terminal controller. Automatically inserted by the loader.
2	1, 2, or 3	Indicates the number of magnetic tape transports in the terminal. Leave blank if there are no tape transports.
18	R	Displays an R on the screen to suffix messages requiring an operator response and also enables the keyboard error-response key. Automatically inserted by the loader.
41-44	Greater than 9	Enter in decimal the desired word size of first magnetic tape buffer. Minimum entry is 9 (nine-word buffer); blank causes default to 69-word buffer. Maximum entry is limited by buffer area available after controlware is loaded.
45-48	Greater than 9	Same as for columns 41 through 44 if second tape transport is present.
49-52	Greater than 9	Same as for columns 41 through 44 if third tape transport is present.
57-59	7 or 9	Enter either a 7 or a 9 in each column. Entries correspond with track size of tape transports 1, 2, and 3, respectively. Default to 9 if a 7 is not entered.
60-80	Not used	

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80

B B 1 6 0 A E

(200 USER TERMINAL EMULATION NO MAGNETIC TAPE UNITS)

3 B B 1 6 0 A E 0 2 8 0 0 2 8 0 0 2 8 0 7 9 9

(200 USER TERMINAL EMULATION THREE MAGNETIC TAPE UNITS)

(2780 EMULATION NO MAGNETIC TAPE UNITS)

2 0 2 8 0 0 2 8 0 9 9

(3780 EMULATION TWO MAGNETIC TAPE UNITS)

Figure 5-2. Selection-Card Punching

**200 USER TERMINAL EMULATION
SELECTION-CARD PUNCHING**

Table 5-2 indicates how the 200 User Terminal emulation selection card is punched. Notice that some of the selections punched on the card (operating parameters) are also key selectable or alterable once the controlware is installed (see the CYBER 18-05/10/20 Computer Systems Batch Terminal Controlware Operators Guide for specific information). The selection card is Hollerith punched, so it may be punched on any 026 or 029 code keypunch machine available at the terminal site.

If operating modes are not selected from the keyboard or by use of a selection card, the terminal automatically defaults to the following operating modes.

- Hollerith 026 punch-coded cards
- External binary-coded decimal (EXT BCD) and ASCII transmission-line code sets selectable by GS key
- Block mode
- Site address 160₈
- Alternate mode of data set operation

When the selection-card punching is completed, reassemble the deck in its proper card sequence. The controlware card deck is now ready for installation.

TABLE 5-2. 200 USER TERMINAL EMULATION SELECTION-CARD PUNCHING

Column	Character	Meaning
1	1-4	Enter the number of 8K-word memory modules contained in the batch terminal controller. If magnetic tape is provided, at least two memory modules are required. Automatically inserted by the loader.
2	1-3	Enter the number of tape transports provided. If none is provided, leave blank.
3-16		Not currently used
17	D or blank	D is punched only if a T is punched in column 30 and the controller has an 8K-word memory.
18	R	Error message displayed on the screen that require an operator response are suffixed by an R. Automatically inserted by the loader.
	Blank or other	Error messages are not suffixed by an R.
19	R	Implements automatic reset option. When in the block mode, the screen information sent to the main central computer, after the EXT or SEND key is pressed, always starts with the first character position on the first line of the screen, and ends at the final cursor position.
	Blank or other	When in the block mode, the screen information sent to the main central computer, after the EXT or SEND key is pressed, always starts with the first character of the current keyboard input and ends at the final cursor position.
20	9	Causes a selection of 029 card punch format at load time
	Blank or other	Defaults to 026 card punch format
21		Selects ASCII or BCD as the transmission code type to be selected on initial controlware load. See description for column 28 of the selection card.
	A	Selects ASCII
	B	Selects BCD
	Blank or other	Selects BCD
22	B	Select block mode

TABLE 5-2. 200 USER TERMINAL EMULATION SELECTION-CARD PUNCHING (Continued)

Column	Character	Meaning
	L	Select line mode
	Blank	Default to block mode
	Other	Default to block mode
23-25	160 ₈ -177 ₈	To establish the site address as other than 160 ₈ (70 ₁₆), columns 23 through 25 must be punched with the different address. A site address of 166 would require a 1 in column 23, a 6 in column 24, and a 6 in column 25.
	Blank	Defaults to site address 160 ₈
	Other	(Other than 160 ₈ through 177 ₈ .) Defaults to 160 ₈
26	C	Code set modification cards follow controlware deck (see appropriate reference manual for modification procedures).
	Blank	No code set modification
27	A	Select alternate mode of data set operation between the terminal and the higher level processor.†
	S	Select simultaneous mode of data set operation between the terminal and the higher level processor.†
	Blank	Default to alternate
28		The tables for only two transmission codes are in core at one time. The tables for ASCII are always loaded. Through column 28 of the selection card, the user may select either internal BCD or external BCD as the code type to be loaded with the ASCII table
	E	Select external BCD
	I	Select internal BCD
	Blank or other	Defaults to external BCD
29		Not currently used
30	T or blank	T is punched if communication-line trace feature is desired; if not, leave blank. If T is centered here and controller has 8K-word memory, a D must be entered in column 17; if memory is larger than 8K words, column 17 should be left blank because entering a D in column 17 deletes the display-to-print and card-to-print utilities. See section 7 of this manual for a description of the trace feature.
31-40		Not currently used
41-44		Enter in decimal the desired word size of the first magnetic tape buffer. Leaving the entry blank causes a default to 138 characters (one print line).
45-48		Same as above for second tape transport
49-52		Same as above for third tape transport
53-56		Not currently used
57-59		Enter either a 7 or a 9 in each column. Entries correspond with track size of tape transports 1, 2, and 3, respectively. Defaults to 9 if a 7 is not entered.
60-80		Not currently used

† All two-wire communications lines (two-wire connected modems) use A; all four-wire communications lines (four-wire connected modems) use S.

This section describes the preparations of the terminal for controlware loading and the installation procedures. Because there are a number of variables in the controlware and hardware configurations of a batch terminal, it is important to use this manual in conjunction with the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual and the CYBER 18-05/10/20 Computer Systems Batch Terminal Controlware Operators Guide.

CLA INTERRUPT AND EQUIPMENT CODE

If the hardware configuration of the system is a CYBER 18-10/20/30 on which the communication line adapter is set for interrupt and equipment code 2 instead of the batch controlware standard of 10, insert the following patch cards just before the last card of the controlware deck:

- DDT 7 1 0101
- DDT 18 1 2900
- DDT 1C 1 8002

For users with a dual channel CLA, patch cards may be used for channel 1 as follows:

If the CLA is on interrupt line 10/equipment code 10, use

- DDT 7 1 509
- DDT 18 1 2D08

If the CLA is on interrupt line 2/equipment code 2, use

- DDT 7 1 109
- DDT 18 1 2908
- DDT 1C 1 8002

Additional information concerning patch cards is contained in the CYBER 18-05/10/20 Computer Systems Batch Terminal Controlware Operators Guide listed in the preface.

INSTALLATION PREPARATION

Once system identification and selection-card punching is completed, but before loading the controlware, the appropriate sections of the CYBER 18-05/10 Computer Systems hardware maintenance manual and the operators guide should be referenced to verify and/or carry out proper equipment interconnection, internal jumper and switch settings, external (operator) control and switch settings, and terminal power-on procedures.

The keyboard display furnished as part of the CYBER 18 is also used in other Control Data products. CYBER 18 products require a fixed setting of some of the keyboard-display switches that other products do not. For this reason a decal is attached describing the fixed switch settings for CYBER 18 applications of the keyboard display. Figure 6-1 is an example of the 1811-1 display terminal and decal. Figure 6-1.1 is an example of the 722-10 display terminal and switch setting decal.





Figure 6-1. 1811-1 CYBER 18 Batch Terminal Decal Layout



DATA RATE SELECT	
■ =	□ =
A= 110	J= 4800
B= 150	K= 9600
C= 200	L=19200
D= 300	M=19200
E= 600	N=19200
F= 1200	P=19200
G= 1800	R=19200
H=2400	S=19200
MODE SELECT	
A=	B=
1 A=NORMAL	B= TRANSPARENT
2 A=NORMAL	B=DATA ONLY
3 A=PARITY ENABLE	B=PARITY DISABLE
4 A= 1 STOP BIT	B=2 STOP BITS
5 A=ADV	B=752
6 A=NORMAL	B= AUTO LF
7 A=DISABLE BELL	B= EOL BELL
8 A=RTS CONSTANT	B= RTS SWITCHED
9 A=DTR CONSTANT	B=DTR SWITCHED
10 A=60 Hz REFRESH	B=50 Hz REFRESH

SWITCH SETTINGS

TOGGLE SWITCHES

DATA RATE: BETWEEN 2400 AND 9600 BPS
 PAR EVEN/PAR ODD: PAR EVEN
 PAGE/ROLL: OPERATOR CHOICE
 FULL DUP/ HALF DUP: FULL DUP
 ONLINE/LOCAL: OPERATOR CHOICE

MODE SELECT SWITCHES

- 1 NORMAL
- 2 NORMAL
- 3 PARITY ENABLE
- 4 1 STOP BIT
- 5 752
- 6 NORMAL
- 7 DISABLE BELL
- 8 RTS SWITCHED
- 9 DTR SWITCHED
- 10 60 Hz (OR 50 Hz DEPENDING ON SITE POWER)

IF SWITCH IS RESET, REINITIALIZE THE TERMINAL BY POWERING IT OFF AND ON OR BY PRESSING THE MANUAL RELEASE SWITCH. THE NEW LINE AND CR KEYS ARE FUNCTIONALLY EQUIVALENT. EACH KEY CAUSES THE CARRIAGE TO RETURN AND THE CURSOR TO ADVANCE.

Figure 6-1.1. 722-10 Batch Terminal Switch Settings

1811 SWITCH SETTINGS

The decal indicates the position that the rocker switches must be in for batch terminal operation. Please note that some of the rocker switches are two-position switches and some are three-position switches and that switch settings must therefore be made accordingly. Two-position switches are in proper position when the side nearest the switch caption indicating the desired operating mode is fully depressed. For batch terminal applications, all switches listed on the decal have their top sides fully depressed, except for the EVEN PARITY switch, which has its bottom side fully depressed.

NOTE

The switch settings are the same for the 1811-2, except the switches are located on the keyboard. In addition, for the 1811-2, insure that the page mode switch is depressed.

722 SWITCH SETTINGS

The SWITCH SETTINGS listed in figure 6-1.1 are the settings used for batch terminal operation. Some of the switches are rocker switches and some are dip switches. Pressing down on the side of the switch which is closest to the setting caption sets the switch properly.

CONTROLWARE INSTALLATION PROCEDURES

This portion of the manual describes the actual controlware installation process. Before carrying out the loading process, all of the procedures described or referenced in the preceding portions of this manual should be performed or verified.

CONTROLWARE LOADING

To load the controlware into the batch terminal, perform the following:

1. Check to ensure that all terminal equipments are on and ready for operation according to the instructions in the operators guide.
2. Ensure that the keyboard display switches are set according to the batch terminal operation decal.
3. Remove the controlware identification card from the front of the controlware deck.

At the card reader:

4. Remove the card weight and any cards from the card reader hopper and stacker areas.
5. Place the card deck face down with the 9s row toward the back of the hopper in the card reader and replace the card weight.

At the basic operators panel:

6. Press STOP.
7. Press MASTER CLEAR.
8. Press AUTO LOAD. (For CYBER 18-10/10M/20 use DEADSTART.)

At the card reader:

9. Press RESET. The card reader begins reading the cards and the controlware begins loading. Reading should continue until the card reader hopper is empty.

As the controlware loads, numbers appear on the display screen. These numbers indicate that the system is tracking the loading procedure. If no errors occur during the loading procedure, the number 19 appears on the display screen as the load finishes. If an error does occur during the loading process, a number other than 19 appears on the display screen, the loading process stops, and the process must be started over. Before beginning a reload, however, check the loader error messages and subsequent load hardware error reporting (appendix A) to determine the nature of the error, the corrective action to be taken, and what to anticipate on the reload attempt.

Figure 6-2 shows a display screen image as it would appear upon the completion of a successful subsequent load attempt. Note that the success of an initial loading attempt (initial load after terminal controller power on) produces a display that is similar but that does not contain hardware error information.

TERMINAL VERIFICATION AFTER LOADING

Once controlware installation is completed, verify terminal operation in the following manner, using the operators guide to run the verification checks.

1. Set up and run some applicable offline operations (utilities).
2. Perform some online terminal-to-terminal operations in the case of a 2780/3780 emulation installation having other terminals to communicate with.
3. Have user supply a job that has known results for online submission to the central computer system if the terminal being verified is a 200 User Terminal emulation-type or a 2780/3780 emulation-type without other terminals to communicate with. Run the job and then compare returned information with known results.
4. If problems are encountered during verification, diagnose and correct problems using the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual.
5. Make a couple of duplicate controlware card decks on a duplicating keypunch machine once terminal operation has been verified. This should always be done because card decks have a limited lifespan and a spare deck should be available for use at all times.

Patch cards provide a means of correcting controlware problems without the necessity of producing an entirely new controlware card deck. Although patch cards can be used to alter the controlware considerably, such usage requires a high level of controlware programming expertise, so patching is best restricted to such things as altering constants, masks, or jump addresses within a particular routine. Even in these latter instances, patching requires programming knowledge, so it should not be attempted by anyone not familiar with controlware modification techniques.

FORMAT

Patch cards are punched in hexadecimal notation on a Hollerith 026 or 029 keypunch. Each patch card must contain the following entries; only the first 60 columns of a card can be used for patching entries, the remaining 20 may be used as a comment field.

nam addr coun pate pate pate

Where: nam is a three-character mnemonic name assigned to the routine to be patched. Routine names are obtained from a controlware list tape. The list tape is a restricted-distribution item and is therefore available only at regional task support offices.

addr is the hexadecimal address where the patch starts relative to the start of the routine.† The start of each routine has a relative address of zero. Leading zeros are not required.

coun is the hexadecimal count of the number of word locations to be patched. Leading zeros are not required.

pate is the hexadecimal patch. A full word entry must be made and portions of the word not to be altered must be entered as they appear in the original word. Leading zeros are not required.

Patch cards are inserted in the controlware deck just prior to the end-of-loader card (see section 3 for deck structure) and the controlware deck is reloaded using the loading procedures described in section 6.

† If the absolute memory address of a location to be patched is known (e.g., via display-core utility), 000 is entered in the nam field and the absolute memory address of the start of the patch is entered in the addr field.



MAINTENANCE UTILITIES, MEMORY DUMP AND HANG 1 ERROR MESSAGE DISPLAY

This section contains information regarding:

- The maintenance utilities available in the terminal and their use in terminal maintenance procedures
- The production and use of a special memory dump card deck, known as the crash dump card deck
- The HANG 1 error-message display

This section of the manual does not include routine operating procedures for the terminal. Such information is found in the operators guide. Appendix C of this manual contains a listing of the online hardware error codes.

MAINTENANCE UTILITIES

The maintenance utilities available in the terminal are:

- Display core †
- Modify core †
- Trace (200 User Terminal emulation only)

These utilities are restricted to use by maintenance personnel. The general-use utilities are described in the operators guide under Offline Processing.

DISPLAY CORE

The display core utility is used to display any 96 (60_{16}) sequential words of memory. This enables the contents of memory locations to be checked prior to making any core modifications.

Although the location of the various routines in memory is relative to the numbers and types of applications routines loaded, memory is always loaded in the general format shown in figure 8-1. Once the beginning of the routine address table (RAT) is located for any given controlware load, the rest of the routine starting addresses become easy to find. A memory-dump printout, described later in this section, further simplifies the location and modification of the controlware stored in memory.

Although the display core utility is an offline procedure, it does not require that the terminal be brought to an offline condition to perform it.

The following procedures describe how to use the display core utility.




Figure 8-1. General Memory Format

† Not available on 2780 and 3780 emulation using 8K words of memory

From the keyboard:

<u>Procedure</u>	<u>Results/Comments</u>
1. Press RESET key to reset cursor	When performing any of the utility functions, it is not necessary to press the RESET key on the keyboard display if the cursor has not been moved since the previous operation.
2. Key in the following: DIS,xxxx	Where xxxx is the hexadecimal starting address of the memory area to be displayed. Leading zeros need not be entered in address field.
3. Press the US key or the CONTROL US key†	Memory display now appears on screen, and it always contains 96 (60 ₁₆) sequential memory word locations from start address.

NOTE

If no address value is entered in step 2, the start address of the display is the last specified value. This simplifies the process of recalling memory display after performing intervening operations.

Error Message

Either of the following messages may be displayed when an attempt to initiate one of the utilities is made. The two error messages are:

UT DEV BUSY	The device requested by the utility is already in use.
UT FMT ERROR	Either the entry used to request the utility is illegal or the utility requested is not loaded, or an attempt has been made to get two utilities to run concurrently; e.g., tape-to-tape and card-to-print.

The messages are automatically erased after 5 seconds and a new display core or modify core command may be entered.

MODIFY CORE

This utility permits temporary patches to be made to the controlware. The patches are temporary in that they only remain in the system until the system controlware is

reloaded. This type of temporary patching determines whether a given patch corrects a controlware problem. If the temporary patch works, it can be made permanent by the production of a patch card (see section 7).

The following procedure describes how to modify the contents of memory.

From the keyboard:

<u>Procedure</u>	<u>Results/Comments</u>
1. Press RESET key to reset cursor or the CONTROL and y keys on the 722-10	It is not necessary to press the RESET key on the keyboard display if the cursor has not been moved since the previous operation.
2. Key in the following: MOD,xxxx,y ₁ , y ₂ ,y ₃ ,...y _n	Where xxxx is the hexadecimal starting address of the memory area to be modified, and y ₁ , y ₂ , etc. are the hexadecimal entries (patches) to be sequentially entered in memory starting at address location xxxx.
3. Press the US key or the CONTROL US key†	Memory is now modified according to the values entered in step 2.

If the area of memory modified had been displayed prior to modification, a display of modifications can be called up by simply keying in DIS and pressing the US key.

Error Message

Either of the following messages may be displayed when an attempt to initiate one of the utilities is made. The two error messages are:

UT DEV BUSY	The device requested by the utility is already in use.
UT FMT ERROR	Either the entry used to request the utility is illegal or the utility requested is not loaded, or an attempt has been made to get two utilities to run concurrently; e.g., tape-to-tape and card-to-print.

The messages are automatically erased after 5 seconds and a new display core or modify core command may be entered.

TRACE

The trace utility is available only in the 200 User Terminal emulation controlware. Its loading is enabled

†When using the 722-10 Conversational Display Terminal, US is keyed in by pressing the CONTROL and - keys simultaneously.

via selection-card punching (see section 5). When implemented, the trace utility enables either display or printer monitoring of the communication line activities of the terminal.

To initiate the trace utility, perform the following.

From the keyboard:

- | Procedure | Results/Comments |
|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. Press RESET key to reset cursor or the CONTROL and y keys on the 722-10 | It is not necessary to press the RESET key on the keyboard display if the cursor has not been moved since the previous operation. |
| 2. Key in the following:
TRA,x,y | Where x is F or E; F enables a full trace for monitoring all communication-line activity. E enables a partial trace for monitoring all communication-line activity except POLL-REJECT sequences.

y is 2 or 5; 2 enables the trace to the display, and 5 enables the trace to the line printer. |
| 3. Press the US key or the CONTROL US key† | Trace begins operating by sending communication-line information to the selected device. |

Figure 8-2 shows an example of one line of a trace output.

To discontinue the trace utility, press the STX key or the CONTROL STX key.††

The hexadecimal output from the trace utilities appears in the following format:

R1R2R3R4 R5R6R7R8 S1S2S3S4 S5S6S7S8

- Where:
- R1R2 is the first-word address of buffer holding received data
 - R3R4 is the byte count of received data
 - R5 is the station address of terminal
 - R6 is the message-type indicator for received messages.
 - 05 = Poll
 - 07 = Alert
 - 0C = Reset-write
 - 10 = Diagnostic-write
 - 11 = Write
 - 12 = Clear-write
 - R7 is the E-code indicator for received messages.
 - 42 = E1, write message to display
 - 20 = E2, write message to line printer
 - 21 = E3, write message to card reader
 - 22 = E4, same as E1
 - 00 = Message was either Poll or Alert
 - R8 is 00




Figure 8-2. Typical Example of Trace Output

†When using the 722-10 Conversational Display Terminal, US is keyed in by pressing the CONTROL and - keys simultaneously.

††When using the 722-10 Conversational Display Terminal, STX is keyed in by pressing the CONTROL and B keys simultaneously.

S1S2	is the first-word address of buffer holding transmit data
S3S4	is the byte count of transmit data
S5	is the station address of the terminal
S6	is the message-type indicator for transmit message
	06 = Acknowledge
	13 = Read
	15 = Error
	18 = Reject
S7	is The E code for transmitted messages
	42 = E1, message from keyboard
	20 = E2, card reader or line printer not ready
	21 = E3, card reader or line printer ready
S8	is the communication-line error indicator
	01 = No start-of-heading (SOH) character
	02 = Illegal site address
	03 = Station-address error
	04 = Illegal control code in message
	05 = Data buffer overflow
	06 = No end-of-text (ETX) character
	07 = Parity error

Error Message

The following message is displayed when an error is made during the entry of a trace request:

TRA FMT ERROR

The message automatically erases after five seconds and the trace request may then be entered again.

CRASH DUMP

A crash dump is a routine enabling the entire contents of the terminal controller memory to be printed out on the line printer. The routine is called a crash dump because it is used strictly for maintenance purposes. It is not a standard feature utility routine of the terminal controlware; rather, it is a special routine supplied only as a keypunch listing. This listing can be punched onto cards via an 026 or 029 keypunch; the resulting deck then becomes a crash dump card deck.

Once the crash dump deck is punched, a memory dump can be obtained by loading the crash dump routine into memory via the card reader. The procedure for loading the crash dump deck is the same as that used for loading the controlware card deck.

MEMORY DUMP

The memory dump is a useful tool for carrying out patching procedures. Its principal function here is locating routines so that they can be:

- Displayed by the display core utility
- Modified temporarily via the modify core utility
- Tested by letting the system run with the modification

If the modified system does not run satisfactorily, the original contents of memory can easily be restored without the necessity of reloading the controlware deck by using the modify core utility and the memory dump listing. Once a workable modification is found, controlware deck patch cards can be produced to make the modification permanent.

To obtain a memory dump listing:

1. Punch the card deck as listed in figure 8-3. Figure 8-3 lists card codes necessary for dumping an 8K memory. Change the 8 in column 21 of card three to 2, 4, 6, or 8 for dumping 8K, 16K, 24K, or 32K memories, respectively. Change the pqrs on the second card and the last card to the desired starting location of the dump routine. On 8K systems, use 1600. On larger systems, use 2800.
2. Ensure that the line printer is loaded with sufficient forms and is ready (START indicator is lit).
3. Remove any cards from the card reader hopper and stacker areas.
4. Place the crash dump deck in the hopper of the card reader with the deck face down and its 9s row toward the back of the hopper.
5. Press the RESET indicator/switch.
6. Press the STOP switch on the basic operators panel.
7. Press the MASTER CLEAR switch on the basic operators panel.
8. Press the AUTO LOAD switch on the basic operators panel.

The card reader reads the crash dump deck and, as soon as the deck is loaded, the contents of the terminal controller memory begin dumping to the line printer. Lines containing all zeros are not printed.

Figure 8-4 shows a sample portion of a memory dump listing.

80-COLUMN PUNCHED CARD LAYOUT

```

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80
K 7 1 0 0 8 0 0 0 G
K p q r s G L
1 8 0 5 G 0 0 0 0 G 8 0 0 0 G 2 0 2 0 G 0 0 0 0 G 5 8 5 3 G 5 8 0 1 G 0 0 0 0 G
E 8 F E G 0 D F 8 G 5 8 2 1 G 5 8 5 3 G C 8 F 4 G 6 8 F 6 G 0 C 0 F G C E F 4 G
0 1 1 5 G 0 6 A 2 G C 8 F 1 G 0 9 1 0 G 6 8 E F G 1 8 1 1 G 5 8 4 2 G C 0 0 0 G
0 1 2 0 G 6 8 3 4 G E 8 E 9 G 5 8 1 0 G C 8 E 6 G 6 8 3 0 G 0 A 0 F G 0 7 C 2 G
5 8 3 0 G E C E 2 G 5 8 0 9 G D 8 E 0 G 0 6 4 4 G 5 8 3 9 G C 8 D D G 9 8 D A G
0 1 2 1 G 1 8 E 4 G 0 0 0 0 G 0 0 0 0 G 0 A 0 3 G 0 7 C 1 G 0 A 0 2 G 6 8 1 D G
0 8 4 4 G 0 F E 4 G 0 9 F 5 G 0 1 3 1 G 0 9 0 7 G 0 9 3 A G 0 4 8 3 G C 0 1 5 G
0 4 8 3 G C 3 1 4 G D 8 1 2 G 0 6 2 B G E 8 0 F G 0 8 4 4 G 0 7 C 1 G 0 4 8 1 G
C 2 0 D G 0 B 0 0 G 0 3 F E G 0 7 2 6 G 0 6 8 6 G 0 9 F A G 0 1 0 2 G 0 9 0 6 G
1 8 F 5 G 1 C E 1 G 0 2 0 1 G 0 2 0 0 G 0 0 0 0 G 4 0 4 C G 2 0 2 0 G 2 0 2 0 G
0 0 0 0 G 0 8 4 4 G E 8 B 1 G 0 F 6 2 G 0 1 1 2 G 0 A 0 2 G 0 7 C 4 G 1 C F 8 G
0 0 0 0 G E 8 F 0 G 0 A 0 1 G 0 B 0 0 G 0 3 F E G 1 C P A G 0 0 0 0 G E 8 E A G
0 A 2 0 G 0 B 0 0 G 0 3 F E G 0 B 0 0 G 0 2 F E G 0 F C E G 0 1 2 1 G 1 8 F B G
1 C F 5 G
K p q r s G J 1 0 G K 7 1 2 0 0 0 0 0 +

```

- NOTES: 1. SHOWN IN COLUMN 59 OF LAST CARD IS AN 026 PLUS (+) OR AN 029 AMPERSAND (&).
2. IN THE SECOND AND LAST LINES OF THE CRASH DUMP ROUTINE, REPLACE THE LETTERS p, q, r, AND s WITH THE 4-DIGIT HEXADECIMAL ADDRESS DESIRED FOR THE STARTING LOCATION OF THE LOAD OF THE ROUTINE INTO MEMORY. THE DUMP PROGRAM USES 68,000 WORDS OF MEMORY. TYPICALLY, IT IS LOADED INTO A SYSTEM BUFFER AREA AND p, q, r, AND s ARE REPLACED BY 1C00 ON 8K MEMORY SYSTEMS OR 2800 ON SYSTEMS WITH MORE MEMORY.

Figure 8-3. Crash Dump Routine Key punch Listing

HANG 1 ERROR MESSAGE

A HANG 1 error message may appear on the display screen during terminal operation. When it does, the display screen goes blank except for the HANG 1 message. This message indicates a controller malfunction that prevents proper terminal operation. To determine the nature of the malfunction and correct it, perform the following:

1. Press the ESC key.
2. Key in HG. Eight hexadecimal digits (xxxxxxy) appear on the display screen.

If the last digit (y) is 8₁₆ or greater, a memory parity error has occurred. Go to the CYBER 18-05/10 system maintenance manual and perform memory checks for the terminal controller. If the last digit is less than 8, obtain a crash dump printout, fill out a controlware technical assistance request (TAR), and send both the dump and the TAR to the regional technical support group because the problem cannot be readily corrected on-site.

STARTING ADDRESS OF
CRASH DUMP ROUTINE

LO2PH0

0000	1400	0497	0000	0001	0003	0007	000F	001F	003F	007F	00FF	01FF	03FF	07FF	0FFF	1FFF
0010	3FFF	7FFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF
0020	C000	8000	0000	0001	0002	0004	0006	0010	0020	0040	0080	0100	0200	0400	0800	1000
0030	2000	4000	8000	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF
0040	0FFF	8FFF	7FFF	0005	0006	0009	000A	0000	000C	2020	0400	FFFF	051C	0070	0000	0000
0050	434F	5054	5249	4748	5420	434F	4E54	524F	4C20	4441	5441	2043	4F5C	502E	2031	3937
0060	0002	14E2	1AF4	1006	0003	18E2	1AF4	1006	0410	7100	0070	0170	0000	1711	0000	0000
0070	1712	0004	0005	0000	0000	0000	0000	18E5	0000	0000	0001	0001	0000	0000	0000	0000
0080	1006	0000	0000	0000	03C2	0000	0000	0000	0000	FFFF	0000	0000	0000	0000	1006	0000
0090	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
00A0	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
00B0	0000	0000	0000	0000	018E	030E	030E	0141	01A2	02A0	0000	0000	02E5	02E5	0200	0200
00C0	7FFF	050E	0006	0151	0000	000F	0300	060E	1070	08C7	0950	0A20	707F	707F	707F	707F
00D0	7FFF	7FFF	707F	7FFF	7FFF	000F	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF
00E0	FFFF	FFFF	FFFF	FFFF	FFFF	0000	00D5	00C5	0EF4	0000	02F0	1000	0000	0000	7FFF	FFFF
00F0	0000	0000	0000	7FFF	0248	1F18	0000	0000	0103	0005	0007	0003	0004	0004	C210	0000
0100	0000	54C3	000F	7FFF	0216	54FE	0008	068C	0000	54FE	0000	02F0	0000	54FE	0000	02F0
0110	021A	54FE	000A	0979	0000	54FE	0000	02F0	0000	54FE	0000	02F0	0000	54FE	0000	02F0
0120	021B	54FE	000B	044A	0000	54FE	0000	02F0	0000	54FE	000E	0A4F	021B	54FE	0000	04E2
0130	0000	54FE	000A	7FFF	0000	54FE	0000	02F0	0000	54FE	0000	02F0	0000	54FE	0000	02F0
0140	1093	1093	1093	1093	1093	1093	1093	1093	1093	1C91	1C91	0C01	0C01	0401	0401	0001
0150	0000	0000	0500	0603	0160	C000	0164	6816	0A31	6810	C000	0101	E80C	03FE	00FF	0A07
0160	07C1	0481	C207	0800	03FE	0624	0000	18F7	0091	0030	2047	4E41	4818	0164	0000	0000
0170	0000	0000	0000	0000	0000	0000	0000	0000	1200	0406	FFFF	0007	5206	068E	0190	0668
0180	1203	1220	0184	0004	1207	1040	0178	0007	520C	08E4	017C	08C7	1203	0621	0140	0001
0190	0000	0000	0194	0000	0000	0000	0196	0000	0000	0000	019C	0000	0000	0000	01A0	0000
01A0	0000	0000	01A4	0000	0000	0000	01A8	0000	0000	0000	0000	0000	0218	1111	2222	3333
01B0	4444	CCCC	AAAA	0000	1093	FFFF	002C	0003	2222	3333	4444	8000	0001	3807	1093	0003
01C0	0466	044A	0036	03A6	13A7	0E92	0188	018C	1C91	0003	C02H	60FF	C303	0122	5008	6303
01D0	0DF8	0141	18F9	C000	0457	6001	1400	0000	0000	01CF	07C1	0F46	A009	68FA	0726	A00A
01E0	0476	C0E8	0103	0901	88F3	1CF3	C011	1CF1	0000	0000	0000	0000	0000	0000	0000	0000
0200	0000	0000	0000	0000	0000	0000	0000	0000	0000	0500	0000	0000	0604	0800	0000	0000
0210	0000	0000	0000	0909	0900	0909	0900	E0FF	E21E	1201	0802	18FE	5C8A	0122	581A	C0EF
0220	0530	EEOA	E8FA	0DFC	C201	6101	0429	C004	L203	60EF	0476	C0H7	0621	0F22	00C0	0445
0230	C200	0207	1801	0475	C0E7	0400	0446	0022	024C	680E	C088	9000	01FD	0132	C809	54C3
0240	C807	0803	0088	C088	09FE	60FF	1CF1	0001	0629	0500	5400	023H	E8FB	4101	07A2	0428
0250	C001	C622	0400	012D	A011	07C2	054F	E00A	0101	0622	C622	0131	1815	056E	F022	0A0B
0260	1813	053E	E00A	056C	A122	0500	0585	3105	056C	0222	0486	C02A	0F40	0400	A006	8101
0270	6101	056C	D422	09EE	0126	0911	0486	C005	0500	6818	1818	54C3	0278	0368	0368	0468
0280	0368	7FFF	0368	0278	0426	0326	0278	0278	0278	0278	0368	0278	029A	0500	C101	6805
0290	0802	0088	0400	1400	062C	3660	0606	0023	0500	0002	053F	E00A	0766	07C2	188A	03D9
02A0	0500	482F	C622	A028	0101	0414	6817	0121	F032	E205	0162	0834	1803	C623	0905	A011
02B0	1805	0000	6000	2020	028A	5853	5801	0287	E8FE	00F8	5821	5853	C8F4	68F6	C00F	CEFA
02C0	0115	06A2	C8F1	0910	68EF	1811	5842	C000	0120	6834	E8E9	5810	C8E6	6830	0A0F	07C2
02D0	5830	ECE2	5809	D8E0	0644	5839	C800	98DA	0121	18E4	0000	02D3	0A03	07C1	0A02	6810
02E0	0844	0FE4	09F5	0131	0907	093A	0483	C015	0483	C314	0812	0628	E80F	0884	07C1	0481
02F0	C200	0800	03FE	0726	0686	09FA	0102	0906	18F5	1CE1	0201	0200	0006	2020	3230	3330
0300	02D1	0844	E861	0F62	0112	0A02	07C4	1CF8	02C7	E8F0	0A01	0800	03FE	1CFA	0206	E8EA
0310	E420	0800	03FE	0800	02FE	0FCE	0121	18FE	1CF5	548E	0500	4C07	0745	052E	FF02	0814
0320	E203	0E04	0104	0178	0034	0000	C622	07C3	A006	0530	330A	0429	C001	056C	D422	09F6
0330	0116	C622	A028	B622	07C3	548E	5828	C106	6203	0500	E0EF	C223	68E8	07A4	E000	02EF
0340	0DFD	07A3	0500	0426	C023	88DF	0101	18F1	C202	013A	0822	053C	330A	6810	C622	A006
0350	9800	0132	0400	18E0	041E	C002	0416	C102	041A	C102	053E	F006	1489	0000	042F	0500
0360	E084	0161	54C3	C202	608A	07A2	0466	C122	0429	C101	1CF3	056C	7322	053D	730A	0804
0370	6202	053E	F006	C203	548C	07A1	F0E6	0DFD	0500	07A3	E202	0171	18FC	041F	C002	0416
0380	C102	041A	C102	0400	044D	C0E7	0500	C205	0101	180A	0400	0429	C105	F032	0500	4803
0390	F011	54FA	88C7	14B9	0800	0500	C8FD	0400	610F	0C00	C108	910A	010F	C109	0FCD	0121
03A0	D10A	0FC2	0139	C108	910A	0106	E106	00FE	C10A	6622	6106	E031	C108	A031	0106	0FC1
03B0	0872	0A01	A10C	0FCD	0872	C00F	A109	0874	6109	E10F	1622	08E6	0500	C8FD	610F	A000
03C0	610A	E105	0142	E6E6	0164	6105	E10F	0400	1622	4106	C202	E105	0400	66E6	053F	F008
03D0	E106	056C	B122	6109	052C	C003	0530	3009	548D	410A	E106	548F	4108	C108	810A	0121
03E0	A201	6106	E10F	1201	0420	0500	E8FD	0400	410F	0AFF	6104	E106	053C	F209	052D	F203
03F0	C201	0112	6202	1809	056F	F022	0500	4804	E203	54F4	2000	138C	053E	F108	E10F	1622
0400	0800	0500	0852	0834	0400	1CFA	0A01	60FF	C4E7	90FF	0122	5815	14EA	E57E	017F	0814
0410	8011	010C	C204	013A	09FE	6204	0127	C602	6804	C203	6803	54F4	0000	0000	00FF	18E8
0420	040C	54FA	101D	0406	000A	1CFA	548E	0554	3322	8000	1200	07C3	0744	5400	035E	C838
0430	6202	4838	0426	C002	6203	1489	044D	0844	6808	E808	C000	0442	0806	E000	00F3	0309
0440	1CF5	6088	80F0	0008	001E	0000	54C3	1804	54C3	18F5	E8F3	02FA	58E9	D0E8	E000	0465
0450	40FF	E102	0161	14EA	C203	0103	09FE	6203	18F7	C201	6808	C622	6808	C202	6102	C084
0460	6202	4084	E0F8	54F4	1203	0621	18EA	018C	C201	548C	07A4	E6E7	07A3	0401	C022	0416
0470	C002	0131	1815	0FC1	0500	0132	C205	011F	0444	C200	020F	0113	E207	0216	180A	0476
0480	C0E8	0111	1811	0434	5001	0765	1802	C20C	6107	0400	041E	C00E	09FE	6106	0726	041E
0490	D008	6106	14B9	0800	C032	07C1	18F1	0500	C000	01AC	6088	0804	6400	02EF	6400	0467
04A0	C000	0178	6084	0C00	0811	07C7	0904	6302	07C1	0004	0814	9000	0034	0102	0726	18F6
04B0	0DFD	0804	6722	0444	C0E6	000C	0785	F0E6	00FD	C202	052E	FF02	0132	07C5	18FA	0567
04C0	FFEE	068C	F4E7	C6E7	07C7	H011	0106	0AFF	6104	C106	0102	0536	FF02	0A00	6106	6105

Figure 8-4. Sample Portion of Memory Dump

LOADER ERROR MESSAGES

During controlware loading, the selective loader writes numbers on the display screen to indicate whether the loader is working properly. The messages displayed are in the form of two numeric characters, ranging from 00 to 99. Not all possible number combinations are used, and the numbers that are used are divided into two groups: information-only numbers (00 through 19) and error messages (20 through 99). The following are listings of numbers displayable and their interpretation.

Information-Only Messages:

<u>Number</u>	<u>Significance</u>
00	All of the autoloader cards (bootstrap routine) have been read successfully and the selective loader has started executing.
01	The first card has been read from the card reader by the loader.
04	Start of another routine to be loaded
06	Start of a routine to be bypassed by loader
14	Patch card processed and patched into memory
16	Patch card bypassed because routine name on card was not found in memory.
19	Loading is complete. No errors detected.

Error Messages:

<u>Number</u>	<u>Significance</u>
53	Checksum error in the bootstrap routine loaded via the card reader autoloader of terminal controller.
56	Memory overflow: controlware being loaded exceeds the memory capacity of the terminal controller.
61	Patch card error. A nonhexadecimal entry encountered in a numeric field of the patch card.
62	Patch card error. Loader expected to find more information on the last card read.
63	Patch card error. Too large a numeric entry on last card read. Largest allowable number is FFFF ₁₆ .
64	The patch count on the last card is too large.

<u>Number</u>	<u>Significance</u>
71	Checksum error on the last card read.
72	Sequence error on the last card read. The sequence number is that punched in column 79 of a controlware section card. There are two sequence-number breaks in the controlware section that the system is aware of and corrects for. The first is near the start of the controlware section, and when encountered, the sequence counter resets to 1 and begins a new count. The second is near the end of the deck, and when encountered, the sequence counter resets to the count prior to its reset to 1. Sequence errors other than these two cause the error condition.
76	Card reader error.

In some instances, a load attempt may not progress far enough to provide a significant (greater than 19) error message; that is, either no cards load and no error message appears or just a few load and information-only messages appear. In such instances, the fault can be either in the card reader or in the bootstrap loader of the terminal controller. The procedure for determining the cause of the stoppage in such instances is as follows:

1. Check the card reader setup.
2. Recheck all settings of terminal switches and controls.
3. Re-attempt the load.
4. If second load attempt fails, a quick check of the bootstrap loader and the card reader function can be made by trying to load the crash dump card deck described in section 8 of this manual.
5. If the crash dump deck does not load, go to the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual for the terminal and begin fault isolation procedures.
6. If the crash dump deck does load, try a spare controlware card deck or examine the original one for light-absorbing markings or particles on the back sides of the first few cards and try a reload.
7. If no controlware deck loads past the first few cards, go to the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual and begin fault isolation procedures.
8. If a controlware deck loads far enough to provide a significant error message (greater than 19), continue with the following portion of this section.

Error messages differ from informative messages in that error messages cause the loading process to stop immediately after the error message is detected and displayed. When an error condition occurs on the first attempt to load any controlware deck, perform steps 1 through 6 of the following procedure. Step 6 of the procedure returns to the initial controlware loading procedure, and if the deck loads properly on the second attempt, this section need not be returned to. If a deck fails to load on a second attempt, return to this section for further instructions.

1. Write down the error message number.
2. Remove the cards from the card reader stacker and place them face down on a flat surface.
3. Remove the last card from the back of the portion of deck removed in step 2, and mark it lightly with a pencil on its front side or top edge so that it can easily be identified.
4. Place the marked card back in its original position in portion of deck removed from stacker in step 2.
5. Remove the unread cards from card reader hopper and place them face down on top of cards removed from stacker so that deck is in original sequence.
6. Reload the entire deck and repeat the procedure under Controlware Loading in section 6.

If a deck fails to load on a second attempt, carry out steps 1 through 5 of the preceding procedure and then try loading a spare deck if one is available. If spare deck fails or if one is not available, continue with suggested solutions for various error messages before calling for technical support assistance or filling out a TAR on controlware.

<u>Error Code</u>	<u>Suggested Solution</u>
53	Card reader bootstrap routine is in the portion of the deck preceding selection card. This portion of deck is Hollerith punched and can be interpreted on a keypunch machine. Have this portion of the deck interpreted (failing card in particular if load fails at same card). Obtain a listing of card reader bootstrap codes (e.g., from a card-to-print from any good controlware deck and operating terminal) and make a card-by-card comparison of printouts and interpretations until error is found (checksums are in column 80). Correct error on key-punch and try reload.
56	Contact the customer engineer.

<u>Error Code</u>	<u>Suggested Solution</u>
61-64	Patch cards are at end of deck, immediately preceding last card. Identify and check their contents using patch card information in section 7 of this manual. Correct any errors found and try reloading deck.
71	Examine back of last card read. If any light-absorbing marks are present, duplicate card on keypunch capable of binary card punching. Check newly punched card against original to verify punching and try reloading deck.
72	Only controlware portion of deck has binary sequence numbers in column 79. This portion of deck runs from about 5 cards after selection card to about 5 cards from end of the deck (excluding any patch cards). Using the ASCII/hexadecimal/Hollerith conversion table in appendix B of this manual, start checking sequence numbers in column 79 for proper sequence. Correct any discontinuities in sequence and try reloading deck. Gross sequence discontinuities can be also noted via the writing on the top edge of a deck. Missing cards in the controlware portion of a deck render the deck useless.
76	Examine card deck for damaged or mutilated cards. If none are found, go to the Operator Troubleshooting section of the appropriate operators guide or to the visual and mechanical card reader DDLTs in section 6 of the CYBER 18-05/10 Computer Systems Hardware Maintenance Manual.

If suggested solutions do not correct a controlware loading problem, call for technical support personnel having controlware expertise. Fill out TAR on controlware.

SUBSEQUENT-LOAD HARDWARE ERROR REPORTING

The controlware incorporates a means of logging and reporting hardware errors detected during terminal operation. The hardware error log is useful to terminal maintenance personnel as an aid in diagnosing terminal device malfunctions. A display of the error log is obtained simply by reloading the controlware deck after the terminal has been operating for a time. The terminal controller cannot be powered off before the controlware reload or the error log information is lost. That is, the error log contains only operating errors that have occurred since the last controlware load; it therefore assumes that the terminal has been operating for a time.

The following list provides logical unit number assignments for determining the cause of an error (device or controlware) and error code assignments for determining the nature of the error.

<u>Logical Unit Number Assignments</u>	<u>Device</u>
1	Controlware
2	Keyboard display
3	Controlware
4	Card reader
5	Line printer
6	Data set adapter
7	Controlware
8	Magnetic tape transport 1
9	Magnetic tape transport 2
A	Magnetic tape transport 3
B	Unused
C	Controlware
D	Controlware
E	Controlware
F	Unused

<u>Error Number Assignments</u>	<u>Error Type</u>
0	Diagnostic timeout
1	Lost data

<u>Error Number Assignments</u>	<u>Error Type</u>
2	Alarm
3	Parity error
5	Internal reject
6	External reject
D	No write ring on tape unit
E	Not ready
15	Data not available
16	Stacker full
17	Hopper empty
18	Card feed failure
19	Card jam
1B	Data set adapter initialization failed
1F	Short record
20	No sync match
21	Carrier dropped
26	Out of paper
29	Irrecoverable error
3B	Output ADT failed. ADT is auto-data transfer. An attempt was made by the terminal to transmit data over the communication lines and the transmission was incomplete.)



HEXADECIMAL CODE CONVERSIONS

B

TABLE B-1. ASCII/BCD/HEXADECIMAL CARD-PUNCH CODE CONVERSIONS

ASCII			Printer CDT Keyboard Character	BCD				EBCDIC	
026 Card Punch Code	029 Card Punch Code	ASCII Code		Internal BCD Code	External BCD Code	026 Card Punch Code	029 Card Punch Code	Hex. Code	029 Card Punch Code
No punch	No punch	2/0-20 ₍₁₆₎	space	30 ₍₁₆₎	50 ₍₁₆₎	No punch	No punch	40	No punch
11-0 or 11-8-2	11-0 or 12-8-7	2/1-21	! exclamation point	2A	2A	11-0 11-8-2	11-0 12-8-7	4F	12-7-8
8-4	8-7	2/2-22	" quote	4C	4C	8-4	8-7	7F	8-7
0-8-6	8-3	2/3-23	#	3E	5E	0-8-6	8-3	7B	8-3
11-8-3	11-8-3	2/4-24	\$	2B	2B	11-8-3	11-8-3	5B	11-8-3
8-6	0-8-4	2/5-25	%	4E	4E	8-6	0-8-4	6C	0-8-4
0-8-7	12	2/6-26	&	3F	5F	0-8-7	12	50	12
11-8-5	8-5	2/7-27	' apostrophe	2D	2D	11-8-5	8-5	7D	8-5
0-8-4	12-8-5	2/8-28	(3C	5C	0-8-4	12-8-5	8D	12-8-5
12-8-4	11-8-5	2/9-29)	5C	3C	12-8-4	11-8-5	5D	11-8-5
11-8-4	11-8-4	2/10-2A	*	2C	2C	11-8-4	11-8-4	5C	11-8-4
12	12-8-6	2/11-2B	+	50	30	12	12-8-6	8E	12-8-6
0-8-3	0-8-3	2/12-2C	, comma	3B	5B	0-8-3	0-8-3	6B	0-8-3
11	11	2/13-2D	- hyphen	20	20	11	11	60	11
12-8-3	12-8-3	2/14-2E	. period	5B	3B	12-8-3	12-8-3	4B	12-8-3
0-1	0-1	2/15-2F	/	31	51	0-1	0-1	61	0-1
0	0	3/0-30	0	40	4A	0	0	F0	0
1	1	3/1-31	1	41	41	1	1	F1	1
2	2	3/2-32	2	42	42	2	2	F2	2
3	3	3/3-33	3	43	43	3	3	F3	3
4	4	3/4-34	4	44	44	4	4	F4	4
5	5	3/5-35	5	45	45	5	5	F5	5
6	6	3/6-36	6	46	46	6	6	F6	6
7	7	3/7-37	7	47	47	7	7	F7	7

NOTE: THE BCD TERMINAL IS A 63-CHARACTER DEVICE. ASCII !, [, AND] GRAPHICS ARE ACTUALLY EBCDIC I, { , AND } . FOR COMPLETE EBCDIC CHARACTER SET, SEE BATCH TERMINAL CONTROL-WARE REFERENCE MANUAL 96768910, SECTION 5.

TABLE B-1. ASCII/BCD/HEXADECIMAL CARD-PUNCH CODE CONVERSIONS (Continued)

ASCII			Printer CDT Keyboard Character	BCD				EBCDIC	
026 Card Punch Code	029 Card Punch Code	ASCII Code		Internal BCD Code	External BCD Code	026 Card Punch Code	029 Card Punch Code	Hex. Code	029 Card Punch
8	8	3/8-38	8	48	48	8	8	F8	8
9	9	3/9-39	9	49	49	9	9	F9	9
8-2	8-2	3/10-3A	: colon	4A	40	8-2	8-2	7A	8-2
12-8-7	11-8-6	3/11-3B	;	5F	3F	12-8-7	11-8-6	5E	11-8-6
12-0 or 12-8-2	12-0 or 12-8-4	3/12-3C	<	5A	3A	12-0 12-8-2	12-8-4 12-0	4C	12-8-4
8-3	8-6	3/13-3D	=	4B	4B	8-3	8-6	7E	8-6
11-8-7	0-8-6	2/14-3E	>	2F	2F	11-8-7	0-8-6	6E	0-8-6
11-8-6	0-8-7	3/15-3F	?	2E	2E	11-8-6	0-8-7	6F	0-8-7
8-5	8-4	4/0-40	@	4D	4D	8-5	8-4	7C	8-4
12-1	12-1	4/1-41	A	51	31	12-1	12-1	C1	12-1
12-2	12-2	4/2-42	B	52	32	12-2	12-2	C2	12-2
12-3	12-3	4/3-43	C	53	33	12-3	12-3	C3	12-3
12-4	12-4	4/4-44	D	54	34	12-4	12-4	C4	12-4
12-5	12-5	4/5-45	E	55	35	12-5	12-5	C5	12-5
12-6	12-6	4/6-46	F	56	36	12-6	12-6	C6	12-6
12-7	12-7	4/7-47	G	57	37	12-7	12-7	C7	12-7
12-8	12-8	4/8-48	H	58	38	12-8	12-8	C8	12-8
12-9	12-9	4/9-49	I	59	39	12-9	12-9	C9	12-9
11-1	11-1	4/10-4A	J	21	21	11-1	11-1	D1	11-1
11-2	11-2	4/11-4B	K	22	22	11-2	11-2	D2	11-2
11-3	11-3	4/12-4C	L	23	23	11-3	11-3	D3	11-3
11-4	11-4	4/13-4D	M	24	24	11-4	11-4	D4	11-4
11-5	11-5	4/14-4E	N	25	25	11-5	11-5	D5	11-5
11-6	11-6	4/15-4F	O	26	26	11-6	11-6	D6	11-6
11-7	11-7	5/0-50	P	27	27	11-7	11-7	D7	11-7

NOTE: THE BCD TERMINAL IS A 63-CHARACTER DEVICE. ASCII !, [, AND] GRAPHICS ARE ACTUALLY EBCDIC I, {, AND }. FOR COMPLETE EBCDIC CHARACTER SET, SEE BATCH TERMINAL CONTROLWARE REFERENCE MANUAL 96768910, SECTION 5.

TABLE B-1. ASCII/BCD/HEXADECIMAL CARD-PUNCH CODE CONVERSIONS (Continued)

ASCII			Printer CDT Keyboard Character	BCD				EBCDIC	
026 Card Punch Code	029 Card Punch Code	ASCII Code		Internal BCD Code	External BCD Code	026 Card Punch Code	029 Card Punch Code	Hex. Code	029 Card Punch
11-8	11-8	5/1-51	Q	28	28	11-8	11-8	D8	11-8
11-9	11-9	5/2-52	R	29	29	11-9	11-9	D9	11-9
0-2	0-2	5/3-53	S	32	52	0-2	0-2	E2	0-2
0-3	0-3	5/4-54	T	33	53	0-3	0-3	E3	0-3
0-4	0-4	5/5-55	U	34	54	0-4	0-4	E4	0-4
0-5	0-5	5/6-56	V	35	55	0-5	0-5	E5	0-5
0-6	0-6	5/7-57	W	36	56	0-6	0-6	E6	0-6
0-7	0-7	5/8-58	X	37	57	0-7	0-7	E7	0-7
0-8	0-8	5/9-59	Y	38	58	0-8	0-8	E8	0-8
0-9	0-9	5/10-5A	Z	39	59	0-9	0-9	E9	0-9
8-7	12-8-2	5/11-5B	[4F	4F	8-7	8-4	C0	12-0
12-8-5	0-8-2	5/12-5C	\	5D	3D	0-8-2	12-0	E0	0-8-2
0-8-2	11-8-2	5/13-5D]	3A	5A	11-8-2	0-8-2	D0	11-0
12-8-6	11-8-7	5/14-5E	^	5E	3E	12-8-6	11-8-7		
0-8-5	0-8-5	5/15-5F	<u> </u> _ underline	3D	5D	0-8-5	0-8-5	6D	0-8-5

NOTE: THE BCD TERMINAL IS A 63-CHARACTER DEVICE. ASCII !, [, AND] GRAPHICS ARE ACTUALLY EBCDIC I, {, AND }. FOR COMPLETE EBCDIC CHARACTER SET, SEE BATCH TERMINAL CONTROLWARE REFERENCE MANUAL 96768910, SECTION 5.



HARDWARE ERROR MESSAGE LISTING

C

These errors may occur during operation and are displayed on the screen.

Card Reader Errors

<u>Message</u>	<u>Definition</u>
READER ALR	Alarm †
READER CFF	Card feed failure
READER EXR	External reject
READER INR	Internal reject
READER JAM	Card jammed
READER LDT	Lost data †
READER DNR	Device not ready
READER SFL	Stacker full
READER SRC	Short record
READER TOE	Timeout error
READER HMT	Hopper empty
READER IHP	Illegal Hollerith punch

Line Printer Errors

<u>Message</u>	<u>Definition</u>
PRINTER ALR	Alarm †
PRINTER EXR	External reject
PRINTER INR	Internal reject
PRINTER PAR	Parity error
PRINTER OOP	Out of paper
PRINTER DNR	Device not ready
PRINTER TOE	Timeout error

Data Set Errors

<u>Message</u>	<u>Definition</u>
COMM ERROR DIF	Data set initialization failed
COMM ERROR DNA	Data not available
COMM ERROR GHI	Ghost interrupt
COMM ERROR EXR	External reject
COMM ERROR INR	Internal reject
COMM ERROR CDP	Carrier dropped
COMM ERROR LDT	Lost data †
COMM ERROR NSM	No sync match
COMM ERROR OAF	Output ADT failed
COMM ERROR PAR	Parity error
COMM ERROR DNR	Device not ready
COMM ERROR TOE	Timeout error

Magnetic Tape Errors

<u>Message</u>	<u>Definition</u>
MAG TAPE ALR	Alarm †
MAG TAPE IRE	Irrecoverable error
MAG TAPE NWR	No write ring
MAG TAPE PAR	Parity error
MAG TAPE DNR	Device not ready
MAG TAPE SRC	Short record
MAG TAPE TOE	Timeout error

Cyclic Encoder Errors (2780/3780 only)

<u>Message</u>	<u>Definition</u>
ENCODER EXR	External reject
ENCODER IXR	Internal reject

† This message requires an operator response. The message indicates that an error condition occurred but the actual cause of the error cannot be determined by the software. The device may be in either a ready or a not ready condition.



TERMINAL CONFIGURATION SHEET

D

Figure D-1 is a terminal configuration sheet for batch terminals. This form should be reproduced so that one can be filled out to reflect the configuration of each terminal to be maintained. As the copy forms are filled in, they can be punched and included as part of this manual.

Below are the instructions for completing the configuration sheet. Note that entries 1 through 8 are made by physical inspection of the equipment during terminal installation, while entries 9 through 16 are made as a result of analysis of the individual user's requirements for terminal operation.

1. Enter the name of the terminal site at which the terminal is being installed.
 2. Enter the general terminal and controlware types (for example, CYBER 18-10-1/200 UT).
 3. This entry should reflect a particular terminal; it can be any unique name or number assigned to a specific terminal. The terminal controller serial number may be a good identifier to use.
 4. Enter the amount of memory in terminal controller (8K, 16K, 24K, or 32K).
 5. Enter the number of magnetic tape transports (0 to 3) used in the terminal.
 - a. Enter the magnetic tape transport track sizes and designate the transports having a translator with the letter T (for example, nine-track/T).†
 - b. Enter the device address assigned to each magnetic tape transport in the terminal (for example, 0 = tape transport 1, 1 = tape transport 2, 2 = tape transport 3).
 6. Enter the print speed and type of the line printer used in the terminal (for example, 300 lpm CL408-C).
 7. Enter the card-read speed of the card reader used in the terminal (for example, 300 or 600 cpm).
 8. Enter the type of controlware used in this terminal (for example, MD426-Axx).
- User-supplied entries (2780/3780 only):
9. Enter the magnetic tape transport type (7- or 9-track) for each tape unit on the system.
 10. Enter the number of words required for each tape transport buffer; entries are made in decimal.
- User-supplied entries (200 UT only):
11. Answer yes or no, depending upon user's requirements.
 12. Enter the type of transmission-line code to be used.
 13. Enter either "Line" or "Block."
 14. Enter either yes or no.
 15. Enter either two-wire or four-wire.
 16. Enter the number of words required for each tape transport buffer. The entries are made in decimal; defaults to 138 characters if entry is left blank.

The column to the right side of the form represents the 80 columns of a selection card. Once the selection card has been punched, the blanks in the column can be filled in to record the manner in which the selection card was punched.

† Tape transports use internal jumper connections to set their device addresses. The CYBER 18-05/10 Computer Systems Hardware Maintenance Manual describes where these jumpers are and how they are set to give the desired device address. Note that the device address setting in a batch terminal must directly follow the number of tape transports in the terminal; that is, if only two tape transports are used in a terminal, their address jumpers must be set to 0 and 1, and not to either 1 and 2, or 0 and 3. Normally, a tape transport having a translator installed has its address jumpers set to device address 0. In terminals that have mixed track sizes and therefore two tape transports with translators, one should have its address jumpers set to 0 and the other should be set to reflect its position in the terminal (for example, 1 or 2, depending upon whether there are two or three tape transports in the terminal).

GENERAL INFORMATION

- 1) NAME OF TERMINAL SITE _____
- 2) TERMINAL TYPE _____
- 3) TERMINAL ID _____
- 4) AMOUNT OF CONTROLLER MEMORY _____
- 5) NUMBER OF MAGNETIC TAPE TRANSPORTS IN TERMINAL _____
- 6) LINE PRINTER SPEED _____
- 7) CARD READER SPEED _____
- 8) TYPE OF CONTROLWARE USED _____

USER-SUPPLIED INFORMATION

2780/3780 ONLY

- 9) a) MAGNETIC TAPE TRANSPORT TYPES:
TAPE TRANSPORT 1 _____ TAPE TRANSPORT 2 _____ TAPE TRANSPORT 3 _____
- b) DEVICE ADDRESS FOR EACH TAPE TRANSPORT IN TERMINAL:
TAPE TRANSPORT 1 _____ TAPE TRANSPORT 2 _____ TAPE TRANSPORT 3 _____
- 10) MAGNETIC TAPE TRANSPORT BUFFER SIZE(S) IN DECIMAL:
TAPE TRANSPORT 1 _____ TAPE TRANSPORT 2 _____ TAPE TRANSPORT 3 _____

USER-SUPPLIED INFORMATION

200 UT ONLY

- 11) WILL ASCII, EXTERNAL BCD, OR INTERNAL BCD BE USED ON THE TRANSMISSION LINES? _____
- 12) WILL PRINCIPAL MODE OF OPERATION BE EITHER LINE OR BLOCK? _____
- 13) WILL A MODIFIED COMMUNICATION-LINE CODE SET BE USED? _____
- 14) WILL COMMUNICATION-LINE CONNECTION BE TWO- OR FOUR-WIRE? _____
- 15) MAGNETIC TAPE TRANSPORT BUFFER SIZE(S) IN DECIMAL:
TAPE TRANSPORT 1 _____ TAPE TRANSPORT 2 _____ TAPE TRANSPORT 3 _____

Figure D-1. Terminal Configuration Sheet

COMMENT SHEET

MANUAL TITLE CDC® Batch Terminal Controlware Installation Handbook

PUBLICATION NO. 96768900 REVISION H

FROM NAME: _____

BUSINESS
ADDRESS: _____

COMMENTS: This form is not intended to be used as an order blank. Your evaluation of this manual will be welcomed by Control Data Corporation. Any errors, suggested additions or deletions, or general comments may be made below. Please include page number.

Please Reply

No Reply Necessary

CUT ALONG LINE

STAPLE

STAPLE

FOLD

FOLD




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 8241 MINNEAPOLIS, MINN.

POSTAGE WILL BE PAID BY

CONTROL DATA CORPORATION
PUBLICATIONS AND GRAPHICS DIVISION
4455 EASTGATE MALL
LA JOLLA, CALIFORNIA 92037



CUT ALONG LINE

FOLD

FOLD



CORPORATE HEADQUARTERS, P.O. BOX 0, MINNEAPOLIS, MINN. 55440
SALES OFFICES AND SERVICE CENTERS IN MAJOR CITIES THROUGHOUT THE WORLD

LITHO IN U.S.A.



CONTROL DATA CORPORATION