



OpenBoot
Quick Reference
Exemplar
S-Class Servers

Second Edition



OpenBoot Quick Reference

S-Class Servers

B5655-90008

Second Edition

January 1997

Hewlett-Packard Company
Convex Division
Richardson, Texas
United States of America

OpenBoot Quick Reference

S-Class Servers

B5655-90008

© Copyright Hewlett-Packard Company 1997. All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Notice

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.



This entire book is recyclable.

Printed in the United States of America

Revision Information for

OpenBoot Quick Reference

S-Class Servers

Edition	Document No.	Description
Second	B5655-90008	Released with Exemplar OpenBoot V3.0
First	710-029430-000	Released with Exemplar OpenBoot V1.1

Syntax

Commands entered at the OpenBoot ok prompt execute left-to-right after pressing Enter. Enter multiple commands on a single line separated by one or more spaces.

Help commands

`help [category | command]` Lists all help categories, commands for the specified *category* or the individual *command*.

Emergency keyboard commands

Esc Interrupts auto-boot sequence when *auto-boot?* option is *true*

Display commands

<code>.attributes</code>	Displays the current node properties.
<code>.io</code>	Displays the number of PCI units available.
<code>.memory</code>	Displays the memory configuration of the current node.
<code>.obp</code>	Displays the OBP loader release and build version.
<code>.post</code>	Displays POST release version number.
<code>.properties</code>	Same as <code>.attributes</code> .
<code>banner</code>	Displays the power-on banner.
<code>date [-u]</code>	Displays the date in local or universal (<i>u</i>) time coordinates.
<code>devalias</code>	Displays all current device aliases.
<code>devalias alias</code>	Displays the device path corresponding to <i>alias</i> .
<code>lifls /flash@1,0</code>	Lists firmware modules located in flash RAM.
<code>list [block-device] [boot-directory]</code>	Displays a directory on any disk drive attached to the system. Commonly used to verify boot files.
<code>ls</code>	Lists device paths under the currently selected node.
<code>pim-info [N [toc hpmc]]</code>	Displays valid TOC or HPMC PIM information for the current CPU or the specified CPU number (<i>N</i>).
<code>printenv [option]</code>	Displays all NVRAM values or the specified NVRAM <i>option</i> .
<code>pwd</code>	Displays current node name.
<code>show-children [device-path]</code>	Displays information about all devices attached to the controller specified by <i>device-path</i> .
<code>show-devs [device-path]</code>	Displays entire device tree or all devices under <i>device-path</i> .
<code>show-map [device unit]</code>	Displays all logical unit mappings or all entries for the named <i>device</i> or logical <i>unit</i> .
<code>show-part [block-device]</code>	Displays all disk partitions or only those for specified <i>block-device</i> .
<code>words</code>	Displays names of the current node's methods.

Configuration commands

<code>date [-u] [mmdhmm[yy]]</code>	Sets the date in local or universal time coordinates (-u).
<code>devalias alias device-path</code>	Sets a temporary device <i>alias</i> representing the <i>device-path</i> . Used until power off or system reset.
<code>mkmap [-n] unit device</code>	Maps a <i>device</i> , i.e., a tape drive or network interface (<i>n</i>), to a logical <i>unit</i> number used by SPP-UX to identify the device.
<code>nvalias alias device-path</code>	Creates a persistent device alias by writing the <code>devalias alias device-path</code> command in NVRAMRC. (Alias persists until <code>nvunalias</code> or <code>set-defaults</code> executes.)
<code>nvunalias alias</code>	Deletes the named <i>alias</i> from NVRAMRC.
<code>password</code>	Sets the security mode password. Prompts twice; once for an 8 character password entry and once for validation.
<code>rmmap device</code>	Undefineds a mapping created with <code>mkmap</code> .
<code>setenv option value</code>	Sets the NVRAM <i>option</i> to the specified decimal or text <i>value</i> .
<code>set-default option</code>	Resets the specified NVRAM <i>option</i> value to the factory default.
<code>set-defaults</code>	Resets all NVRAM options values to the factory defaults, if any.
<code>time [-u] [hhmm[ss]]</code>	Sets the date in local or universal time coordinates (-u).

NVRAMRC commands

<code>nvedit</code>	Invokes the NVRAMRC editor. If data remains in the temporary buffer from a previous <code>nvedit</code> session, it resumes editing that content. If no data remains from a previous session, <code>nvedit</code> reads the current NVRAMRC contents into the buffer for editing. Since <code>nvedit</code> stores its changes only in a temporary buffer, use <code>nvstore</code> to permanently save information to NVRAMRC.
<code>nvquit</code>	Discards temporary buffer contents without writing to NVRAMRC. Prompts for confirmation.
<code>nvramrc eval</code>	Executes commands saved in NVRAMRC without rebooting.
<code>nvrecover</code>	Enters the editor and recovers NVRAMRC contents lost by <code>set-defaults</code> if <code>nvedit</code> was not executed after the NVRAMRC contents loss and before <code>nvrecover</code> execution.
<code>nvrn</code>	Executes temporary buffer contents.
<code>nvstore</code>	Copies temporary buffer contents to NVRAMRC.

Keyboard editor commands

Ctrl-A	Go to start of line
Ctrl-B	Go back one character
Ctrl-D	Delete current character
Ctrl-E	Go to end of line

Ctrl-F	Go forward one character
Ctrl-H	Delete previous character (also Del or Backspace keys)
Ctrl-K	Delete to end of line
Ctrl-L	Show command history list, then retype line
Ctrl-N	Recall subsequent command line
Ctrl-P	Recall previous command line
Ctrl-Q	Quote next character (to type a control character)
Ctrl-R	Retype line
Ctrl-U	Delete entire line
Ctrl-W	Delete previous word
Ctrl-Y	Insert save buffer contents before the cursor
Esc B	Go to previous word
Esc D	Delete from cursor to end of word
Esc F	Go to next word
Esc H	Delete from cursor to beginning of word (also Ctrl-W)
Ctrl-Space	Complete the current command
Ctrl-/	Show all possible matches/completions
Ctrl-?	Show all possible matches/completions
Ctrl-}	Show all possible matches/completions

Device tree browsing commands

<code>cd <i>device-path</i></code>	Selects the indicated device node, making it the current node.
<code>cd <i>node-name</i></code>	Selects the first node with the given name in the subtree below the current node.
<code>cd ..</code>	Selects the parent of the current device node.
<code>cd /</code>	Selects the root machine node.
<code>device-end</code>	Deselects the current device node, leaving no node selected.

Boot commands

<code>boot [<i>device</i>] [<i>boot-directory</i>] [<i>boot-arguments</i>]</code>	<ul style="list-style-type: none"> <i>device</i> is the full device path name or alias. Examples: <code>sd0a</code> (alias for default SCSI disk root partition) <code>rmt0</code> (alias for default SCSI DAT install tape drive) <code>fddi0</code> (alias for FDDI network controller) <i>boot-directory</i> is the HFS full directory path name in the boot partition containing the three boot files (<code>mach</code>, <code>server</code>, and <code>tunables</code>). Valid only for disk devices. <i>boot-args</i> <ul style="list-style-type: none"> <code>-s</code> — Boots SPP-UX in single-user mode if <code>boot-file=mach</code>. <code>-mk-debug</code> — Microkernel waits for <code>kgdb</code> to attach. <code>-halt</code> — Halt after loading <code>-noheader</code> — <i>boot-file</i> is Forth or FCode, not <code>a.out</code>.
<code>reset</code>	Restarts POST.
<code>soft-reset</code>	Resets the system forcing <code>core</code> mode reboot (debug mode).

File loading commands

fwcp [*test station IP address:source file*] [*sector / FILE*]

Loads firmware modules to flash RAM.

go Begin executing a previously loaded binary program, or resume executing an interrupted program.

load [*specifiers*] Load file(s) from specified source. Specifiers are same as for *boot*.

source [*devspec*][*nfs-server*:]*full-pathname* \ *filepathname*

Loads and interprets a Forth file from the default *boot-device* file system.

Number base commands

.d Display *n* in decimal without changing base.

.h Display *n* in hex without changing base.

binary Set the number base to 2.

d# number Interpret the next number in decimal.

decimal Set the number base to 10.

h# number Interpret the next number in hex; base is unchanged.

hex Set the number base to 16.

octal Set the number base to 8.

ROBP commands

ROBP provides restricted OBP functionality after the system boots or to control user access before boot time. Set *security-mode* to *command* or *full* to invoke ROBP at boot time and require password access to higher level OBP commands. The following OBP commands are available in ROBP while the operating system is running:

<i>.attributes</i>	<i>.io</i>	<i>.memory</i>
<i>.obp</i>	<i>.post</i>	<i>.properties</i>
<i>banner</i>	<i>date</i>	<i>dealias</i>
<i>dealias</i>	<i>lifls</i>	<i>list</i>
<i>ls</i>	<i>pim-info</i>	<i>printenv</i>
<i>pwd</i>	<i>show-children</i>	<i>show-devs</i>
<i>show-map</i>	<i>show-part</i>	<i>words</i>

The following commands work only in ROBP:

_version Displays the *robp* version number.

_quit Quit *robp*.

OBP options

Option Default value Data type	Description
<i>alternate-obp?</i> false boolean	When true, the OBP loaded in the TC area of flash memory boots instead of the one loaded in the normal OBP area.
<i>auto-boot?</i> false boolean	Determines if OBP automatically probes the I/O system and boots the operating system.
<i>auto-search</i>	Determines whether OBP ignores boot parameters and searches all devices for boot media. Normally false since searching all SCSI devices on over 20 PCI slots significantly slows boot time.
<i>boot-args</i> <no-default> null string	Possible values are: -s Boots SPP-UX in single-user mode if <i>boot-file</i> =mach. -mk-debug Microkernel waits for kgdb to attach. -halt Halt after loading -noheader <i>boot-file</i> is Forth or FCode, not a.out.
<i>boot-device</i> /pci@fe,2100000/qlisp@0,0/sd@2,0:a string	Specifies programs OBP loads when <i>boot-mode</i> is sppux. The default is the root drive located internally opposite the ECUB, PCI slot 2 on EPIC 4, SCSI disk target 2, partition a. If <i>boot-file</i> value is mach, OBP loads both tunables and server.
<i>boot-directory</i> /stand/spp3 string	Directory containing the mach, tunables, and server files. If <i>boot-device</i> is a network device, use the syntax <i>ip#:/directory_path</i> where <i>ip#</i> is the NFS server IP address.
<i>boot-file</i> mach string	If value is mach, OBP attempts to load the tunables and server from the <i>boot-directory</i> .
<i>boot-mode</i> core bootmode	After a soft-reset, OBP boots in core mode and skips POST initialization regardless of the actual value of boot-mode.
<i>cache-error-fdce</i> false boolean	Debug flag.
<i>cache-error-reset</i> false boolean	Debug flag.

Option Default value Data type	Description
<i>cpu-clock-speed</i> 0 MHz	Determines clock calibration method. If the value is 0, OBP causes each CPU to self-calibrate its clock frequency using the Exemplar Time-of-Century counter. Other possible values are 120 and 180, the frequency in Megahertz OBP uses to calibrate the CPU.
<i>dns-ip#</i> <no default> ip#	DNS IP address used to resolve hostnames in <i>boot-directory</i> when booting or loading from the network.
<i>dr2</i> 00000000.00000000 hexint64	Along with <i>rdr9</i> , <i>PDC_ENTRY</i> and OBP use this value to diagnose register initial contents when a machine is reset.
<i>fcode-debug?</i> false boolean	When <i>true</i> , FCode device drivers output more information when booting.
<i>input-device</i> /core@f0,f0000000/tty:a string	Default is the RS232 port A on the system. Optional values are keyboard, <i>ttya</i> , <i>ttyb</i> , or other input device path name or alias. If the specified device is unavailable after a system reset or power on, input is sent to port 0 (<i>tty:a</i>).
<i>local-mac-address?</i> true boolean	When <i>true</i> , sets <i>/core/lan</i> device driver to use the built in node serial number to derive the Ethernet physical address.
<i>nvrामrc</i> <no default> null string	The NVRAMRC Forth script name OBP executes during the latter phase of booting before probing the I/O system.
<i>nvrाम-erase?</i> false boolean	When OBP cannot boot and reset default values because of corrupt NVRAM, setting this option to <i>true</i> from the test station diagnostic shell clears all NVRAM settings enabling the <i>set-defaults</i> operation during <i>do_reset</i> .
<i>output-device</i> /core@f0,f0000000/tty:a string	Default is the RS232 port A on the system. Optional values are screen, <i>ttya</i> , <i>ttyb</i> , or other output device path name or alias. If the specified device is unavailable after a system reset or power on, output is sent to port 0 (<i>tty:a</i>).

Option Default value Data type	Description
<p><code>pci[X]-fcode-enable</code></p>	<p>X=0-7. Enable booting up to three SCSI controllers each for a designated PCI bus. Specify slot numbers as a comma delimited list (0, 1, 2). Limiting FCode compilation to a single slot permits a full 24-controller system to boot without running out of compiler memory.</p>
<p><code>pim-save-first?</code> false boolean</p>	<p>Used in the machine check handler to alter the overwriting rules. If true, multiple HPMCs or TOCs do not overwrite the first occurrence. When false, each HPMC or TOC is saved.</p>
<p><code>rdr9</code> 00000001.20000000 hexint64</p>	<p>Along with <code>dr2</code>, <code>PDC_ENTRY</code> and <code>OBP</code> use this value to diagnose register initial contents when a machine is reset.</p>
<p><code>screen-#columns</code> 80 int8</p>	<p>Screen column width.</p>
<p><code>screen-#rows</code> 24 int8</p>	<p>Number of screen rows (lines). Use when a terminal has a scrollbar. Set to 0 to disable paging.</p>
<p><code>security-#badlogins</code> <no default> int32</p>	<p>Stores the number of incorrect security password entries.</p>
<p><code>security-mode</code> none security</p>	<p>Other possible values are <code>command</code> and <code>full</code>. It is not recommended to set this value in <code>NVRAMRC</code>.</p>
<p><code>security-password</code> <no default> password</p>	<p>Stores the password set by the <code>password</code> command to access the <code>OBP</code> unrestricted mode.</p>
<p><code>system-mac-address</code> <no default> mac#</p>	<p>Set only when <code>local-mac-address?</code> value is false.</p>
<p><code>tz</code> CST6CDT,92/03:00,302/01:00 string</p>	<p>Controls time zone and daylight savings time conversion rules for the <code>date</code> command I/O.</p>
<p><code>udp-log#</code> <no default> int32</p>	<p>The UDP port number on the test station used to log events.</p>
<p><code>unit-map</code> <no default> mappable</p>	<p>Tape and network peripherals mapping table set by <code>show-map</code>, <code>mkmap</code>, and <code>rmmap</code> instead of <code>setenv</code> and <code>printenv</code>.</p>
<p><code>use-nvramrc?</code> false boolean</p>	<p>Determines whether <code>OBP</code> uses the <code>NVRAMRC</code> file contents to boot. Creating an alias with <code>nvalias</code> automatically sets this flag to true.</p>

POST options

Option Default value Data type	Description
<i>80bit-dimms?</i> false boolean	Flag informing POST of DRAMS size installed in the memory boards.
<i>boot-module</i> obp module	Determines the firmware module to which POST transfers control upon completion. Other possible values are TC and EPSDW.
<i>cachetest?</i> true boolean	Determines if POST executes self-tests on each CPU cache coming out of reset. Caches always initialize, but are tested only when this option is true.
<i>ecubtest?</i> true boolean	When this value is true, the POST monarch processor performs ECUB tests.
<i>emac[X]-ee[0]</i> 5faaaff9.b7ffffab hexint16	X=0-7. Specifies one of the two 64-bit error enable register contents for each of 8 MAC ASICs.
<i>emac[X]-ee[1]</i> 00000000.00ffff569 hexint16	X=0-7. Specifies one of the two 64-bit error enable register contents for each of 8 MAC ASICs.
<i>emuc-ee</i> <no default> hexint16	Specifies the CORE MUC FPGA error enable bits when <i>use-error-overrides?</i> is true.
<i>epac[X]-ee[0]</i> fffffeab.ffffeeee hexint16	X=0-7. Specifies one of the two 64-bit error enable register contents for each of 8 PAC ASICs.
<i>epac[X]-ee[1]</i> ffe5d6bb.ebffffff hexint16	X=0-7. Specifies one of the two 64-bit error enable register contents for each of 8 PAC ASICs.
<i>epic[X]-ee</i> 1557abea.b6aaaa01 hexint16	X=0-7. Specifies the 64-bit error enable register contents for each of 8 PIC ASICs.
<i>epuc-ee</i> <no default> hexint16	Specifies the CORE PUC FPGA error enable bits when <i>use-error-overrides?</i> is true.
<i>erac[X]-ee</i> ed80 hexint16	X=0-3. Specifies the Crossbar ASIC error enable bits when <i>use-error-overrides?</i> is true.
<i>etac[X]-ee</i> d7d65597.bfdfffd5 hexint16	X=0-7. Specifies the 64-bit error enable register contents for each of 8 TAC (SCI) ASICs.
<i>force-monarch?</i> false boolean	When true, both POST and OBP use the <i>monarch#</i> value as boot monarch CPU number.
<i>monarch#</i> 0 int8	Specifies the boot control CPU number OBP uses as monarch when <i>force-monarch?</i> is true. When false, POST and OBP randomly select the monarch.
<i>obp-ip#</i> <no default> ip#	IP number OBP uses as the <i>/core/lan</i> address.
<i>master-error-enable?</i> true boolean	If false and <i>use-error-overrides?</i> is false, POST sets all ASIC error configuration registers to zeros.
<i>post-revision</i> <no default> rev#	A read-only parameter containing the POST firmware software version number.

Option Default value Data type	Description
<i>reduced-bandwidth?</i> false boolean	Determines if POST configures the memory subsystem for reduced bandwidth mode.
<i>selftest?</i> true boolean	When this value is true, POST executes self-tests on each CPU coming out of reset.
<i>ts-ip#</i> <no default> ip#	Test station IP number to which the /lan device is attached.
<i>use-error-overrides?</i> false boolean	If false, POST uses current NVRAM ASIC error configuration parameters instead of POST defaults. If true, <i>master-error-enable?</i> is ignored.
<i>verify-dimms?</i> false boolean	Determines if POST performs a destructive memory test during memory initialization. Normally, POST initializes only the tags and parity of the memory lines using diagnostic CSR writes without performing CPU loads and stores to memory.

Post boot configuration map options

The next set of NVRAM options constitutes a portion of the POST Boot Configuration Map. These values change as a side effect of POST configuration and are not simply user configurable options. For example, if the user tries to enable `cpu[1]` and it is not installed, POST sets the value to `empty`. POST uses the following values to set map parameters:

`enable` or `unknown`

POST autoconfigures the component.

`disable`

POST software deconfigures the component.

`fail`

The component failed a test.

`pass`

The component is normal and usable.

`disabled`

The user deconfigured the component by setting its value to `disable` and rebooting.

`deconfig`

POST deconfigured the component due to configuration rules enforced when a component is manually disabled or unavailable due to test failure.

Option Default value Data type	Description
<i>cpu[X]</i> unknown mapstate	X=0-15. CPU module configuration map.
<i>epac[X]</i> unknown mapstate	X=0-7. PAC configuration map.
<i>epic[X]</i> unknown mapstate	X=0-7. PIC configuration map.
<i>erac[X]</i> unknown mapstate	X=0-3. Crossbar configuration map.



CONVEX
PRESS

B5655-90008

