

**CONVEX VMEbus DAT/3480 Tape Subsystem (*dev_vscsit*)
Diagnostics Manual**

Order No. DHW-247

Second Edition
June 1992

CONVEX Press
Richardson, Texas
United States of America

CONVEX VMEbus DAT/3480 Tape Subsystem
(dev_vscsit) Diagnostics Manual
Order No. DHW-247
Second Edition

Copyright © 1990, 1991, 1992 CONVEX Computer Corporation
All rights reserved.

This document is copyrighted. This document may not, in whole or part, be copied, duplicated, reproduced, translated, electronically stored or reduced to machine readable form without prior written consent from CONVEX Computer Corporation (CONVEX).

Although the material contained herein has been carefully reviewed, CONVEX does not warrant it to be free of errors or omissions. CONVEX reserves the right to make corrections, updates, revisions, or changes to the information contained herein. CONVEX does not warrant the material described herein to be free of patent infringement.

UNLESS PROVIDED OTHERWISE IN WRITING WITH CONVEX COMPUTER CORPORATION (CONVEX), THE EQUIPMENT DESCRIBED HEREIN IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES. THE ABOVE EXCLUSION MAY NOT BE APPLICABLE TO ALL PURCHASERS BECAUSE WARRANTY RIGHTS CAN VARY FROM STATE TO STATE. IN NO EVENT WILL CONVEX BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING ANY LOST PROFITS OR LOST SAVINGS, ARISING OUT OF THE USE OR INABILITY TO USE THIS EQUIPMENT. CONVEX WILL NOT BE LIABLE EVEN IF IT HAS BEEN NOTIFIED OF THE POSSIBILITY OF SUCH DAMAGE BY THE PURCHASER OR ANY THIRD PARTY.

CONVEX and the CONVEX logo ("C") are registered trademarks of CONVEX Computer Corporation.
C100 Series, C200 Series, and ConvexOS are registered trademarks of CONVEX Computer Corporation
C1, C120, C201, C202, C210, C220, C230 and C240 are trademarks of CONVEX Computer Corporation.
UNIX is a registered trademark of UNIX System Laboratories, Inc.

Printed in the United States of America

Revision history
CONVEX VMEbus DAT/3480 Tape Subsystem
(dev_vscsit) Diagnostics Manual

Edition	Document No.	Description
Second Edition	760-003530-002	Released June 1992. Added subtests to test EDRC data compression. Added information on how to load test tape cartridges. Added debugger commands.
First, Rev. 1	760-003530-001	Released September 1991
First	760-003530-000	Released May 1991

THIS PAGE INTENTIONALLY LEFT BLANK

Table of Contents

1 Diagnostics environment

1.1 Overview	1-1
1.2 Operating system	1-1
1.2.1 EGOS for the Multibus interface	1-2
1.2.2 EGOS for VMEbus interface (VIOP EGOS)	1-2
1.2.3 EGOS for HSP interface (HSP EGOS)	1-2
1.2.4 EGOS for HIPPI (HIPPI EGOS)	1-2
1.2.5 EGOS's position in the environment	1-2
1.3 dshell utility overview	1-4
1.3.1 Diagnostic shell (dshell) overview	1-4
1.3.2 dshell commands	1-4
1.3.3 Syntax help for dshell commands	1-6

2 VMEbus DAT/3480 tape subsystem test (dev_vscs1t)

2.1 Overview	2-1
2.2 Prerequisites	2-2
2.2.1 Hardware requirements	2-3
2.2.2 Software requirements	2-4
2.2.3 Setting the 3480-compatible formatter unit number	2-5
2.2.4 Setting the 3480-compatible tape unit logical address	2-5
2.2.5 Setting the DAT drive unit number	2-5
2.3 Test invocation	2-6
2.3.1 Loading test tape cartridges	2-6
2.3.2 Starting dev_vscs1t	2-7
2.3.3 Test Parameter Menu	2-9
2.4 Initialization sequence for dev_vscs1t	2-11
2.4.1 Prompt explanations	2-12
2.5 Class descriptions	2-17
2.6 Class 1 subtests, SCSI host adapter tests	2-17
2.6.1 Subtest 100, host adapter identify test	2-18
2.6.2 Subtest 101, host adapter RAM test	2-18
2.6.3 Subtest 102, host adapter PROM test	2-18
2.7 Class 2 subtests, tape controller and logical unit self-test	2-19
2.7.1 Subtest 200, tape controller self-test	2-20
2.7.2 Subtest 201, tape logical unit self-test	2-22
2.8 Class 3 subtests, tape drive tests	2-25
2.8.1 Subtest 300, tape mark test	2-26
2.8.2 Subtest 301, space record test	2-27
2.8.3 Subtest 302, erase test	2-27
2.8.4 Subtest 303, long block read test	2-28
2.8.5 Subtest 304, fixed record size read/write test	2-28
2.8.6 Subtest 305, write file UNIX-style test	2-29
2.8.7 Subtest 306, variable size records test	2-29
2.8.8 Subtest 307, long space test	2-30
2.8.9 Subtest 308, tape release test	2-31
2.8.10 Subtest 309, compression ratio test	2-31
2.8.11 Compressed mode tests	2-31
2.9 Class 4 subtests, tape driver exception tests	2-32
2.9.1 Subtest 400, beginning-of-tape (BOT) status exception test	2-33

2.9.2	Subtest 401, zero-length operations exception test	2-33
2.9.3	Subtest 402, end-of-data (EOD) status exception test	2-34
2.9.4	Subtest 403, end-of-tape (EOT) status exception test	2-34
2.9.5	Compressed mode tests	2-34
2.10	Class 5 subtests, automatic cartridge loader (ACL) tests	2-35
2.10.1	Subtest 500, stacker automatic mode test	2-35
2.10.2	Subtest 501, stacker system test	2-35
2.11	Interactive debugger	2-36
2.12	Interactive debugger command descriptions	2-38
2.12.1	help	2-38
2.12.2	boot	2-38
2.12.3	cd	2-39
2.12.4	changeunit	2-39
2.12.5	daidentify	2-39
2.12.6	dapseltest	2-39
2.12.7	darseltest	2-39
2.12.8	dfcselftest	2-39
2.12.9	dfdispload	2-39
2.12.10	dfrecvdiag	2-40
2.12.11	dfuselftest	2-40
2.12.12	dtidentify	2-40
2.12.13	echo	2-40
2.12.14	erase	2-40
2.12.15	fb, fl, fw	2-41
2.12.16	ffb, ffl, ffw	2-42
2.12.17	fsr, bsr, fsf, bsf	2-42
2.12.18	laststatus	2-42
2.12.19	mb, mw, ml	2-43
2.12.20	mmb, mmw, mml	2-44
2.12.21	notimeout	2-44
2.12.22	pause	2-44
2.12.23	quit	2-45
2.12.24	reset	2-45
2.12.25	rewind	2-45
2.12.26	rphys	2-45
2.12.27	scsi	2-45
2.12.28	scsimm	2-45
2.12.29	status	2-46
2.12.30	stkload	2-46
2.12.31	stkloadmag	2-46
2.12.32	stkmode	2-46
2.12.33	stkselect	2-46
2.12.34	stkstat	2-46
2.12.35	stkunload	2-47
2.12.36	tracemsgs	2-47
2.12.37	unitclr	2-47
2.12.38	unload	2-47
2.12.39	weof	2-47
2.12.40	wphys	2-47
2.13	Using a test script	2-47
2.14	SCSI host adapter status and error information	2-50
2.14.1	Flags byte	2-50
2.14.2	Error byte	2-51

2.14.3 Host adapter status byte	2-52
2.15 Tape system status and error information	2-52
2.15.1 Sense data	2-53
2.15.2 Sense byte description	2-54
2.16 Error examples	2-64

List of Tables

1-1 dshell commands	1-5
2-1 SCSI interface commands	2-2
2-2 Hardware requirements	2-3
2-3 ConvexOS requirements summary	2-4
2-4 DAT drive dip switch settings	2-6
2-5 Getting help during test parameter entry	2-9
2-6 dev_vscsit test classes	2-17
2-7 Class 1 subtests	2-17
2-8 Class 2 subtests	2-19
2-9 Receive diagnostic command data return format	2-23
2-10 Class 3 subtests	2-26
2-11 Subtest 304 data pattern	2-28
2-12 Subtest 306 record sizes	2-30
2-13 Tape drive data compression subtests	2-32
2-14 Class 4 subtests	2-33
2-15 Tape driver exception data compression subtests	2-34
2-16 Class 5 subtests	2-35
2-17 Status block contents	2-50
2-18 Status block flags byte	2-50
2-19 Host adapter status byte	2-52
2-20 Bit values for SCSI status byte code	2-52
2-21 Sense byte format	2-53
2-22 Sense key codes	2-54
2-23 Additional sense codes and descriptions	2-55
2-24 FRU codes for byte 14 nibbles	2-59

List of Figures

1-1 EGOS's position in the environment	1-3
1-2 Syntax help for the loop command	1-6
2-1 Initial test invocation sequence	2-7
2-2 Alternate test invocation sequence	2-8
2-3 Test parameter menu	2-9
2-4 Test parameter summary (CCU never loaded)	2-10
2-5 Test parameter summary (CCU previous loaded)	2-11
2-6 Test parameter menu (with all options)	2-13
2-7 Test parameter menu (with help fields)	2-14
2-8 Interactive debugger on-line help	2-37
2-9 Example script file, scr3	2-48
2-10 Example script file, scr3a	2-48
2-11 Example test script output	2-49

2-12	Host adapter missing or unpowered VMEbus error	2-64
2-13	Command not completed error example	2-64
2-14	Wrong driver file loaded error example	2-64

Preface

Purpose and intended audience

This manual explains how to run the *dev_vscsit* diagnostic, which checks the CONVEX VMEbus 3480-compatible tape system, CONVEX digital audio tape (DAT) drive system, and the VMEbus small computer system interface (SCSI) host adapter. It also checks the optional automatic cartridge loader (ACL) mechanism. This document is not a tutorial, but rather a reference for the users of the *dev_vscsit* diagnostics, including field service and manufacturing test personnel, as well as the diagnostics sustaining staff. In addition, CONVEX customers can use this manual to execute the *dev_vscsit* diagnostic.

This manual applies to all CONVEX computers.

This document is intended as a reference for users who have a good understanding of the host adapter and VIOP and for those who have a basic understanding of tape drives and magnetic tape recording principles. Specifically, this test description assumes familiarity with SCSI host adapter and tape drive subsystem functionality.


Organization

This document consists of the following:

- **Chapter 1, “Diagnostics environment”**—Introduces the theories and concepts that underlie I/O diagnostics on CONVEX machines. It also provides an overview of the operating system and *dshell* utility used by the diagnostic tests.
- **Chapter 2, “VMEbus DAT/3480 tape subsystem test (*dev_vscsit*)”**—Describes how to operate the diagnostic, including prerequisites, test invocation, hardware initialization sequence, and class descriptions. It also describes the interactive debugger commands, explains how to use a test script, and provides status and error information for the SCSI host adapter and tape system, plus examples of this information.

Notational conventions

The notational conventions used in this text are listed as follows:

- **Boldface** indicates user-entered information for a computer program that should be entered exactly as it appears.
- *Italic* is used to define new terms, for user-supplied variables, for emphasis, and to indicate titles of publications.
- `Constant-width` is used for code examples, command names and options, error messages, screen output, and system calls.
-  indicates a specific keyboard key to press. A hyphen between two keycap symbols indicates to press the two keys simultaneously. A space between two symbols indicates a sequence of keys to press.
- Bit numbering is left to right, N-1 through 0. The most significant numerical bit is N-1, the least significant 0. The bit numbering represents the binary weight of a position.
- Bit fields are specified using the following convention: *name*<*x..y*> where the bit field is *name* from bits *x* through *y*.
- Individual bit positions within a register are denoted by specific positions separated by commas. For example, REG<15,4,0> denotes bits 15, 4, and 0 of REG.
- Byte numbering is from left to right.
- A *bit* is a single binary value or entity.
- A *nibble* is 4 bits.
- A *byte* is 8 bits.
- A *halfword* is 16 bits.
- A *word* is 32 bits.
- A *longword* is 64 bits.
- An *instruction* is a multihalfword operand.
- A bit is *set* when it contains a binary value of 1.
- A bit is *clear* when it contains a binary value of 0.
- All memory and I/O addresses are written in hexadecimal notation unless explicitly stated otherwise.
- All register contents are written in hexadecimal notation unless explicitly stated otherwise.
- A *register* is a programmer-visible hardware storage element internal to the processor.
- *Physical memory* is the physical storage installed in the system.
- The symbol *K* is an abbreviation for *kilo* or 1,024.
- The symbol *M* is an abbreviation for *mega* or 1,048,576.
- The symbol *G* is an abbreviation for *giga* or 1,073,741,824.
- *Reserved* or *undefined* conveys what to expect, if anything, from unused fields in registers, reserved memory, or reserved I/O space. Algorithm implementation based on the use of undefined or reserved fields is not recommended.

All CONVEX illustrations have an illustration file number at the bottom right-hand corner that is for CONVEX use only.

Warnings

The following are examples of warnings, cautions, and notes and their typical content as used in CONVEX documents:

WARNING

Warnings highlight procedures or information necessary to avoid injury to personnel. A warning immediately precedes the critical information and includes a description of the hazard.

CAUTION

Cautions highlight procedures or information necessary to avoid damage to equipment, loss of data, or invalid test results. A caution immediately precedes the critical information and includes a description of the possible damage.

NOTE

Notes highlight useful information that is supplemental in nature. A note may immediately precede or follow the information that is being highlighted.

Associated documents

The following is a partial list of other manuals or books that can provide more detailed information on the topics presented in this manual:

- *CONVEX Processor Diagnostics Manual (C1, C120)*, Order No. DHW-071
- *CONVEX Processor Diagnostics Manual (C200 Series)*, Order No. DHW-081
- *CONVEX Processor Diagnostics Manual (C3400 Series)*, Order No. DHW-302
- *CONVEX SPU UNIX Utilities Manual*, Order No. DHW-021
- *CONVEX SPU System Manager's Guide*, Order No. DSW-022
- *CONVEX Diagnostic Utilities Manual (C1, C120)*, Order No. DHW-072
- *CONVEX Diagnostic Utilities Manual (C200 Series)*, Order No. DHW-082
- *Ciprico Rimfire 3510 SCSI Host Adapter and Floppy Disk Controller Reference Manual*, CONVEX Part No. 900-000425-001
- *Fujitsu Cartridge Tape Controller Customer Engineering Manual*, CONVEX Part No. 900-000444-001
- *Fujitsu Cartridge Tape Drives CE Manual*, CONVEX Part No. 900-000443-001
- *Archive Python DDS DAT Tape Drive Product Description Manual*, CONVEX Part No. 900-000601-001
- *Archive Python DDS-DC DAT Tape Drive Product Description Manual*, CONVEX Part No. 900-000626-001 (DIF/COMP)
- *Archive Python DDS-DC DAT Tape Drive Product Description Manual*, CONVEX Part No. 900-000627-001 (AutoLoader)
- *Archive Python DDS-DC DAT Tape Drive Product Description Manual*, CONVEX Part No. 900-000628-001 (SE/COMP)

Ordering documents

To order the most current edition of this or any other CONVEX document, send requests to:

CONVEX Computer Corporation
Customer Service
PO Box 833851
Richardson TX 75083-3851 USA

Include the order number with the request. The order number is on the title page of the manual and begins with the letters "DSW" or "DHW."

Technical assistance

Hardware, software, and documentation support can be obtained through the CONVEX Technical Assistance Center (TAC):

- From locations in the continental United States:
 - Customers call (800)952-0379
 - CONVEX employees call (800)545-4839
- From locations in Canada, call (800)345-2384.
- From all other locations, contact the nearest CONVEX office.

Using the contact utility

The TAC recommends using the `contact` utility to report a hardware, software, or documentation problem. The `contact` utility is an interactive program that helps the TAC track reports and route them to the CONVEX personnel most qualified to fix a problem. After you invoke `contact`, it prompts you for information about the problem. When you finish your report, `contact` mails it to the TAC electronically.

The TAC notifies you within 48 hours that your report has been received. To use `contact` requires:

- UNIX-to-UNIX Communications Protocol (UUCP) connection to the TAC.
- Full path name of the program or utility in question.
- Version number of the program or utility in question.

Refer to the `contact(1)` man page for complete details.

THIS PAGE INTENTIONALLY LEFT BLANK

Chapter 1

Diagnostics environment

1.1 Overview

CONVEX system diagnostics consist of a suite of test programs designed (except where noted) to execute under the service processor operating system, SPU OS. These programs utilize the capabilities of the service processor to test the operation of one or more of the functions of the system and report any errors detected. All diagnostics in this manual are intended to be executed *offline*; that is, while ConvexOS is not being executed by any of the central processing units (CPUs) in the system.

The service processor, together with SPU OS, various diagnostic utilities, and the test programs themselves, comprise the CONVEX diagnostic environment. This chapter provides an overview of the operating system and `dshell` utility used by the diagnostic tests. For more information about the diagnostic environment, refer to the *CONVEX Processor Diagnostics Manual (C200 Series)* or *CONVEX Processor Diagnostics Manual (C3400 Series)*, depending on the architecture of the machine under test.

1.2 Operating system

The event-governed operating system (EGOS) is a simple operating system that the device tests use to handle interrupts, schedule processes, and generally allocate and control input/output processor (IOP) and VMEbus input/output processor (VIOP) resources. The diagnostics code uses both EGOS and the message-based system (MBS) to manipulate test program control over to the CCU side of the test program. MBS is not a part of EGOS, but rather a system that allows a common section of memory to be used as a message area between multiple processors. For more information on MBS, refer to the *CONVEX Guide to Writing Device Drivers*.

EGOS initially sets up interrupt tables, determines hardware configuration, and initializes its windows and resource allocation tables.

There are four types of EGOS systems, one for each type of channel control unit (CCU). There is one each for the Multibus interface, the VMEbus interface, the high-speed parallel channel controller (HSP) interface, and the high-performance parallel interface (HIPPI). The following sections explain the four types of EGOS systems and how EGOS is positioned within the overall operating system environment.

1.2.1 EGOS for the Multibus interface

EGOS for the Multibus interface supports event-driven device drivers. The Multibus version of EGOS takes interrupts that are local to a CCU and channels those errors to the proper piece of code to handle the error. It supplies the error interrupt handlers for the CCU error interrupts. It also contains support routines to control allocation of the various CCU-related resources.

1.2.2 EGOS for VMEbus interface (VIOP EGOS)

The VMEbus interface version of EGOS is designed with a scheduler for the VIOP and is called VIOP EGOS. VIOP EGOS supports event-driven device drivers as well as process-type device drivers. VIOP EGOS utilizes a *sleep/wakeup* type of process control that improves efficiency of the device driver and makes it less complicated to create user-written device drivers. Each process device driver has a priority level that can be defined relative to other processes. The scheduler supports 32 process priorities and is preemptive for higher priority processes. The VIOP hardware supports 14 device events for event-driven device drivers. The 14 levels actually share two 68020 interrupt levels. Therefore, two is the maximum number of processes at any given time.

1.2.3 EGOS for HSP interface (HSP EGOS)

EGOS for the HSP interface supports event-driven device drivers. The HSP version of EGOS is like the Multibus version. It takes interrupts that are local to a CCU and channels those errors to the proper piece of code to handle the error. It supplies the error interrupt handlers for the CCU error interrupts. It also contains support routines to control allocation of the various CCU-related resources.

1.2.4 EGOS for HIPPI (HIPPI EGOS)

EGOS for the HIPPI interface supports event-driven device drivers as well as process-type device drivers. HIPPI EGOS uses a *sleep/wakeup* type of process control that improves efficiency of the device driver and makes it less complicated to create user-written device drivers. Each process device driver has a priority level that can be defined relative to other processes. The scheduler supports up to 256 process priorities and is preemptive for higher priority processes.

HIPPI EGOS helps device drivers handle hardware interrupts by providing interrupt prolog and epilog code. This code deals with all Motorola 88100 microprocessor requirements for interrupts and exceptions. This functionality allows interrupt procedures to be written in a high-level language and to easily use EGOS functions.


1.2.5 EGOS's position in the environment

EGOS is positioned in the operating environment between the actual device driver and MBS. MBS is a transparent layer that bridges the CCU and its resources to SPU OS. SPU OS handles many of the message manipulations that occur during testing. Many error messages that occur during diagnostics testing come from the device driver. When the device driver detects an error from the controller, it calls a routine in EGOS that places a message in the MBS system. This causes SPU OS to be interrupted, and it retrieves the message from MBS. SPU OS then passes a

signal to the test program. The test program then prints an error message to the console based on the code that it received.

Figure 1-1 illustrates the position of EGOS in the operating system environment.

Figure 1-1, EGOS's position in the environment



AH008003
6/3/82

1.3 dshell utility overview

The diagnostic shell (**dshell**) is a command interface program that runs on the service processor. Most of the diagnostics available for the CONVEX machines are interfaced through the **dshell**. Certain peripheral diagnostics are run as standalone tests. This section provides a brief overview of the **dshell** utility, including a brief explanation of the utility and a list of the utility's commands. For a complete description of the **dshell** utility, refer to Chapter 2, "Diagnostic Shell (Dshell)," in the *CONVEX Diagnostic Utilities Manual (C200 Series)*.

1.3.1 Diagnostic shell (dshell) overview

The **dshell** has two functions:

- Selecting diagnostics for execution
- Selecting test options as listed:
 - Pause on a failure or at the beginning or end of any specific subtest
 - Loop on a specific type of subtest or on a given set of subtests
 - Select subtest execution order
 - Direct test output to a file or to the screen (or both) to monitor the test
 - Select long or short error messages, or turn messages off
 - Execute either user-created or predefined command scripts

1.3.2 dshell commands

Table 1-1 summarizes the various **dshell** commands and their functions.

Table 1-1, dshell commands

Command	Function
! <i>[command]</i>	Accesses or forks a SPU OS shell to execute the command that follows !.
exit or quit	Immediately terminates the dshell process and any test processes that may have been forked.
CTRL-C	Returns user to the dshell command level if no subtest is running. If subtest is running, provides options to continue or abort subtest.
CTRL-B	Immediately terminates the dshell and any associated active processes. Core is dumped.
help	Displays a standard help menu. The menu describes the correct command syntax for each dshell command and gives a terse description of what each command does.
status	Generates a report on the current state of the dshell command options. This report gives the name of each option, its current value, and an explanation of its current effect.
log <i>[options]</i>	Provides a mechanism for specifying the number of failures allowed to occur before a test or subtest terminates execution.
loop <i>[options]</i>	Causes dshell to repeat the execution of a test or subtest.
msgs <i>[options]</i>	Enables or disables different levels of test, class, and subtest result messages.
pause <i>[options] [nn]</i>	Returns program control to the dshell at the beginning, end, or failure of all or specific subtests.
test <i>[testname] [options]</i>	Executes specific tests and displays test, class, and subtest menus.

1.3.3 Syntax help for dshell commands

The syntax for each dshell command can be obtained by typing the command without options and pressing **RETURN**. For example, by typing **loop** and pressing **RETURN**, the syntax help in Figure 1-2 will be displayed on the screen.

Figure 1-2, Syntax help for the loop command

```
: loop
Proper syntax is:

loop off (-s) (-t)           :disables loop modes
loop -s nnn                  :loop on subtest nnn
loop -t                      :loop on test
```

Chapter 2

VMEbus DAT/3480 tape subsystem test (dev_vscsit)

2.1 Overview

The `dev_vscsit` test is a functional test for the CONVEX VMEbus 3480-compatible tape system, the CONVEX digital audio tape (DAT) drive system, and the VMEbus small computer system interface (SCSI) host adapter. The test is subdivided into separate classes that verify the functional integrity of the host adapter, the 3480-compatible tape controller and tape drive, the DAT drive; and tape motion and data transfer functions of the tape drive subsystems. In addition, `dev_vscsit` verifies the:

- Functional ability of the SCSI host adapter to operate in the CONVEX VMEbus I/O environment, including main memory access and interrupt generation and detection.
- Ability of the host adapter to detect anomalous conditions on the SCSI bus.
- Operational integrity of the cable interface between the host adapter and the tape subsystems.
- Ability of the tape subsystem and the automatic cartridge loader (ACL) to communicate and function properly. The ACL subtests, however, are not supported on C100 Series computers.

NOTE

The `dev_vscsit` diagnostic uses the ConvexOS VMEbus input/output processor (VIOP) driver that normally resides in `/mnt/os` on the SPU disk drive. This VIOP driver file contains the tape subsystem driver used by the `dev_vscsit` diagnostic. If a VIOP driver exists in the same directory as the `dev_vscsit` diagnostic, the diagnostic will use this driver and not the driver in `/mnt/os/viop`.

Channel control unit (CCU) communications use the event governed operating system (EGOS) and the message-based system (MBS) used by ConvexOS. The intent is to test the communication paths that are used in a normal operating environment. Table 2-1 lists most of the SCSI interface commands, their op codes, and command names.

Table 2-1, SCSI interface commands

Number	Group code	OP code	Command name
1	0	0x00	Test unit ready
2	0	0x01	Rewind
3	0	0x03	Request sense
4	0	0x08	Read
5	0	0x0a	Write
6	0	0x10	Write filemarks
7	0	0x11	Space
8	0	0x12	Inquiry
9	0	0x15	Mode select
10	0	0x19	Erase
11	0	0x1a	Mode sense
12	0	0x1b	Unload
13	0	0x1c	Receive diagnostic results
14	0	0x1d	Send diagnostic
15	6	0xcf	Load display
16	6	0xcb	Select cartridge
17	6	0xcc	Eject
18	6	0xcd	Load magazine
19	6	0xce	Autoloader mode select

2.2 Prerequisites

The following sections list the required hardware, software, and instructions on setting unit numbers and logical addresses.

2.2.1 Hardware requirements

Table 2-2 lists the required hardware depending on the type of machine under test.

Table 2-2, Hardware requirements

C1/C120	C210/220	C240	C3400 Series	C3800 Series
MCU MAU SPU VIOP VBCU	Memory system ¹ CPX SP2, SP4, SP5 VIOP PIA or PI2	Memory system ¹ CPX SP4 VIOP PI2	Memory system ¹ CUO and CUE SP5 VIOP PI2	Memory system ¹ CUJ SWIP and SWIS VIOP NIA
3480 drive ² or DAT drive ³	3480 drive ² or DAT drive ³	3480 drive ² or DAT drive ³	3480 drive ² or DAT drive ³	3480 drive ² or DAT drive ³

¹ Memory system consists of a minimum of one pair of memory boards (1 odd and 1 even).

² 3480-compatible tape subsystem

³ DAT drive subsystem

NOTE

A maximum of 16 CONVEX 3480-compatible tape drives or 16 DAT drives can be connected to a single VIOP.

2.2.2 Software requirements

The current revision of the `dev_vscsit` diagnostic is dependent on the following software revision levels:

- SPU OS V5.2 or later
- The appropriate diagnostics product:
 - For C100 Series systems, System Diagnostics V6.6 or later
 - For C200/C3200/C3400 Series systems, I/O Diagnostics V1.1 or later
 - For C3800 Series systems, System Diagnostics V1.2 or later
- ConvexOS requirements:
 - **ConvexOS V8.1**—Required to operate CONVEX 3480-compatible cartridge tape system and CONVEX DAT drive system.
System generation of the software drivers required when a cartridge tape subsystem or DAT drive system is installed.
 - **ConvexOS V9.0**—System generation of the software drivers required when a DAT drive system is installed.
 - **ConvexOS V9.1**—System generation of the software drivers not needed when a cartridge tape subsystem or DAT drive system is installed.
Required to operate a CONVEX 3480-compatible cartridge tape system with automatic cartridge loader (ACL). Requires a system generation of the software drivers when an ACL is installed.
 - **ConvexOS V10.0**—System generation of the software drivers not needed when a cartridge tape subsystem or DAT drive system is installed.
Cannot be used with 3480-compatible ACL.
 - **ConvexOS V10.1 or later**—System generation of the software drivers not needed when a cartridge tape subsystem or DAT drive system is installed.
Required to operate a CONVEX 3480-compatible cartridge tape subsystem with EDRC data compression. No system generation of drivers is required.
Required to operate a CONVEX DAT drive system with data compression and/or ACL. No system generation of drivers is required.

Table 2-3 summarizes the ConvexOS requirements.

Table 2-3, ConvexOS requirements summary

System	8.1	9.0	9.1	10.0	10.1 & later
3480	sysgen	yes	yes	yes	yes
3480 + ACL	no	no	sysgen	no	yes
3480 + compression	no	no	no	no	yes
DAT	sysgen	sysgen	yes	yes	yes
DAT + ACL	no	no	no	no	yes
DAT + compression	no	no	no	no	yes

2.2.3 Setting the 3480-compatible formatter unit number

Refer to the *CONVEX 3480-Compatible Tape Drive Service Guide* for information on setting the formatter's unit number.

2.2.4 Setting the 3480-compatible tape unit logical address

The following procedure changes the logical address of the tape unit from address 0 to address 1:

	Front panel operation	Tape drive display
1.	Press RESET	NT RDYU
2.	Press UNLOAD	*0
3.	Remove the tape cartridge	
4.	Press and hold down both UNLOAD and TEST	DIAGMODE
5.	Press START	SETTING
6.	Press TEST	70: S.L-A
7.	Press TEST	L-ADR:0
8.	Press START	L-ADR:1
9.	Press TEST	70:END
10.	Press START multiple times until the display shows	89:WTROM 89:WTROM
11.	Press TEST	WTROM:Y
12.	Press TEST	89:END
13.	Press RESET (twice)	SELFTEST

After the tape unit number is set, the display on the tape unit will show *1.

Refer to the *Fujitsu Cartridge Tape Drives CE Manual*, Chapter 5, "Setting Method," for more information.

2.2.5 Setting the DAT drive unit number

Check and, if necessary, change the dip switch settings on the DAT tape drive to set the drive's logical unit number. Table 2-4 lists the dip switch settings.

Table 2-4, DAT drive dip switch settings

SCSI device address	S1	S2	S3	S4	S5	S6	S7	S8
	SCSI ID	SCSI ID	SCSI ID	SCSI 1 or SCSI-2 ¹	Parity enable ²	Compression ³	Reserved	Self-test enable ⁴
0	OFF	OFF	OFF	ON	ON	OFF or ON	OFF	ON
1	ON	OFF	OFF	ON	ON	OFF or ON	OFF	ON
2	OFF	ON	OFF	ON	ON	OFF or ON	OFF	ON
3	ON	ON	OFF	ON	ON	OFF or ON	OFF	ON
4	OFF	OFF	ON	ON	ON	OFF or ON	OFF	ON
5	ON	OFF	ON	ON	ON	OFF or ON	OFF	ON
6	OFF	ON	ON	ON	ON	OFF or ON	OFF	ON

¹ OFF = SCSI-1; ON - SCSI-2

² OFF = Parity disabled; ON = parity enabled

³ Compression is enabled via software. Set switch ON for the AutoLoader or the manual-load drive with compression. Set the switch OFF for the manual-load drive without compression.

⁴ OFF = Self-test disabled; ON = self-test enabled

2.3 Test invocation

The following sections discuss procedures for starting `dev_vscsit`.

2.3.1 Loading test tape cartridges

All test classes except Class 1 require a scratch tape to be loaded in the drive before the tests can be executed successfully. In the case of drives with no automatic cartridge loader (ACL) or AutoLoader, the scratch tape should be manually inserted. If the drive has an ACL, a magazine containing at least two scratch tapes should be loaded. The procedure for loading the magazine is different for the 3480-compatible cartridge drive and the DAT drive.

For the 3480-compatible cartridge drive with ACL, place the ACL in AUTO mode (if necessary) using the MODE SEL. switch on the front panel of the ACL. Then, set the magazine containing the scratch tapes in place in the ACL. Next, press the START button to initiate the cartridge loading sequence. Once the first cartridge has been loaded into the drive, `dev_vscsit` can be started.

For the DAT drive with an AutoLoader, place the magazine containing the scratch tapes into the magazine holder, which will initiate the magazine loading sequence. Once the magazine has stopped moving, press the button on the front of the ACL to load the first cartridge. The orange LED on the ACL will light while the DAT updates system records on the tape cartridge. When the light has gone off, `dev_vscsit` can be started.

CAUTION

Any data existing on the scratch tapes will be lost during the execution of these tests.

2.3.2 Starting dev_vscsit

The `dev_vscsit` test executes under the diagnostic shell (`dshell`) and supports all the features of the `dshell`. The `dshell` permits tests to be initiated in any order. To invoke the `dev_vscsit` test, use the procedure shown in Figure 2-1. User input is indicated in **boldface**. The prompts and responses appear sequentially on the screen, one line at a time. Figure 2-1 shows all the prompts and responses.

NOTE

Use the following test invocation sequence for the initial invocation of `dev_vscsit` or when the state of the machine is unknown. Also, the following invocation sequence should be used if any hard errors have occurred since the last system initialization.

Figure 2-1, Initial test invocation sequence

```
(spu)> cd /mnt/test
(spuc> sysreset
(spuc> mminlt -s
(spuc> dshell
: test dev_vscsit [-c [class number(s)]] [-s [subtest number(s)]] [-dV] [-f file] [+>filename] RETURN
```

NOTE

After entering `dshell`, specific `dshell` parameters may be changed. Refer to Chapter 1, Section 1.3, "`dshell` utility overview," for more information.

Entering only `test dev_vscsit` executes all `dev_vscsit` subtests sequentially. Execute a specific class(es) of subtest(s) or one or more individual subtests by using the `-c` or `-s` options, respectively. Refer to Chapter 1, Section 1.3, "`dshell` utility overview," for more detailed information on these options.

The following list defines the remaining options:

- d Enters debugger (no subtests are executed).
- V Prints version string (compilation date of test-last modification date).
- v Sets verbose mode; causes the status lines printed during each subtest to generate a new line with each message.
- m Sets message tracing mode; causes each message to and from the CCU to be displayed in hexadecimal. This option can generate a lot of screen output.
- n Causes CCU message timeouts to be ignored. This option is useful for debugging with CCU breakpoints.
- f *file* Uses *file* as the parameter save file. If this option is omitted, /tmp/dev_vscsit.tmp is used as the parameter file.

The [+> *filename*] option appends the test results to *filename*.

NOTE

The following alternate test invocation procedure is optimal when invoking `dev_vscsit` multiple times. Using this invocation sequence ensures that the test is invoked and executed with all set-up parameters supplied when the test was last executed with the initial invocation sequence.

The only difference in this alternate invocation sequence is the **x** after `dev_vscsit`. When invoking `dev_vscsit` in this manner, no prompts are displayed. The diagnostic obtains all prompt information from the parameter file (default parameter file is /tmp/dev_vscsit.tmp) created when the initial invocation sequence was performed. Also note that `mminit -s` is only required if the state of the machine is unknown or if hard errors have occurred since the last system initialization. Figure 2-2 shows the alternate test invocation sequence.

Figure 2-2, Alternate test invocation sequence

```
(spu)> cd /mnt/test
(spu)> mmlnt -s
(spu)> dshell
:test dev_vscsitx [-c [class number(s)]] [-s [subtest number(s)]] [-dV] [-f FILE] [+> filename] (RETURN)
```

2.3.3 Test Parameter Menu

Once the test is invoked, a test menu prompt is presented allowing selection of default switches. Figure 2-3 shows the TEST PARAMETER MENU with all prompts, their possible answers in brackets [], and their default answers in parentheses ().

Figure 2-3, Test parameter menu

```

ENTER TEST PARAMETERS

[] Encloses allowed input ranges or values
() Encloses the default value
^ Returns to the previous prompt
:nn Returns to the prompt # nn
: Returns to the first unsatisfied prompt
:? Reviews previous entries
? Provides additional help for each question

1: Select ioconfig file [<filepath>,?] (/ioconfig) -> RETURN

                PERIPHERAL CONFIGURATION DATA
                CCU   Chassis  Type   CSR   Int Unit   Type
                -----
1) viop 3      1    MTC-202 0xee00 3    0.0 MTD-207
2) viop 3      1    MTC-202 0xee00 3    0.1 MTD-207
3) viop 3      1    MTC-202 0xea00 4    0.0 MTD-208
4) viop 3      1    MTC-202 0xea00 4    1.0 MTD-208

*** Enter 0 for manual configuration ***

2: Ioconfig File Unit(s) to Test [1-4,0,?] (1) -> RETURN
3: Use Defaults for Remaining Parameters [y,n,?] (y) -> RETURN
4: Enter OK, or :NN to return to question NN [OK] (OK) -> RETURN

```

The prompts and responses in the figure appear sequentially on the screen, one line at a time. The figure illustrates *most* questions that can be displayed during test parameter input. However, some questions may be omitted, depending on answers to previous questions. In all cases, questions are numbered sequentially. The numbers displayed on the screen during testing may not correspond to those shown in the example, as the questions illustrated are examples only.

For help or information during test parameter entry, enter one of the help characters followed by a RETURN. Table 2-5 lists the help characters:

Table 2-5, Getting help during test parameter entry

Character	Description
:?	Reviews previous entries
?	Provides specific help where available

After displaying the desired help information, the system redisplay the last prompt.

If **OK** or **RETURN** is entered, the test parameter menu terminates and all inputs are no longer changeable.

After all the prompts have been answered, the screen displays a **TEST PARAMETER SUMMARY** that displays prompts that were answered and their responses. Figure 2-4 shows a sample **Test Parameter Summary** after a system reset and **mminit** have been performed. In this case, the CCU drivers (**/mnt/os/viop**) will be loaded, probed, and attached.

NOTE

Refer to Figure 2-1 for the test invocation sequence to produce this **TEST PARAMETER SUMMARY**.

Figure 2-4, Test parameter summary (CCU never loaded)

```
TEST PARAMETER SUMMARY

Select ioconfig file                               : /loconfig
Ioconfig File Unit(s) to Test                     : 1

      PERIPHERAL CONFIGURATION DATA
      CCU   Chassis  Type   CSR   Int Unit  Type
      -----
viop 3     1     MTC-202  0xee00  3   0.0 MTD-207

Use Defaults for Remaining Parameters             : y
Enter OK, or :NN to return to question NN       : OK

Saving options in parameter file "/tmp/dev_vscsit.tmp" ... Done
Initializing MBS processor queues ... Done
Loading CCU(s) ... Done
CCU 3/MTC-202 configure/probe completed
Tape unit 0.0 attach and connect completed
Main memory data buffer address starts at 0x00202000
```

If **dev_vscsit** has been executed previously and **sysreset** and **mminit** have not been executed since, the CCU drivers are still loaded and a different **TEST PARAMETER SUMMARY** will be displayed. Figure 2-5 shows a sample **TEST PARAMETER SUMMARY** with the CCU drivers already loaded.

NOTE

Refer to Figure 2-2 for the test invocation sequence to produce this **TEST PARAMETER SUMMARY**.

Figure 2-5, Test parameter summary (CCU previous loaded)

```
TEST PARAMETER SUMMARY

Select ioconfig file                               : /loconfig
Ioconfig File Unit(s) to Test                     : 1

      PERIPHERAL CONFIGURATION DATA
      CCU   Chassis  Type   CSR   Int Unit  Type
      -----
viop 3     1     MTC-202 0xee00 3     0.0 MTD-207

Use Defaults for Remaining Parameters             : y
Enter OK, or :NN to return to question NN        : OK

Saving options in parameter file ''/tmp/dev_vscsit.tmp'' ... Done
Initializing MBS processor queues ... Done
*** CCU driver already loaded on VIOP 3
*** Tape unit 0.0 already attached and connected
Main memory data buffer address starts at 0x00202000
```

2.4 Initialization sequence for dev_vscsit

After the last prompt is entered and before substest code execution, the following events occur:

- The diagnostics locates the largest contiguous main memory space after the first 2 Mbytes and reserves it for use by the diagnostic.
- The diagnostic checks to see if the CCU is already loaded with the `dev_vscsit` CCU driver. If the driver is not loaded, the CCU is reloaded. After the load completes, the driver is configured for EGOS and the EGOS probe message starts the driver.
- The diagnostic passes the current test parameters to the CCU driver.

NOTE

The file `/mnt/boot_db` is used to determine what memory is installed. If this file is nonexistent, it can be created by entering: `scn_util -b > /mnt/boot_db` from the `(spu)>` prompt.

After all the above events have occurred, the test code is started.

2.4.1 Prompt explanations

The test parameter prompts are repeated and explained in the following paragraphs.

1: Select ioconfig file [<filepath>.]?] (/ioconfig) ->

This option allows you to specify an alternate /ioconfig file. The file must still be in the same format as a conventional /ioconfig file.

PERIPHERAL CONFIGURATION DATA							
CCU	Chassis	Type	CSR	Int	Unit	Type	
1)	viop	3	1	MTC-202	Oxee00	3	0.0 MTD-207
2)	viop	3	1	MTC-202	Oxee00	3	0.1 MTD-207
3)	viop	3	1	MTC-202	Oxea00	4	0.0 MTD-208
4)	viop	3	1	MTC-202	Oxea00	4	1.0 MTD-208

The digit to the left of the period under the Unit heading is the SCSI target identification number and has a value range from 0 to 6. SCSI identification number 7 is reserved for the host adapter. The digit to the right is the tape unit logical address number and has a value range from 0 to 3 for 3480-compatible tape drives (DAT drives allow 0 only).

*** Enter 0 for manual configuration ***

2: Ioconfig File Unit(s) to Test [1-4,0,?] (1) ->

The applicable /ioconfig file entries are listed (if any). To select a predefined controller configuration entry from the /ioconfig file, enter the number to the left of the desired entry. Entering a 0 allows each item within the controller configuration entry to be independently specified. If you want to use most of the items associated with a given entry in the /ioconfig file, select the number for that entry, back up to this prompt (via the CTRL command), and then enter 0 the second time. The default values for the independent items will then be the same as the originally selected entry.

3: Use Defaults for Remaining Parameters [y,n,?] (y) ->

This option lets you use the default values for the remaining questions.

4: Enter OK, or :NN to return to question NN [OK] (OK) ->

This option lets you return to a specified question number and change the answer.

Figure 2-6 shows all the options for the TEST PARAMETER SUMMARY.

Figure 2-6, Test parameter menu (with all options)

```

ENTER TEST PARAMETERS

[] Encloses allowed input ranges or values
() Encloses the default value
^ Returns to the previous prompt
:nn Returns to the prompt # nn
: Returns to the first unsatisfied prompt
:? Reviews previous entries
? Provides additional help for each question

1: Select ioconfig file [<filepath>?] (/ioconfig) -> RETURN

PERIPHERAL CONFIGURATION DATA
CCU Chassis Type CSR Int Unit Type
-----
1) viop 3 1 MTC-202 0xee00 3 0.0 MTD-207
2) viop 3 1 MTC-202 0xee00 3 0.1 MTD-207
3) viop 3 1 MTC-202 0xea00 4 0.0 MTD-208
4) viop 3 1 MTC-202 0xea00 4 1.0 MTD-208

*** Enter 0 for manual configuration ***

2: Ioconfig File Unit(s) to Test [1-4,0,?] (1) -> RETURN
3: Use Defaults for Remaining Parameters [y,n,?] (y) -> n
4: Enable Debug Monitor [y,n,?] (n) -> y
5: Run Tape Tests to EOT [y,n,?] (n) -> RETURN
6: Variable record substest pattern [<hexadecimal pattern>?]
(Ox6db6) -> RETURN
7: Variable record miscompare Line Dump Count [1-100, ?] (8) -> RETURN
8: Maximum Cartridges Used in Autoloader Tests [1,10,?] (2) -> RETURN

** Printer On/Off Enable/Disable Options (bit mapped) **
0x0001: Enable printer ON string before error
0x0002: Enable printer OFF string after error

9: Select Printer On/Off Mode [0x0-0x3,?] (0x0) -> 3
10: Printer On Character Sequence (before error)
[<printer on string>?] (\033[?51) -> RETURN
11: Printer Off Character Sequence (after error)
[<printer off string>?] (\033[?41) -> RETURN
12: Enter OK, or :NN to return to question NN [OK] (OK) -> RETURN

```

Figure 2-7 shows the TEST PARAMETER SUMMARY menu with online help for each option.

Figure 2-7, Test parameter menu (with help fields)

```

ENTER TEST PARAMETERS

[]      Encloses allowed input ranges or values
()      Encloses the default value
^       Returns to the previous prompt
:nn     Returns to the prompt # nn
:       Returns to the first unsatisfied prompt
:?      Reviews previous entries
?       Provides additional help for each question

1: Select ioconfig file [filepath,?]          (/ioconfig) -> ?
      HELP FOLLOWS
-----
Specify an alternate "/ioconfig" file. The file must still be in
the same format as a conventional "/ioconfig" file
-----
      END OF HELP -----

                PERIPHERAL CONFIGURATION DATA
                CCU      Chassis  Type      CSR      Int Unit  Type
                -----
1) viop  3      1      MTC-202  0xee00   3      0.0 MTD-207
2) viop  3      1      MTC-202  0xee00   3      0.1 MTD-207
3) viop  3      1      MTC-202  0xea00   4      0.0 MTD-208
4) viop  3      1      MTC-202  0xea00   4      1.0 MTD-208

*** Enter 0 for manual configuration ***

2: Ioconfig File Units to Test [1-4,0,?]      (1) -> ?
      HELP FOLLOWS
-----
Above, the applicable "/ioconfig" file entries are listed (if any).
To select a predefined controller configuration entry from the
"/ioconfig" file, enter the number which is found to the left of
the desired entry. Entering a 0 allows each item within the
controller configuration entry to be independently specified. If
you desire to use most (but not all) of the items associated with a
given entry in "/ioconfig" file, select the number for that entry,
backup to this prompt (via the ^ command), and then specify 0 the
second time. This will cause the default values for the
independent items to be the same as the originally selected entry.
-----
      END OF HELP -----

3: Use Defaults for Remaining Parameters [y,n,?] (y) -> ?
      HELP FOLLOWS
-----
A "Yes" answer here will result in the selection of the default
value for all remaining prompts. This allows the user to avoid
having to explicitly enter a <C/R> in response to every remaining
prompt.
-----
      END OF HELP -----

4: Enable Debug Monitor [y,n,?]                (n) -> ?
      HELP FOLLOWS
-----
This option allows the user to automatically enter the interactive
debugger any time an error is detected within a subtest. The
debugger may also be invoked by specifying the "-d" option at test
invocation time (i.e., dev_vscsit[x].t -d).
-----
      END OF HELP -----

```

Figure 2-7, Test parameter menu (with help fields)
(continued)

```
5: Run Tape Tests to EOT [y,n,?] (n) -> ?
      HELP FOLLOWS
-----
If this flag is asserted, tests that attempt to write to
end-of-tape (EOT) will be executed. For DAT devices, this could
take as long as 2 hours.
-----
      END OF HELP -----
6: Variable record substest pattern [<hexadecimal pattern>,?]
      (0x6db6) -> ?
      HELP FOLLOWS
-----
Enter the hexadecimal data pattern to use for variable-record
read/write substests. The pattern may be any length from 1 nibble
to 256 bytes. The pattern will be replicated over and over as
necessary when formatting buffers for tape writes.

Optional pattern files:
The pattern can be specified via a file on the SPU disk. For this
method enter a "+" followed by the optional filename of the pattern
file. If the filename is omitted, the test will default to the
file "dev_vscsit.pat". The pattern can contain whitespace and can
be spread across multiple lines if desired.

*** NOTE:
The buffer fill pattern before reads is "0x55aa55aa". Therefore,
this pattern should be avoided as the write/read data pattern.
-----
      END OF HELP -----
7: Variable record miscompare Line Dump Count [1-100, ?](8) -> ?
      HELP FOLLOWS
-----
Enter the MAXIMUM number of display lines to print when a data
miscompare occurs.
-----
      END OF HELP -----
8: Maximum Cartridges Used in Autoloader Tests [1,10,?] (2) -> ?
      HELP FOLLOWS
-----
This is the number of tapes that will be used to run the autoloader
tests. The default is 2 to shorten test times.
-----
      END OF HELP -----
** Printer On/Off Enable/Disable Options (bit mapped) **
0x0001: Enable printer ON string before error
0x0002 Enable printer OFF string after error

9: Select Printer On/Off Mode [0x0-0x3,?] (0x0) -> ?
      HELP FOLLOWS
-----
This option allows the ability to send a user specified character
string to the display before and/or after an error message has been
displayed. Although any string up to 64 characters may be used,
its intended use is to turn a printer on before an error is
displayed and turn it off after the error has been displayed.
This is a paper-saving feature when running the test over and over
for several hours. Only errors will be printed when both the on
and off strings are defined. This assumes a printer is connected
to the auxiliary port on the display terminal where the test is
running and that the auxiliary port can be turned on and off via an
escape character sequence.
-----
      END OF HELP -----
```

Figure 2-7, Test parameter menu (with help fields)
(continued)

10: Printer On Character Sequence (before error)
[<printer on string>,<?>] (\033[?51) -> ?

HELP FOLLOWS

Enter the character string to be displayed before an error message is printed. The default value is the "Enter Auto Print Mode" sequence for terminals that support vt100 terminal protocol. This will turn on the echo of all displayed data to the terminal's auxiliary port.

Control characters may be specified by using standard C programming style escape sequences. For example:

\033	-	Octal value of the ASCII escape character (0x1b)
\x1b	-	Same as above but specified in hex.
\r	-	Carriage Return
\n	-	Line Feed
\t	-	Tab Character
\b	-	Backspace character
\f	-	Form Feed character

----- END OF HELP -----

11: Printer Off Character Sequence (after error)
[<printer off string>,<?>] (\033[?41) -> ?

HELP FOLLOWS

Enter the character string to be displayed after an error message has been printed. The default value is the "Exit Auto Print Mode" sequence for terminals that support vt100 terminal protocol. This will turn off the echo of all displayed data to the terminal's auxiliary port.

Control characters may be specified by using standard C programming style escape sequences. For example:

\033	-	Octal value of the ASCII escape character (0x1b)
\x1b	-	Same as above but specified in hex.
\r	-	Carriage Return
\n	-	Line Feed
\t	-	Tab Character
\b	-	Backspace character
\f	-	Form Feed character

----- END OF HELP -----

12: Enter OK, or :NN to return to question NN [OK] (OK) -> RETURN

2.5 Class descriptions

Table 2-6 lists the four classes of subtests contained in `dev_vscsit`.

Table 2-6, `dev_vscsit` test classes

Class	Description
1	SCSI host adapter tests
2	Tape controller and logical unit self-tests
3	Tape motion and read/write tests
4	Tape drive exception tests
5	Stacker mechanism tests

NOTE

When a subtest is executing, the elapsed time counter is not updated until the subtest has been completed.

2.6 Class 1 subtests, SCSI host adapter tests

Class 1 subtests only test the VMEbus SCSI host adapter. A target device does *not* need to be connected to the host adapter to run any of the class 1 subtests. Class 1 subtests verify the following functionalities:

- The ability to communicate with the VIOP and the VMEbus Control Unit (VBCU)
- The ability of the host adapter to interrupt and to mask interrupts
- Accessibility to main memory

Table 2-7 lists all Class 1 subtests, their descriptions, and the approximate times required to execute each subtest.

Table 2-7, Class 1 subtests

Subtest	Description	Time (min:sec) ¹
100	Host adapter identify test	00:01
101	Host adapter RAM test	00:10
102	Host adapter PROM test	00:30

¹ The times presented are approximated and are the same for 3480-compatible subsystem and DAT subsystem.

2.6.1 Subtest 100, host adapter identify test

Subtest 100 issues an IDENTIFY command to the host adapter from a diagnostic parameter block that contains only a Target ID field (0xff) and a command field (0x05). The IDENTIFY command returns a specially-formatted status block that identifies the firmware version, engineering revision level, and the day, month, and year when the firmware in the programmable read only memory (PROM) was generated. The test formats the information returned from the host adapter and then displays it on the terminal. The following is an example of the formatted output from the host adapter identify test:

```
Subtest 100      0:00:00
Firmware rev = 07, Engr rev = 57, Prom generation date (mm/dd/yy) 04/02/90
0:00:00      passed
```

2.6.2 Subtest 101, host adapter RAM test

Subtest 101 issues a BOARD TEST command to the host adapter from a diagnostic parameter block that contains the target ID field (0xff), the command field (0x09), and the test flag field with the static RAM test (SRT) bit set. When the BOARD TEST command is completed, the results of the diagnostic are returned in a status block. This test is repeated 500 times. If the error byte in the status block equals 0x61, the memory test has failed. The following is an example of a failed host adapter RAM test:

```
Failed: VME host adapter ram test
Error: (flag byte) Command completed with error status.
Error: (error byte) Static ram error.
      : Error addr xxxx expected yy found zz
```

NOTE

To avoid writing test patterns over data, the BOARD TEST command will not execute until all preceding commands have finished. While this command is running, the adapter will not accept other commands. At the end of the command, any pending channel attentions will be serviced and execution will resume.

2.6.3 Subtest 102, host adapter PROM test

Subtest 102 issues a BOARD TEST command to the host adapter from a diagnostic parameter block that contains the target ID field (0xff), the command (0x09), and the test flag field with the PROM checksum test (PCS) bit set. When the BOARD TEST command is completed, the results of the diagnostic are returned in a status block. This test is repeated 50 times. The PCS has failed when the error byte in the status block equals 0x62. The following is an example of a failed host adapter PROM test:

Failed: VME host adapter prom test
 Error: (flag byte) Command completed with error status.
 Error: (error byte) Prom Checksum error.

2.7 Class 2 subtests, tape controller and logical unit self-test

Class 2 subtests invoke the self-test capabilities of the 3480-compatible tape controller (formatter) and cartridge tape drive and the DAT drive. In this test class, self-test diagnostic commands are sent to the controller (formatter) and tape drives. The receive diagnostic results are then invoked. A tape controller (formatter), a 3480-compatible cartridge tape drive, and a 3480 scratch tape (or a DAT drive and a DAT scratch tape) are required for this class of tests.

CAUTION

During Class 2 subtests, do *not* load, unload, or reset the selected tape drive. Doing so will invalidate the test results.

Any data existing on the scratch tape will be lost during the execution of these subtests.

NOTE

If subtest 201 is to be run, a tape cartridge needs to be loaded prior to starting Class 2 subtests.

Table 2-8 lists all Class 2 subtests, their descriptions, and the approximate times required to execute each subtest.

Table 2-8, Class 2 subtests

Subtest	Description	3480 Time (min:sec) ¹	DAT Time (min:sec) ¹
200	Tape controller self-test	00:56 ²	00:30
201	Tape logical unit self-test	15:00	NA ³

¹ The times presented are approximated.

² This test can run 00:56, 01:49, or 03:36 depending on the number of tape drives connected to the controller.

³ This test does not run on the DAT drive subsystem.

2.7.1 Subtest 200, tape controller self-test

Subtest 200 issues a **SEND DIAGNOSTIC** command to request the tape controller (formatter) or DAT drive to perform diagnostic tests on itself. The SCSI command block containing the **SEND DIAGNOSTIC** command is sent to the host adapter using a standard parameter block. The SCSI command block is a group 0 type, and the op code is 0x1d. The self-test (SLFTST), device offline (DEVOFL), and unit offline (UNITOFL) bits are set to 1, 1, and 1 for 3480-compatible tape controllers (formatters) and 1,0, and 0 for DAT drives, respectively, to direct the targeted tape controller (formatter) or DAT drive to perform a self-test. If there is no error, the command is terminated with good status. If an error is encountered in the test, the command is terminated with check condition status and the sense key is set to indicate a hardware error. The following functions are tested in the 3480-compatible tape controller (formatter):

- **Processor-to-processor communications**—The processor-to-processor information transfer FIFO is diagnosed for failure conditions.
- **Buffer test**—The buffer RAM, microprocessor interface, and the CRC generation circuitry are diagnosed.
- **Device digital logic test**—The digital portion of the device logic is diagnosed.

For 3480-compatible systems only, a **RECEIVE DIAGNOSTIC RESULTS** command (op code 0x1c) is issued after the **SEND DIAGNOSTIC** command has completed. Refer to the next section, "Subtest 201, tape logical unit self-test," for more information. The following is an example of a failed tape controller self-test:

```

Subtest 200    0:00:00
0:00:01    failed

**** Mon Apr 16 19:07:03 1990 ****
Test:    dev_vscsit.t 1.1    Class: 2    Subtest: 200 1.1    Count: 1    Error: 0
Failed: Controller self test

Error: (flag byte) Command completed with error status.

Error: (error byte) Bad status from scsi device.

Error: (SCSI stat byte) Check condition - error or exception event occurred.

Sense bytes:

[ 0-9 ] = 70 00 04 00 00 00 00 24 00 00
[10-19] = 00 00 44 00 23 00 00 00 02 2c

Sense information interpretation:

70          Residual-length field is NOT valid
00          Segment number = 0
04          Sense Key = 4 (DRIVE HARDWARE ERROR)
00000000    Residual length = 0 (NOT valid)
24          36 additional sense bytes
00 00 00 00 (Command-specific bytes)
44 00      Internal target failure
23          Primary FRU: FM PCB (formatter)
           Secondary FRU: CF PCB (core function)
00 00 00    (Sense-key-specific bytes - NOT valid)
02          Sense bytes 20-43 have contents of controller hardware regs
2c          ERPA: Permanent equipment check

```

From the previous example, the following sense byte entries are of interest:

```

[ 0-9 ] = 70 00 04 00 00 00 00 24 00 00
[10-19] = 00 00 44 00 23 00 00 00 02 2c

```

- Sense key definitions are listed in Table 2-22, "Sense key codes," on page 2-54.
- Request sense bytes 12 and 13—Additional sense code and sense code qualifiers (44 00 = internal target failure)
Additional sense code and sense code qualifiers definitions are listed in Table 2-23, "Additional sense codes and descriptions" on page 2-55.
- FRU code definitions are listed in Table 2-24, "FRU codes for byte 14 nibbles," on page 2-59.
- ERPA code definitions are listed on pages 2-60 through 2-63.

2.7.2 Subtest 201, tape logical unit self-test

NOTE

This test does not run on the DAT drive subsystem.

Subtest 201 invokes a self-test on a selected cartridge tape logical unit. The SEND DIAGNOSTIC command is used to begin the cartridge self-test. The SCSI command block is a group 0 type and the op code is 0x1d. The SLFTST, DEVOFL, and the UNITOFL bits are set to 0, 1, and 1, respectively, to direct the targeted tape controller (formatter) to perform a self-test on the tape logical address unit matching the logical unit number (LUN) field of the SCSI command block.

The following are online diagnostic routine descriptions for the tape logical unit self-test:

- **Routine 50 (LOOP WRITE TO READ level 1) test**—Data is written into the data buffer and passed from the buffer through the tape controller (formatter) digital detection circuitry.
- **Routine 51 (LOOP WRITE TO READ level 2)**—Data is written into the data buffer and passed from the data buffer to the tape drive. The tape drive returns the data to the tape controller (formatter) through both the analog and the digital check circuitry. No tape motion is required.
- **Routine 52 (Write data)**—The tape is positioned at the load point and 25 blocks of 100 bytes, 1 kbyte, 32 kbytes, and 64 kbytes each are written to tape.
- **Routine 53 (Read data)**—The tape is positioned at the load point and 25 blocks of 100 bytes, 1 kbyte, 32 kbytes, and 64 kbytes each are written to tape. All data blocks are then read in the reverse and forward directions.
- **Routine 54 (Combination test 1)**—Various combinations of the WRITE, READ, REVERSE, WRITE FILEMARK, ERASE, and SPACE commands are tested.
- **Routine 55 (Lifter test)**—The tape drive is set into special diagnostic mode and a write operation is performed on the medium. The tape drive diagnoses the tape drive lifter solenoid, which controls air pressure between the medium and the magnetic tape head.
- **Routine 56 (Reserved)**—Routine 56 is reserved by the manufacturer and is not available for diagnostic use.
- **Routine 57 (Combination test 2)**—An all-zeros pattern is replicated in the data buffer and blocks are written to tape until Logical End-of-Media (EOM) is detected. The first block written is 255 bytes in length. Each succeeding block length is incremented by one byte. All data is read in both forward and reverse directions.

If an error is encountered during the execution of a routine, a diagnostic result file is generated at that time and no further routine executions occur. This diagnostic result file is then retrieved by the RECEIVE DIAGNOSTIC RESULTS command.

A RECEIVE DIAGNOSTIC command (op code 0x1c) is issued following the completion of the SEND DIAGNOSTIC command. Table 2-9 lists the format of the diagnostic data returned.

Table 2-9, Receive diagnostic command data return format

Byte	Bit <7>	Bit <6>	Bit <5>	Bit <4>	Bit <3>	Bit <2>	Bit <1>	Bit <0>	
0	Routine in error (00,50,51,52,53,54,55,57)								
1	Pass count								
2	FRU code								
3	Reserved byte								
4	(MSB)				First symptom code				(LSB)
5									
6	(MSB)				Second symptom code				(LSB)
7									
8	(MSB)				Third symptom code				(LSB)
9									

The following are field descriptions for the RECEIVE DIAGNOSTIC RESULTS command:

- **Routine in Error**—This field contains the routine ID of the failed routine. If this field contains 0x00, there were no errors detected during the last execution of a SEND DIAGNOSTIC command for the tape logical unit self-test.

If this field contains 0xff, the diagnostic results of data are not generated as the results of a SEND DIAGNOSTIC command. This field is set to 0xff on completion of a successful RECEIVE DIAGNOSTIC RESULTS command for the tape controller (formatter) self-test.

- **Pass Count**—This field contains the number of passes attempted before an error was detected. If an error is detected on the first pass, this field contains a 1. This field is reset each time a new routine is started. For example, if the SEND DIAGNOSTIC command parameter list contained a pass count of 7 for Routine 51 and an error was detected on the third attempt to execute Routine 51, this field would contain a 3.
- **FRU code**—The FRU (field replaceable unit) code attempts to identify the most likely failure at the board level. For example, if the FRU code is a 1, the most likely failure is the SCSI interface (SI) board in the tape controller (formatter). The farthest left four bits contain the least probable FRU and the farthest right four bits contain the most likely FRU. Refer to byte 14 (FRU code) sense data error information in Section 2.15, "Tape system status and error information," on page 2-52.
- **Symptom Codes**—The symptom code attempts to identify the hardware condition that caused the failure. For example, if the first symptom code is 0x0009, the second is 0x918a, and the third is 0x0073, this would mean the machine reel tachometer fluctuated, the RECA dropped at DID write, and the ready signal went off. If the MSB of the symptom code is 00 (for example, 00xx), refer to the *Fujitsu Cartridge Tape Drive CE Manual*, Table 9.1, "Troubleshooting by check codes," for more information. Otherwise, refer to the *Fujitsu Cartridge Tape Controller Customer Engineering Manual*, Appendix A, "FSC DIRECTORY," for more information.

The following is an example of failure output from a tape logical unit self-test when the tape unit input power was turned off:

```
Failed: Tape logical unit self test

Error: Formatter LUN self test detected error executing inline routine.
      : from controller_lun_selftest
Routine in error= 50, Pass count= 01, FRU CODE= 00
1st symptom code= 8520, 2nd symptom code= 8580, 3rd symptom code= 8520
```

- **Symptom code 8520**—TSTBB on time-out at data-transfer-out sequence
- **Symptom code 8580**—MTU offline

NOTE

Symptom code definitions can be found in the *Fujitsu Cartridge Tape Controller Customer Engineering Manual*, Appendix A, "FSC DIRECTORY," and in the *Fujitsu Cartridge Tape Drives CE Manual*, Chapter 9, "MAINTENANCE," Table 9.1, "Troubleshooting by check codes."

The following is an example of failure output from the tape logical unit self-test with no tape cartridge installed:

```
Subtest 201 0:00:43 failed

**** Wed May 2 11:39:59 1990 ****
Test: dev_vscsit.t 1.1 Class: 2 Subtest: 201 1.1 Count: 1 Error: 0
Failed: Tape logical unit self test

Error: Formatter lun self test detected error executing inline routine.
      : from controller_lun_selftest
Routine in error= 52, Pass count= 01, Fru Code= 00
1st symptom code = 00a3, 2nd symptom code = 00a3, 3rd symptom code = 8510
```

- **Symptom code 00a3**—Motion command received when *not ready* was set
- **Symptom code 8510**—TSTI on time-out at ending sequence

The following is an example of a tape unit input power interrupt error:

NOTE

For more information on this error, refer to section 2.14, "SCSI host adapter status and error information," on page 2-50 and section 2.15, "Tape system status and error information," on page 2-52.

```

Subtest 201    0:00:45    failed

**** Mon Apr 16 18:34:07 1990 ****
Test:   dev_vscsit.t  1.1      Class: 2    Subtest: 201 1.1    Count: 1 Error: 0
Failed: Tape logical unit self test

Error: (flag byte) Command completed with error status.

Error: (error byte) Bad status from scsi device

Error: (SCSI stat byte) Check condition - error or exception event occurred.

Sense bytes:

[ 0-9 ] = 70 00 02 00 00 00 00 24 00 00
[10-19] = 00 00 04 00 00 00 00 00 00 3b

Sense information interpretation:

70          Residual-length field is NOT valid
00          Segment number = 0
02          Sense Key = 2 (DRIVE NOT READY)
00000000    Residual length = 0 (NOT valid)
24          36 additional sense bytes
00 00 00 00 (Command-specific bytes)
04 00      Logical unit not ready, cause not reported
00         No FRU identified
00 00 00    (Sense-key-specific bytes - NOT valid)
00         No additional info in sense bytes 20-43
3b         ERPA: Volume removed by operator

```

From the previous example, the following are request sense bytes of interest:

```

[ 0-9 ] = 70 00 02 00 00 00 00 24 00 00
[10-19] = 00 00 04 00 00 00 00 00 00 3b

```

- Sense key definitions are listed in Table 2-22, "Sense key codes," on page 2-54.
- Request sense bytes 12 and 13—Additional sense code/qualifier (04 00 = Logical unit not ready, cause not reportable)
Additional sense code and sense code qualifiers definitions are listed in Table 2-23, "Additional sense codes and descriptions" on page 2-55.
- ERPA code definitions are listed on pages 2-60 through 2-63.

2.8 Class 3 subtests, tape drive tests

Class 3 subtests verify tape motion and that the drive can read and write data to the tape. Class 3 subtests use the command set from the standard common message interface (CMI) set.

CAUTION

Any data existing on the scratch tape will be lost during the execution of these subtests.

The first four subtests do not perform any data verification checks. A status check is made prior to all commands to ensure that the tape is online and ready. Before any command using forward motion is issued, a check is made to ensure that the physical end of the tape has not been reached. For all write commands, a check is made to ensure that the write protect has not been set on the tape media. A beginning-of-tape (BOT) status bit set check is done for every REWIND command to check completion status. The REWIND command will not be sent to the tape driver if the tape media is already at BOT.

Each subtest has no dependency on prior execution of other subtests. The execution of the subtests in sequential order will check the tape subsystem in order of increasing complexity. Table 2-10 lists all Class 3 subtests, their descriptions, and the approximate time required to execute each one.

Table 2-10, Class 3 subtests

Subtest	Description	3480 Time (min:sec) ¹	DAT Time (min:sec) ¹
300	Tape mark test	01:17	01:00
301	Space record test	02:06	02:00
302	Erase test	00:48	NA ²
303	Long block read test	00:15	01:00
304	Fixed record size read/write test	04:40	06:00
305	Write file UNIX-style test	01:12	04:00
306	Variable size records test	00:42	01:00
307	Long space test	00:59	02:43
308	Tape release test	NA ³	07:28
309	Compression ratio test	02:13	NA ²
310	Tape mark test (compressed)	01:17	01:00
311	Space record test (compressed)	02:06	02:00
312	Erase test (compressed)	00:48	NA ²
313	Long block read test (compressed)	00:15	01:00
314	Fixed record size read/write test (compressed)	04:40	06:00
315	Write file UNIX-style test (compressed)	01:12	04:00
316	Variable size records test (compressed)	00:42	01:00
317	Long space test (compressed)	00:59	02:43
318	Tape release test (compressed)	NA ³	07:28

¹ The times presented are approximated.

² This test does not run on the DAT drive subsystem.

³ This test does not run on the 3480 cartridge tape subsystem.

2.8.1 Subtest 300, tape mark test

Subtest 300 verifies that a tape mark can be written to the tape and detected. The subtest first verifies that a tape mark that has been written can be detected in the forward direction.

Next, 100 tape records, each followed by a tape mark, are written. SPACE FILE commands are then issued in both the forward and reverse directions. Tape position is then verified by testing for the presence or absence of a tape mark.

The following is an example of a failed tape mark test:

```
Error: Expected tape mark status did not occur
       : while fwd space file
```

2.8.2 Subtest 301, space record test

Subtest 301 verifies the SPACE FORWARD RECORD and the SPACE REVERSE RECORD commands. The subtest begins by rewinding the tape and writing two records followed by a tape mark. The subtest then writes 20 records of decreasing size to the tape; the biggest of these records is 1,000 bytes and the smallest is 50 bytes. A tape mark is then written to the tape. A space record test is then performed between the end points denoted by the tape marks. The subtest then issues a varying series of FORWARD SPACE RECORD commands. The subtest verifies the success of the space record test by checking for the presence of a filemark. The testing sequence is repeated using the BACK SPACE RECORD command. The subtest then repeats the testing sequence with a combination of FORWARD SPACE and BACK SPACE commands.

The following is an example of a failed space record test:

```
Error: Unexpected tape mark status sensed
       : while fwd space rec
```

2.8.3 Subtest 302, erase test

NOTE

This test does not run on the DAT drive subsystem.

Subtest 302 verifies that an ERASE command used in a write recovery, due to write errors, does not leave glitches on the tape. The subtest writes 10 records of 4,096 bytes each to the tape. Each record, in turn, is erased and the remaining records are reconstituted to make a total of 10 records in the file again. The integrity of the file is checked by spacing over the records.

The following is an example of a failed erase test:

```
Error: Expected tape mark status did not occur
       : while backspace rec
```

2.8.4 Subtest 303, long block read test

Subtest 303 verifies that the long-block status bit indicates correctly whether a long block is present. This test begins by writing a series of records correctly on the tape, starting with a record of four bytes and each subsequent record being twice the size of the previous record. The sixteenth and last record written to the tape is 128 kbytes long. Next, four read passes are used to read the records, test the long-block status bit, and verify that the number of bytes transferred was correct.

The first read pass has the number of bytes to be transferred equal to the record size on the tape. A check is then made to ensure that the long-block status bit is not set.

The second pass reads each record with the requested transfer size as two bytes less than the record size on the tape. A check is made to ensure that the long-block status bit is set and the number of bytes transferred is equal to the number requested.

The third pass is the same as the second pass except that the requested transfer size is one byte less than the record size on the tape. The results of this pass are odd byte counts in the data transfer size requests.

The fourth and final pass reads each record except the 128-kbyte record, with the requested transfer size equal to the maximum number of bytes allowed by the 3480/DAT drive (0x20000). A check is made to ensure that the long-block status bit is not set and that the number of bytes transferred is not equal to the number of bytes requested. The following is an example of a failed long block read test:

```
Error: Expected long block read status did not occur
       :from long_xblk_test
```

2.8.5 Subtest 304, fixed record size read/write test

Subtest 304 writes and reads 160 records of a fixed size. The first write pass writes twenty 16-kbyte records to the tape. Each of these records contains a different data pattern. On subsequent write passes, the record size is increased by 16 kbytes until the record size reaches the maximum 128 kbytes. The tape is then rewound and the records are read and the data is verified. Table 2-11 lists the data pattern used.

Table 2-11, Subtest 304 data pattern

Hexadecimal test pattern			
00000000	ffffff	a5a5a5a5	5a5a5a5a
f0f0f0f0	0f0f0f0f	cc33c3c3	99669696
01010101	02020202	04040400	8080808
10101010	20202020	40404040	80808080
fedfbf7	edfbf7f	0fa5c396	12487edb

The following is an example of a failed fixed record size read/write test:

```
Error: data miscompare
      : buf adr 00000000 exp 00000000 act 12487edb
      : while reading from tape
```

2.8.6 Subtest 305, write file UNIX-style test

Subtest 305 simulates the sequence of commands that are given to the tape driver by the ConvexOS driver. A file of 8 records of 32 kbytes each are written to tape. Two filemarks are written to the tape, and a BACKSPACE FILEMARK command is issued. Seven more files are written in the same manner. The data in each record is set equal to the record number. The end result is 64 numbered records on the tape with a filemark after every 8 records. The last record ends with two filemarks. The tape is rewound. All records are read and verified and all filemarks are verified to be in the right locations on the tape.

The following is an example of a failed write file UNIX-style test:

```
Error: Expected tape mark status did not occur
      : while verifying last tapemark on tape
```

2.8.7 Subtest 306, variable size records test

Subtest 306 verifies that variable-length records on a tape can be written, read, and verified. First, records of 1 byte to 258 bytes (each record size is incremented by 1 byte) are written to the tape. Next, sets of 5 records each are written to the tape. The sizes of these records are designed to cross base 2 boundaries. With the exception of the 1-byte record, the first 2 bytes of each record contain the record number. Byte 3 and greater all contain a data pattern that is either defaulted or is user-specified from the keyboard or from a file. The default pattern is 0x6db6. The default number of error printouts is 8 but can be set up to 100 error printouts by the user. The total number of miscompares in a record are totaled for the printout. There are a total of 298 records written and verified with the size of the records ranging from 1 byte to 65,538 bytes in this subtest. Table 2-12 lists the record sizes for Subtest 306.

Table 2-12, Subtest 306 record sizes

Starting size	Number of records	Record sizes	Record number
1	258	1 to 258	1 to 258
510	5	510 to 514	259 to 263
1,022	5	1,022 to 1,026	264 to 268
2,046	5	2,046 to 2,050	269 to 273
4,094	5	4,094 to 4,098	274 to 278
8,190	5	8,190 to 8,194	279 to 283
16,382	5	16,382 to 16,386	284 to 288
32,766	5	32,766 to 32,770	289 to 293
65,534	5	65,534 to 65,538	294 to 298

The following is an example of a failed variable records test:

```

Error in record 292, record length=32769 bytes
Error: data byte miscompared
  : buf adr = 00000008 exp = 6d act = dd
  : buf adr = 00000009 exp = b6 act = bb
  : buf adr = 00000f01 exp = b6 act = bb
  : buf adr = 00000f02 exp = 6d act = 6f
  : buf adr = 00002012 exp = 6d act = 66
  : buf adr = 00002013 exp = b6 act = b7
  : buf adr = 00002014 exp = 6d act = 7d
  : buf adr = 00004022 exp = 6d act = 6f
  : Total miscompares = 10
  : while comparing data read from tape
0:00:30 failed
**** Sat May 12 15:23:30 1990 ****
Test: dev_vscsit.t 1.1 Class: 3 Subtest: 306 1.1 Count: 1 Error: 0
Failed: Variable size records read/write test

```

2.8.8 Subtest 307, long space test

Subtest 307 verifies that the tape drive can space across long regions of the tape. The subtest begins by rewinding the tape and writing two records followed by a tape mark. The subtest then writes 3 records of 100 bytes, 80 records of 128 kbytes, 3 records of 100 bytes, and a tape mark. SPACE FORWARD RECORD and SPACE REVERSE RECORD commands are then used to move back and forth across these records.

2.8.9 Subtest 308, tape release test

NOTE

This test does not run on the 3480-compatible cartridge tape subsystem.

Subtest 308 verifies the ability of the DAT drive to automatically release the capstan, pinch roller, and cylinder without losing its position on the tape or corrupting data stored on the tape. The DAT drive will release the capstan and pinch roller when it is idle for more than 30 seconds, and will pull the tape medium away from the cylinder when it is idle for more than 90 seconds. This subtest verifies these functions by first rewinding the tape, writing 10 records of 64 kbytes each, and waiting for 45 seconds for the drive to release the capstan and pinch roller. It then writes 10 more records and waits 120 seconds for the drive to pull the tape away from the cylinder. The subtest then writes 10 more records, rewinds the tape, verifies that the first 5 records are correct, and with the drive in "read" mode waits 120 seconds for the tape to be pulled away from the cylinder again. The subtest then verifies the next 20 records and waits 45 seconds for the capstan and pinch roller to be released again. Finally, the last 5 records are verified, the tape is rewound, and all 30 records are verified without interruption.

2.8.10 Subtest 309, compression ratio test

NOTE

This test does not run on the DAT drive subsystem.

Subtest 309 verifies that the EDRC compression feature is functioning on the 3480-compatible drives that have this feature. This test utilizes the formatter's ability to report the number of bytes written to the tape, as well as the number of bytes written to the formatter. If data is compressed, these quantities will not be the same. A megabyte of zeros is first written to the drive with EDRC compression turned off; the test verifies that the number of bytes written to the drive was no less than the number of bytes written to the formatter. Then, a megabyte of zeros is written to the drive with EDRC compression turned on; the test verifies that the number of bytes written to the drive was less than the number of bytes written to the formatter. This test makes no attempt to verify that the data is compressed accurately or effectively; its purpose is to identify cases where compression is unexpectedly absent.

2.8.11 Compressed mode tests

Subtests 310-318 run only on tape subsystems equipped with data compression. Their operation is identical to tests described in previous sections; Table 2-13 lists the subtest number, name, and the subtest number with the corresponding description.

Table 2-13, Tape drive data compression subtests

Subtest number	Description	Corresponding subtest
310	Tape mark test (compressed mode)	300
311	Space record test (compressed mode)	301
312	Erase tape test (compressed mode)	302
313	Long block read test (compressed mode)	303
314	Fixed record size read/write test (compressed mode)	304
315	Write file UNIX-style test (compressed mode)	305
316	Variable size records read/write test (compressed mode)	306
317	Long space record test (compressed mode)	307
318	Tape release test (compressed mode)	308

2.9 Class 4 subtests, tape driver exception tests

Class 4 subtests test various conditions that do not usually occur during normal tape drive operations. These exception subtests test the tape driver and controller stability and integrity when such operations such as ZERO BYTES READ or WRITE commands are submitted to the tape driver.

CAUTION

Any data existing on the scratch tape will be lost during the execution of these subtests.

Table 2-14 lists all Class 4 subtests, their descriptions, and the approximate time required to execute each subtest.

Table 2-14, Class 4 subtests

Subtest	Description	3480 time (min:sec) ¹	DAT time (min:sec) ¹
400	Beginning-of-tape (BOT) exception test	00:07	00:30
401	Zero length operations exception test	00:09	00:30
402	End-of-data (EOD) test	00:17	01:30
403	End-of-tape (EOT) exception test	04:56	02:00:00 ²
404	Beginning-of-tape (BOT) exception test (compressed)	00:07	00:30
405	Zero length operations exception test (compressed)	00:09	00:30
406	End-of-data (EOD) test (compressed)	00:17	01:30
407	End-of-tape (EOT) exception test (compressed)	04:56	02:00:00 ²

¹ The times presented are approximated.

² Because of the time required to complete, this test does not run as default option from the Test Parameter Menu.

2.9.1 Subtest 400, beginning-of-tape (BOT) status exception test

This subtest rewinds the tape then writes a tape filemark. Three consecutive BACKSPACE FILE commands are issued. After the first BACKSPACE FILE, the BOT status bit should not be set, but the tape mark status bit should be set. At the completion of the second and third BACKSPACE FILE, the BOT status bit should be set and a check condition should occur. The request sense bytes obtained after the check condition are checked to see whether the EOM bit is set. A FORWARD SPACE command is then issued. The BOT status bit should be reset and the tape mark status bit should be set.

The tape is rewound and a 256-byte record is written. Three Backspace Record commands are issued consecutively. After the first BACKSPACE RECORD command, the BOT status bit should not be set. After the second and third BACKSPACE RECORD commands are complete, the BOT status bit should be set and a check condition should occur. The request sense bytes obtained after the check condition are checked to see whether the EOM bit is set. A FORWARD SPACE RECORD command is then issued. The BOT status bit should be reset.

2.9.2 Subtest 401, zero-length operations exception test

Subtest 401 rewinds the tape and writes two 4-kbyte records with known patterns. The zero-length operations are commands formatted to write 0 bytes, read 0 bytes, forward space 0 records, forward space 0 files, backspace 0 records, and backspace 0 files. Each of these zero-length operations is preceded by a backspace record of count = 1. The second record is then read and verified. No tape motion is expected for any of the zero-length commands sent to the tape driver.

2.9.3 Subtest 402, end-of-data (EOD) status exception test

Subtest 402 rewinds the tape and writes two records of known patterns of 128 kbytes. A BACKSPACE RECORD command is issued followed by a command to write a 4-kbyte record of a known pattern. This effectively replaces the second record on tape with a shorter record. The tape is rewound and the two records are read and verified. A third READ command is issued to attempt to read past the second record on tape. A check condition from the controller is expected with the request sense bytes indicating end-of-data (EOD).

The tape is rewound and the first record is read and verified. An ERASE command with a default byte length is issued. The tape is rewound again. The first record is read and verified, and an attempt is made to read the erased second record. A check condition from the controller is expected with the request sense bytes indicating EOD.

2.9.4 Subtest 403, end-of-tape (EOT) status exception test

Subtest 403 rewinds the tape and writes multiple 128-kbyte records until EOT is sensed in the status byte. A BACKSPACE RECORD command is issued. Then a 128-kbyte record with a known pattern is written. An EOT status condition is expected as a result of the WRITE command. The tape is backspaced one record and the record just written is verified. A REWIND command is then issued, which completes the test.

2.9.5 Compressed mode tests

Subtests 404-407 run only on tape subsystems equipped with data compression. Their operation is identical to tests described in previous sections; Table 2-15 lists the subtest number, name, and the subtest number with the corresponding description.

Table 2-15, Tape driver exception data compression subtests

Subtest Number	Description	Corresponding subtest
404	Beginning-of-tape (BOT) status exception test (compressed mode)	400
405	Zero-length operations exceptions test (compressed mode)	401
406	End-of-data (EOD) status exception test (compressed mode)	402
407	End-of-tape (EOT) status exception test (compressed mode)	403

2.10 Class 5 subtests, automatic cartridge loader (ACL) tests

Class 5 subtests test the functionality of the magazine automatic cartridge loader (ACL) mechanism.

CAUTION

Any data existing on the scratch tape will be lost during the execution of these subtests.

Table 2-16 lists all Class 5 subtests, their descriptions, and the approximate time required to execute each subtest when using two tapes in the magazine.

Table 2-16, Class 5 subtests

Subtest	Description	3480 time (min:sec) ¹	DAT time (min:sec) ¹
500	Stacker auto test: Stacker automatic mode test	02:58	07:23
501	Stack system test: Stacker system mode test	02:05	03:50

¹ The times presented are approximated.

2.10.1 Subtest 500, stacker automatic mode test

Subtest 500 tests the stacker in automatic mode, which loads tape cartridges sequentially. The operator is required to load a magazine containing at least two test tapes. The diagnostic makes two passes through the magazine. A unique pattern is written on each cartridge on the first pass. These patterns are verified on the second pass, to assure that the stacker is progressing through the tape cartridges in proper sequence.

2.10.2 Subtest 501, stacker system test

Subtest 501 tests the stacker in system mode, which permits random access loading of tape cartridges. The operator is required to load a magazine containing at least two test tapes. The diagnostic makes two passes through the magazine. On the first pass, the cartridges in the magazine are loaded at random and a unique pattern is written on each cartridge. On the second pass, the cartridges are loaded in the same order and the patterns are verified.

2.11 Interactive debugger

The diagnostic provides an interactive debugger that allows the operator to perform some low-level interactions that are helpful when diagnosing a subtest failure. Invoke the debugger with one of the following methods:

- Use the **-d** option when invoking the diagnostic (enter **dev_vscsit[x] -d**). No subtests are executed.
- Respond with a **y** to the **Enable Debug Monitor** question in the **TEST PARAMETER SUMMARY**. The debugger will then be invoked if an error is encountered during a test.

Once the interactive debugger is entered, online help commands are available. Figure 2-8 illustrates the information displayed when you enter **help**.

Figure 2-8, Interactive debugger online help

Input base specification:

OdNN - decimal, 0xNN or NN - hexadecimal, the default is hexadecimal

Meta-command sequences:

![UNIX_CMD] - execute UNIX_CMD
 !![UNIX_CMD] - fork a shell and execute UNIX_CMD (allows redirection)
 <FILE - redirect input from FILE (recursive)
 <<FILE - end input from current file and change input to FILE

Commands:

Commands may be abbreviated as long as the abbreviation is unique.

help	[COMMAND ...]	- display general or specific help
cd	[DIRECTORY]	- change to DIRECTORY
quit		- exit debug mode
echo	[-n] [arg ...]	- echo statement to display
pause	[-n] [seconds]	- pause for <C/R> or seconds
mb	begin [end] [step]	- modify/[dump] bytes CCU
mw	begin [end] [step]	- modify/[dump] words CCU
ml	begin [end] [step]	- modify/[dump] longs CCU
mmb	begin [end] [step]	- modify/[dump] bytes in MM
mmw	begin [end] [step]	- modify/[dump] words in MM
mm1	begin [end] [step]	- modify/[dump] longs in MM
fb	begin [end] value [incr [step]]	- fill bytes CCU
fw	begin [end] value [incr [step]]	- fill words CCU
fl	begin [end] value [incr [step]]	- fill longs CCU
ffb	begin [end] value [incr [step]]	- fill bytes in Main Memory
ffw	begin [end] value [incr [step]]	- fill words in Main Memory
ff1	begin [end] value [incr [step]]	- fill longs in Main Memory
weof	count	- write EOF count times
fsr	count	- forward space record count times
bsr	count	- backward space file count times
fsf	count	- forward space file count times
bsf	count	- backward space file count times
erase		- erase tape, default length
wphys	[-c] [-b <blksz>] [-n <nfiles>] [-i] {byte_count [pattern]} {<file>}	- write bytes with optional pat
rphys	[-c] [-b blksz] {byte_count [pattern]} {>file}	- read bytes with opt pat to verify
rewind		- rewind tape unit
changeunit	unit subunit	- change current unit and subunit
tracemsgs	0 or 1	- trace mbs messages control
notimeout	0 or 1	- mbs message timeout control
status		- read tape status(IO_RDSTATS_PHYS)
laststat		- read last command's sense bytes
unload		- unload tape (IO_UNLOAD)
unitclr		- clear tape error status
boot		- reboot the CCU driver
reset		- reset the host adapter

Figure 2-8, Interactive debugger online help
(continued)

dapseltest	- diagcmd adapter prom self-test
darseltest	- diagcmd adapter ram self-test
daidentify	- diagcmd adapter identify(rev num)
dtidentify	- diagcmd target identify(rev num)
dfcselftest	- diagcmd target cntrl self-test
dfuseltest	- diagcmd target lun self-test
dfrecvdiag	- diagcmd recv diag results
dfdispload string	- diagcmd load display on tape unit
stkselect	- select a tape in the stacker
stkstat	- read stacker status
stkmode	- set stacker mode
stkload	- load tape from stacker
stkunload	- unload tape to stacker
stkloadmag	- load stacker magazine
tapelog	- show log sense info
scsi	- send scsi command
scsimm	- send scsi command with DMA

In addition to the help screen in Figure 2-8, you can display help for a specific command by entering:

help *command*

where *command* is the desired debugger command. Abbreviations of desired commands may be used as long as they are unique. For example, to display help for all commands starting with the letter "r," enter **help r**.

2.12 Interactive debugger command descriptions

This section describes each command in the interactive debugger.

2.12.1 help

Usage: **help** [*command* ...]

Displays general or specific help information, where *command* is the desired debugger command. Abbreviations of desired commands may be used as long as they are unique. For example, the following command displays help for all commands starting with the letter "r":

help r

2.12.2 boot

Usage: **boot**

Reboots the CCU driver.

2.12.3 cd

Usage: **cd** [*directory*]

Changes to another directory, where *directory* is any valid directory path. If *directory* is omitted, the default path is \$HOME or / if \$HOME is not set.

2.12.4 changeunit

Usage: **changeunit** *unit subunit*

Selects the next tape unit to be tested in the debug mode, where *unit* is the SCSI ID of the 3480-compatible formatter or DAT drive and *subunit* is the subunit number of the tape drive.

2.12.5 daidentify

Usage: **daidentify**

Tells the host adapter to report its revision number.

2.12.6 dapseltest

Usage: **dapseltest**

Tells the host adapter to run its PROM self-test.

2.12.7 darseltest

Usage: **darseltest**

Tells the host adapter to run its RAM self-test.

2.12.8 dfcselftest

Usage: **dfcselftest**

Tells the 3480-compatible tape controller (formatter) or DAT drive to run its self-test.

2.12.9 dfdispload

NOTE

dfdispload is not supported on the DAT drive subsystem.

Usage: **dfdispload** *string*

Tells the 3480-compatible target device to load a *string* on its display.

2.12.10 dfrecvdiag

NOTE

dfrecvdiag is not supported on the DAT drive subsystem.

Usage: **dfrecvdiag**

Tells the target 3480-compatible device to report its diagnostics results.

2.12.11 dfuselftest

NOTE

dfuselftest is not supported on the DAT drive subsystem.

Usage: **dfuselftest**

Tells the target 3480-compatible tape unit to run its self-test.

2.12.12 dtidentify

Usage: **dtidentify**

Displays the target's vendor ID, product ID, product revision level, and (DAT only) firmware revision level.

2.12.13 echo

Usage: **echo** [-n] [*arg* ...]

Writes arguments separated by blanks and terminated by a newline to the display, where -n means do not echo the terminating newline character.

2.12.14 erase

Usage: **erase**

Erases a default length of tape on the selected tape drive. For DAT drives, this command erases the rest of the tape by placing an EOD mark at the current tape position.

2.12.15 fb, fl, fw

Usage: **fb** *begin value [incr [step]]*
fb *begin end value [incr [step]]*
fl *begin value [incr [step]]*
fl *begin end value [incr [step]]*
fw *begin value [incr [step]]*
fw *begin end value [incr [step]]*

Fills CCU memory with specified pattern in byte-at-a-time mode (**fb**), halfword-at-a-time mode (**fw**), or word-at-a-time mode (**fl**), where:

- *begin* is the starting address.
- *end* is the ending address.
- *incr* is the fill value increment.
- *step* is the address increment.
- *value* is the initial fill value.

The first format (for example, **fb** *begin value [incr [step]]*) stores *value* at address *begin*.

The second format (for example, **fb** *begin end value [incr [step]]*) fills from the address *begin* up to and including address *end* with the value *value*.

If the optional *incr* parameter is specified, *value* is incremented by *incr* after each fill. If *incr* is followed by *step*, the fill address is incremented by *step* elements instead of the normal step of one for a byte, two for a halfword, or four for a word.

The following examples illustrate the use of these commands.

1. *fl 2000000 12345678*

This command stores one longword (32 bits) of value 0x12345678 at main memory address 0x200000.

2. *fl 200000,0d1000 0*

This command zeroes 1000 longword (32-bit) locations starting at main memory address 0x200000.

3. *fb 200000,0d40 10 4 2*

This command fills 40 even bytes starting at CCU address 0x200000 with a value that begins at ten and increments by four each time.

2.12.16 ffb, ffl, ffw

Usage: **ffb** *begin value [incr [step]]*
ffb *begin end value [incr [step]]*
ffl *begin value [incr [step]]*
ffl *begin end value [incr [step]]*
ffw *begin value [incr [step]]*
ffw *begin end value [incr [step]]*

Addresses are offsets into the diagnostic's main memory I/O buffer. Fills main memory with specified pattern in byte-at-a-time mode (**ffb**), halfword-at-a-time mode (**ffw**), or word-at-a-time mode (**ffl**) where:

- *begin* is the starting address.
- *end* is the ending address.
- *value* is the initial fill value.
- *incr* is the fill value increment.
- *step* is the address increment.

The first format (**ffb** *begin value*) stores *value* at address *begin*. The second format (**ffb** *begin end value [incr [step]]*) fills from the address *begin* up to and including address *end* with the value *value*.

If the optional *incr* parameter is specified, *value* is incremented by *incr* after each fill. If *incr* is followed by *step*, the fill address is incremented by *step* elements instead of the normal step of one for a byte, two for a halfword, or four for a word.

2.12.17 fsr, bsr, fsf, bsf

Usage: **fsr** *count*
bsr *count*
fsf *count*
bsf *count*

Spaces forward by *count* records (**fsr**), backward by *count* records (**bsr**), forward by *count* files (**fsf**), and backward by *count* files (**bsf**).

2.12.18 laststatus

Usage: **laststatus**

Retrieves the sense bytes from the last request sense command performed by the CCU driver.

2.12.19 mb, mw, ml

Usage: **mb** *begin* [*end* [*step*]]
 mw *begin* [*end* [*step*]]
 ml *begin* [*end* [*step*]]

Displays and/or modifies CCU address space in byte-at-a-time mode (mb), halfword-at-a-time mode (mw), or word-at-a-time mode (ml), where:

- *begin* is the starting address.
- *end* is the ending address.
- *step* is the address increment (if omitted, default value is access size).

If *end* is omitted, the debugger enters an interactive mode that allows modification of memory. The following list gives the valid responses while in interactive mode:

[<i><value></i>]	Write optional <i><value></i> to current address, advance to next address.
[<i><value></i>]=	Write optional <i><value></i> to current address, and stay at the present address (reread).
[<i><value></i>] ^[<i>N</i>]	Write optional <i><value></i> to current address, move to address <i>N</i> (address 0 if <i>N</i> is omitted).
[<i><value></i>]+[<i>N</i>]	Write optional <i><value></i> to current address, advance to the next address (<i>N</i> addresses, if <i>N</i> is specified).
[<i><value></i>]-[<i>N</i>]	Write optional <i><value></i> to current address, back up to the previous address (<i>N</i> addresses, if <i>N</i> is specified).
[<i><value></i>]q	Write optional <i><value></i> to current address, exit interactive mode.

Multiple commands may be specified on the same line. A comma or space may be used to separate the commands or value as shown in the following example:

```
Debug Mode-> ml c00000  
<CCU:00c00000> = 1c 00=ff,1q
```

00=ff,1q is an example of executing multiple commands on the same line. This sequence displays the word value at IDC address c00000 and allows the operator to modify this value. The operator's response modifies the word to 0, rereads and displays the new value at c00000, modifies the value again to 0xff, skips to address c00000, modifies its value to 0x1, then exits the interactive mode.

2.12.20 mmb, mmw, mml

Usage: **mmb** *begin* [*end* [*step*]]
 mmw *begin* [*end* [*step*]]
 mml *begin* [*end* [*step*]]

Displays and/or modifies main memory address space in byte-at-a-time mode (mmb), halfword-at-a-time mode (mmw), or word-at-a-time mode (mml), where:

- *begin* is the starting main memory address.
- *end* is the ending main memory address.
- *step* is the address increment (if omitted, default value is access size).

If *end* is omitted, the debugger enters an interactive mode that allows modification of memory. The following list gives the valid responses while in interactive mode:

[<value>]	Write optional <value> to current address, advance to next address.
[<value>]=	Write optional <value> to current address, and stay at the present address (reread).
[<value>]^[<i>N</i>]	Write optional <value> to current address, move to address <i>N</i> (address 0 if <i>N</i> is omitted).
[<value>]+[<i>N</i>]	Write optional <value> to current address, advance to the next address (<i>N</i> addresses, if <i>N</i> is specified).
[<value>]-[<i>N</i>]	Write optional <value> to current address, back up to the previous address (<i>N</i> addresses, if <i>N</i> is specified).
[<value>]q	Write optional <value> to current address, exit interactive mode.

Multiple commands may be specified on the same line. A comma or space may be used to separate the commands or values as shown in the following example:

```
Debug mode -> mmb c03fc1  
<Main-Mem:c03fc1> = 1c 00==ff,1q
```

1c 00==ff,1q is an example of executing multiple commands on the same line. This sequence modifies the byte at main memory address c03fc1 to 0, rereads and displays the new value, modifies the byte to 0xff, skips to address 0xc03fc2 and modifies it to a 0x1, and then quits interactive mode.

2.12.21 notimeout

Usage: **notimeout** {0 | 1}

Enables (0) or disables (1) the timeout of the MBS return message. It is useful during debugging of the driver when timeout should be disabled.

2.12.22 pause

Usage: **pause** [-n] [*seconds*]

Waits for specified amount of time or for a **(RETURN)** if the time is omitted, where -n means do not echo the pause message and *seconds* specifies the number of seconds to pause.

2.12.23 quit

Usage: **quit**

Exits the interactive debugger.

2.12.24 reset

Usage: **reset**

Resets the host adapter using EGOS to write to the host adapter reset port. An EGOS read from the status port follows the write to read status from the host adapter. A bad status signal will result in an error printout. After this RESET command, the BOOT command in debugger mode should be invoked to reconfigure and reprobe the driver.

2.12.25 rewind

Usage: **rewind**

Rewinds tape unit.

2.12.26 rphys

Usage: **rphys** *byte_count* [*pattern*]

Reads from the physical device *byte_count* number of bytes with optional *pattern* to verify.

2.12.27 scsi

Usage: **scsi** [*arg ...*]

Sends a 12-byte SCSI command descriptor block (CDB) to the target. Up to 12 arguments may be specified; each argument will be interpreted as the hexadecimal representation of a byte to be placed in the CDB. Any remaining unspecified bytes in the CDB will be cleared.

The specified CDB will be passed to the driver in the data field of a CMI message. If the SCSI device generates any data as a result of executing the command, up to 20 bytes of this data will be imbedded in the message when it returns. These 20 bytes are displayed in hexadecimal after the **scsi** command is completed.

2.12.28 scsimm

Usage: **scsimm** [*-t timeout*] [*cmdarg ...*]

Sends a 12-byte SCSI command descriptor block (CDB) to the target. Up to 12 command arguments may be specified; each argument will be interpreted as the hexadecimal representation of a byte to be placed in the CDB. If there is at least one argument, any remaining unspecified bytes in the CDB will be cleared. The optional *-t* argument should be followed by a decimal number, indicating the number of seconds that will be allowed before the command times out. The default time-out value is 1.

This command differs from the **scsi** command in that the **scsi** command is not passed to the driver in the CMI message. Instead, the command is written at the beginning of the main memory buffer allocated for the diagnostic (see **mmb**, **mmw** and **mm1** commands). The

driver will read the CDB from the buffer. Any required input will be obtained from the buffer starting after the 20-byte command structure (4-byte data offset + 4-byte time-out + 12-byte CDB). Any output generated by the SCSI command will appear in the main memory buffer at this same offset when the command has completed. The `mmb` command can be used to view or modify this buffer at the address indicated when the diagnostic is started up.

`scsim` with no command arguments will resend the command in the buffer. The time-out will then be the default 1 second if it is not respecified.

2.12.29 status

Usage: `status`

Reads and returns current tape unit status.

2.12.30 stkload

Usage: `stkload`

Causes the stacker to load the cartridge into the tape drive.

2.12.31 stkloadmag

Usage: `stkloadmag`

Loads the magazine into the stacker.

2.12.32 stkmode

Usage: `stkmode [4 | 8]`

Sets the stacker mode to auto (4) or system (8).

2.12.33 stkselect

Usage: `select n`

Selects tape *n* in the stacker.

2.12.34 stkstat

Usage: `stkstat`

Obtains the status from the stacker. The status is returned in the CMI message. It must be viewed there by using `trace_msgs`.

2.12.35 stkunload

Usage: **stkunload**

Causes the tape drive to unload the cartridge into the stacker.

2.12.36 tracemsgs

Usage: **tracemsgs** {0 | 1}

Enables (1) or disables (0) the listing of the MBS send and receive messages sent to and received from the driver. When an error is encountered in the test, the debugger mode may be entered and the message tracing should be turned on.

2.12.37 unitclr

Usage: **unitclr**

Clears tape error status.

2.12.38 unload

Usage: **unload**

Unloads tape medium from tape unit.

2.12.39 weof

Usage: **weof** *count*

Writes a number of end-of-file (EOF) marks on the tape medium, where *count* is the number of EOF marks to be written.

2.12.40 wphys

Usage: **wphys** *byte_count* [*32-bit pattern*]

Writes *byte_count* bytes to the physical device with optional *pattern* of bytes.

2.13 Using a test script

The following procedure describes how to run a test script and includes an example test script.

1. Create two files. For this example, the script files are named `scr3` and `scr3a`. Figures 2-9 and 2-10 show examples of `scr3` and `scr3a` script files:

Figure 2-9, Example script file, scr3

```
echo ++
echo *****Tape test starting*****
echo status command
status
echo ...rewinding tape
rew
echo + write 1 filemark at bot
weof 1
<<scr3a
```

Figure 2-10, Example script file, scr3a

```
echo ++
echo *****Scr3a tape test script re-starting*****
echo + backspace 1 file
bsf 1
echo + erase the old tape mark
erase
echo + weof 1 (write new tape mark)
weof 1
echo + write 10000 bytes with 11111111
wphys 10000 11111111
echo + write 16000 bytes with 22222222
wphys 16000 22222222
echo + write 1f000 bytes with 33333333
wphys 1f000 33333333
echo + write 20000 bytes with 44444444
wphys 20000 44444444
echo + back space 1 record
bsr 1
echo + back space 3 records
bsr 3
echo + back space 1 file
bsf 1
echo + forward space 1 file
fsf 1
echo + read 10000 11111111
rphys 10000 11111111
echo + read 16000 22222222
rphys 16000 22222222
echo + read 1f000 33333333
rphys 1f000 33333333
echo + read 20000 44444444
rphys 20000 44444444
<<scr3a
```

2. Invoke the dev_vscsit diagnostic using the debug option (dev_vscsit.t -d).

3. Respond to the questions asked in the diagnostic normally.
4. At the Debug Mode-> prompt, type <scriptname. Figure 2-11 shows the output of the example test script.

Figure 2-11, Example test script output

```

Debug Mode-> <scr3
++
*****Tape test starting*****
status command

The current tape unit status is = 0x0000043
+ write 1 filemark at bot
++
*****Scr3a tape test script re-starting*****
+ backspace 1 file
+ erase the old tape mark
+ weof 1 (write new tape mark)
+ write 10000 bytes with 11111111
+ write 16000 bytes with 22222222
+ write 1f000 bytes with 33333333
+ write 20000 bytes with 44444444
+ back space 1 record
+ back space 3 records
+ back space 1 file
+ forward space 1 file
+ read 10000 11111111
+ read 16000 22222222
+ read 1f000 33333333
+ read 20000 44444444
++
*****Scr3a tape test script re-starting*****
+ backspace 1 file
+ erase the old tape mark
+ weof 1 (write new tape mark)
+ write 10000 bytes with 11111111
+ write 16000 bytes with 22222222
+ write 1f000 bytes with 33333333
+ write 20000 bytes with 44444444
+ back space 1 record
+ back space 3 records
+ back space 1 file
+ forward space 1 file
+ read 10000 11111111
+ read 16000 22222222
+ read 1f000 33333333
+ read 20000 44444444
++

```

5. The script will continue to run until the end-of-tape (EOT) is reached. To exit the program before the EOT is reached, press **CTRL-C**.

2.14 SCSI host adapter status and error information

The following sections include information on status and error reporting for the SCSI host adapter. Table 2-17 lists the contents of the SCSI host adapter status block.

Table 2-17, Status block contents

Bits <31..24>	Bits <23..16>	Bits <15..8>	Bits <7..0>
Command identifier			
Reserved	SCSI status	Error	Flags
Class/code	Segment	SCSI flags	Info byte 3
Info byte 4	Info byte 5	Info byte 6	EX length

2.14.1 Flags byte

This byte contains flags indicating the status of the host adapter. Table 2-18 lists each flag bit in the host adapter status block flags byte.

Table 2-18, Status block flags byte

Bit <7>	Bit <6>	Bit <5>	Bit <4>	Bit <3>	Bit <2>	Bit <1>	Bit <0>
CC	ERR	RTY	DTT	TAR	CSB	SE	0

The following list contains a brief explanation of each flag bit.

- CC Command complete
- ERR Error status (this command had an error)
- RTY Command required one or more retries
- DTT Data transfer truncated (SCSI command completed, but fewer bytes were transferred than requested)
- TAR Target mode enabled in SCSI host adapter
- CSB Continued status block (for additional sense data)
- SE Soft error

2.14.2 Error byte

The following list contains a brief explanation of each error byte code.

0x01	Invalid board command
0x02	Bad unit or ID number
0x03	Floppy disk option not installed
0x0b	Reserved field not zero
0x0e	Command list stopped
0x0f	Bad command list size field
0x11	List already active
0x14	Bus time-out
0x15	Bus error
0x16	Scatter/gather descriptor block read error
0x1e	SCSI select time-out
0x1f	SCSI disconnect time-out
0x20	SCSI parity error
0x21	Unexpected SCSI disconnect
0x22	General SCSI bus error
0x23	SCSI device returned bad status
0x24	Unexpected SCSI phase encountered
0x25	Bad byte seen by SCSI controller chip
0x26	Error in synchronous transfer negotiation
0x27	SCSI bus reset during operation
0x28	Target command not found
0x29	This command must be issued with a command list.
0x2a	Drive is write protected
0x2b	Vendor unique command set up improperly, modifier field zero
0x2c	Bad SCSI chip condition
0x61	Static RAM error
0x62	PROM checksum error
0x63	Undefined diagnostic specified
0x80	Firmware error (0x80 and above)

2.14.3 Host adapter status byte

A status byte is sent from the target to the initiator during the STATUS phase at the termination of each command unless the command is cleared by one of the following:

- An ABORT message
- A BUS DEVICE RESET message
- A "hard" RESET condition
- An unexpected BUS FREE condition

Table 2-19 lists the bits in a host adapter status byte.

Table 2-19, Host adapter status byte

Byte	Bit <7>	Bit <6>	Bit <5>	Bit <4>	Bit <3>	Bit <2>	Bit <1>	Bit <0>
0	Reserved		Status byte code					Reserved

Table 2-20 lists the status byte codes and their descriptions.

Table 2-20, Bit values for SCSI status byte code

Status byte bits								Status represented
<7>	<6>	<5>	<4>	<3>	<2>	<1>	<0>	
R	R	0	0	0	0	0	R	Good
R	R	0	0	0	0	1	R	Check condition
R	R	0	0	0	1	0	R	Condition met/good
R	R	0	0	1	0	0	R	Busy
R	R	0	1	0	0	0	R	Intermediate/condition met/good
R	R	0	1	1	0	0	R	Reservation conflict
R	R	1	0	1	0	0	R	Queue full

R = Reserved bit
All other codes are reserved

2.15 Tape system status and error information

The following sections include information on status and error reporting for the 3480-compatible formatter and tape drive(s) in a cartridge tape system or the DAT drive subsystem.

2.15.1 Sense data

The sense bytes contained in the 3480-compatible controller (formatter) or DAT drive indicate error, status, and statistical information about the controller to the drive or about the device. Error information is set in a sense byte when the check condition status is reported as a completion status. The sense byte is transmitted to an initiator by the REQUEST SENSE or the REQUEST LOG command. Table 2-21 lists the sense byte format for error code 70.

Table 2-21, Sense byte format

Byte	Bit <7>	Bit <6>	Bit <5>	Bit <4>	Bit <3>	Bit <2>	Bit <1>	Bit <0>	
0	Valid	1	1	1	0	0	0	0	
1	Segment number (0x00)								
2	FMark	EOM	ILI	Reserved	Sense key				
3 to 6	(MSB) Residual length							(LSB)	
7	Additional sense length								
8 to 11	(MSB) (SCSI-2 command-specific information bytes)							(LSB)	
12	Additional sense code								
13	Additional sense code qualifier								
14	FRU Code (3480 only)								
15 to 17	SKSV	(MSB)						(SCSI-2 sense-key specific information bytes)	(LSB)
18	Format of additional sense (3480 only)								
19	Host ERPA (3480 only)								
20 to 43	(MSB) Additional sense bytes as defined by the format indicated in byte 18. (3480 only)							(LSB)	

2.15.2 Sense byte description

This section describes all bits in the sense format bytes.

- Byte 0 (valid)
When the valid bit is a one, sense bytes 3 to 6 indicate the difference between the number of bytes, blocks, or filemarks requested by a command and the number of bytes, blocks, or filemarks actually executed.
- Byte 1 (segment number)
- Byte 2
Bit <7> fmark (filemark)
Bit <6> EOM (End-of-medium)
Bit <5> ILI (Incorrect length indicator)
Bit <4> Ignored
Bits <3..0> Sense key, listed in Table 2-22

Table 2-22, Sense key codes

Code	Description
0x0	No sense
0x1	Recovered error
0x2	Not ready
0x3	Medium error
0x4	Hardware error
0x5	Illegal request
0x6	Unit attention
0x7	Data project
0x8	Blank check
0x9	Busy/not busy
0xa	Copy aborted
0xb	Aborted command
0xd	Volume overflow
0xe	Miscompare

Bytes 3 - 6 (residual length)

Byte 7 (additional sense length)

Bytes 8-11 (command specific information)

Bytes 12-13 (Additional sense code and sense code qualifiers as listed in Table 2-23)

Table 2-23, Additional sense codes and descriptions

Byte 12	Byte 13	Description
00	00	No additional sense information
00	01	Filemark detected
00	02	End-of-medium (EOM) detected
00	03	Beginning-of-data (BOD) detected (3480 only)
00	03	Setmark detected (DAT only)
00	04	Beginning-of-tape (BOT) detected
00	05	End-of-medium (EOM) detected
03	00	Peripheral device write fault
03	01	No write current (3480 only)
03	02	Excessive write errors
04	00	Logical unit not ready, cause not reported
04	01	Logical unit not ready, manual intervention required (3480 only)
		Logical unit is in process of becoming ready (DAT only)
04	02	Logical unit not ready, initializing command required
04	03	Logical unit is in process of becoming ready (3480 only)
		Logical unit not ready, manual intervention required (DAT only)
04	04	Logical unit not ready, format in progress
05	00	Logical unit does not respond to selection
07	00	Multiple peripheral devices selected
08	00	Logical unit communication failure
08	01	Logical unit communication time-out
08	02	Logical unit communication parity error
09	00	Track following error
0a	00	Error log overflow
0c	00	Write error (sense key says whether recovered)
11	00	Unrecovered read error
11	01	Read retries exhausted
11	02	Error too long to correct
11	03	Multiple read errors
11	04	Physical EOT encountered (3480 only)
11	08	Incomplete block read (postamble not found)
11	09	No gap found
11	0a	Miscorrected error
14	00	Recorded entity not found
14	01	Record not found
14	02	Filemark not found
14	03	End-of-data not found
14	04	Block sequence error

**Table 2-23, Additional sense codes and descriptions
(continued)**

Byte 12	Byte 13	Description
15	00	Random positioning error
15	01	Mechanical positioning error
15	02	Positioning error detected by read of medium
17	00	Recovered read data with no error correction applied
17	01	Recovered read data with retries
17	02	Recovered read data with positive head offset (3480 only)
17	03	Recovered read data with negative head offset (3480 only)
18	00	Recovered read data with error correction applied
1a	00	Parameter list length error
1b	00	Synchronous data transfer error
20	00	Invalid command operation code
21	00	Logical block address out of range
24	00	Invalid field in CDB (check field pointer)
25	00	Unsupported logical unit
26	00	Invalid field in parameter list (check field pointer)
26	01	Parameter not supported
26	02	Parameter value not supported
26	03	Threshold parameters not supported
27	00	Write protected
28	00	Not ready to ready transition (medium may have changed)
29	00	Power on, reset, or BUS DEVICE RESET occurred
2a	00	MODE SELECT parameters changed by another initiator
2a	01	Mode parameters changed
2a	02	Log parameters changed
2b	00	COPY cannot execute since host cannot disconnect
2c	00	Command sequence error
2d	00	Overwrite error on update in place
2f	00	Tagged commands cleared by another initiator

**Table 2-23, Additional sense codes and descriptions
(continued)**

Byte 12	Byte 13	Description
30	00	Incompatible medium installed
30	01	Cannot read medium—unknown format
30	02	Cannot read medium—incomplete format
30	03	Cleaning cartridge installed
31	00	Medium format corrupted
33	00	Tape length error
37	00	Rounded parameter
39	00	Saving parameters not supported
3a	00	Medium not present
3b	00	Sequential positioning error
3b	01	Tape position error at beginning-of-tape
3b	02	Tape position error at end-of-tape
3b	08	Reposition error
3d	00	Invalid bits in IDENTIFY message
3e	00	Logical unit has not self-configured yet
3f	00	Target operating conditions have changed
3f	01	Microcode has been changed
3f	02	Changed operating definition
3f	03	INQUIRY data has changed
40	nn	Diagnostic failure on component nn (0x80-0xff)
43	00	Message error
44	00	Internal target failure
45	00	Select/reselect failure
46	00	Unsuccessful soft reset
47	00	SCSI parity error
48	00	Initiator detected error message received
49	00	Invalid message error

**Table 2-23, Additional sense codes and descriptions
(continued)**

Byte 12	Byte 13	Description
4a	00	Command phase error
4b	00	Data phase error
4c	00	Logical unit failed self-configuration
4e	00	Overlapped commands attempted
50	00	Write append error
50	01	Write append position error
50	02	Timer position error
51	00	Erase fault
52	00	Cartridge fault
53	00	Media load/eject failed
53	01	Unload tape failure
53	02	Medium removal prevented (DAT only)
5a	00	Operator request or state change input unspecified (3480 only)
5a	01	Operator medium removal request
5a	02	Operator selected write protect (3480 only)
5a	03	Operator selected write permit (3480 only)
5b	00	Log execution
5b	01	Threshold condition met
5b	02	Log counter at maximum
5b	03	Log list codes exhausted

NOTE

Byte 14 (FRU codes) applies only to the 3480-compatible subsystem.

Byte 14 (FRU codes) Nonzero values in the FRU field are used to define a specific FRU or FRU-pair that has failed. The FRU byte contains two nibbles of information. The low-order nibble indicates the highest probability FRU. The high-order nibble indicates a secondary FRU that may also be responsible for the reported failure. Table 2-24 lists the FRU codes for the two nibbles.

Table 2-24, FRU codes for byte 14 nibbles

Code	FRU	Description
1	SI or DI PCB	The SI or DI PCB contains the SCSI interface processor (68000), associated ROM/RAM, SCSI interface drivers or receivers, and the SCSI interface chip. The SI card is used in single-ended controllers. The DI card is used in differential controllers.
2	CF PCB	The CF PCB contains the formatter microprocessor (MPU), associated ROM/RAM, data buffer, and the buffer function chip (BFC).
3	FM PCB	The FM PCB contains the formatter digital read/write interface, the MTU serial interface, and the MTU parallel interface.
4	RA PCB	The RA PCB contains the formatter analog read circuitry.
5	XL PCB	The XL PCB contains the compression hardware.
6	OP panel	The OP panel is not diagnosed.
7	Power Supply	The power supplies are not diagnosed.
8-D	Fans	The fans are not reported in sense.

Bytes 15-18 Not applicable for this diagnostic.

NOTE

Byte 19 (ERPA code) applies only to the 3480-compatible subsystem.

Byte 19 (ERPA code)

Byte 19 identifies the error recovery procedure action (ERPA) code. A list of the codes and their meanings follows.

ERPA code 0x22

Path equipment check.

One or more of the following errors cause this error code:

- Drive adapter error occurred.
- System could not recover from a buffer error on the lower interface.
- System could not use internal path (sense byte 2 identifies the path in error).

ERPA code 0x23

Read data check.

A permanent read error has occurred, or a temporary read error occurred with one of the following conditions:

- The controlling computer had inhibited control-unit error recovery with mode set bit <7>.
- Tape synchronous mode was in effect.

ERPA code 0x24

Load display check.

A LOAD DISPLAY command is received by a drive while a cartridge is being loaded.

ERPA code 0x25

Write data check. One or more of the following errors can cause this error code:

- Buffered data could not be written on the tape successfully. ERP has tried to erase gaps and rewrites but could not complete the write operation.
- A permanent error occurred when trying to write data, an IBG, or a tape mark on the tape. All attempts to retry the operation have been completed but were unsuccessful.
- A temporary write error occurred with one of the following conditions: The controlling computer had inhibited control-unit error recovery by mode set bit <1>, or tape synchronous mode was in effect.

ERPA code 0x26

Data check (read opposite).

A read recovery is in progress, and a READ command (in the opposite direction) must be issued to the subsystem before the data can be recovered.

If the command at CCW address pointer -8 is 0x02 (read), issue a 0x0c (read backward) chained to a 0x37 (forward space block).

If the command at CCW address pointer -8 is 0x0c (read backward), issue a 0x02 (read) chained to a 0x27 (backspace block).

If the controlling computer cannot issue a command to the subsystem to read the block in the opposite direction, a permanent OBR record is entered. If the subsystem cannot complete the command to read the record in the opposite direction, a unit check is issued and the associated sense information contains the ERPA code.

ERPA code 0x27

Command reject.

ERPA code 0x28

Write ID mark check.

The ID mark could not be written successfully at the beginning-of-tape (BOT). Any data to be written to the drive is still in the buffer.

ERPA code 0x2c

Permanent equipment check.

Either the control unit cannot recover because an error occurred in the subsystem hardware or microprogram, or the control unit recovery action was unsuccessful.

ERPA code 0x2d

Data security ERASE command failure.

The drive became "not ready" after the command was issued, or an error occurred while the command was processing.

ERPA code 0x2e

Not capable (BOT error).

Either a density mark could not be read correctly or the block ID read by the control unit is invalid (bit <0> or bits <8..11> are not zero).

If a density could not be read correctly, likely causes are:

- A void occurred at BOT.
- A time-out occurred before the density separator was detected.

ERPA code 0x30

File protected.

A write type operation was attempted on a tape cartridge that is file protected.

ERPA code 0x31

Tape void.

No patterns or data were found on the tape during a read operation. The tape could be positioned after the last data block or tape mark that was written on the tape.

ERPA code 0x32

Load assistance.

An error caused the drive to lose tape tension.

ERPA code 0x33

Load failure.

The cartridge is not inserted or threaded correctly.

ERPA code 0x34

Manual unload.

The drive cannot maintain tape tension and control tape movement during an unload operation.

ERPA code 0x35

Drive equipment check.

One of the following has occurred:

- The control unit cannot recover from a drive-detected error.
- A check code message is displayed on the drive message display and a LOAD DISPLAY command is issued (drive display is busy).
- A failure occurred during an index/load or unload cycle. The tape cartridge is not manually retrievable by the operator.

ERPA code 0x37

Tape length error.

The tape length in the cartridge is too short. This error could occur when the leader block was replaced (the length of tape ahead of the BOT has been trimmed).

ERPA code 0x38

Physical EOT.

A read or write operation was in process when the physical EOT pattern was reached. The drive does not pull the tape out of the cartridge.

ERPA code 0x39

Backward at beginning-of-tape (BOT).

While the tape was moving backwards, the BOT pattern was reached.

ERPA code 0x3a

Drive reset by operator.

The drive reset switch was activated, and the drive is not ready.

ERPA code 0x3b

Volume removed by operator.

The rewind unload switch on the drive has been activated and the cartridge is unloaded.

ERPA code 0x41

Block ID sequence error.

The control unit detected an incorrect block ID sequence.

ERPA code 0x43

Intervention required.

A start I/O or start subchannel instruction was received by a drive that is not ready.

ERPA code 0x44

Locate block unsuccessful.

The control unit cannot find the block preceding the desired block.

ERPA code 0x46

Drive not online.

A command was issued to a drive that is not online. One of the following has occurred:

- The drive is switched offline.
- The drive power is switched off.
- The drive address is set incorrectly.

ERPA code 0x47

Control unit error.

The control unit developed an error that caused it to initialize itself again and continue.

ERPA code 0x49

Bus out parity.

The bus parity error was detected on the command or parameter transfer.

ERPA code 0x4a

Control unit ERP failed.

The control unit could not recover from a data handling failure.

Bytes 20 - 43

Not applicable for this diagnostic.

2.16 Error examples

This section gives examples of various errors that may be encountered.

Figure 2-12 shows the error message received when a SCSI host adapter board is not present in the VMEbus chassis or there is no power to the VMEbus chassis.

Figure 2-12, Host adapter missing or unpowered VMEbus error

```
Loading CCU(s) . . . Done
Bus error
Error: Ego's write to adapter reset port failed - adapter installed correctly?
      from boot_ccu1
dev_vscsit: ccu_init failed!
```

Figure 2-13 shows an example of an error message received when a command does not complete in the allotted time or the CCU (VIOP) is not responding to the command.

Figure 2-13, Command not completed error example

```
Error: (0x6) timeout waiting for message
      : cmi operation 0x201e IO_RDSTATS_PHYSICAL: read statistics
      : cmd specific modifier 0x01 cmd common modifier 0x32
      : from sc_wrt_eof
```

Figure 2-14 shows an example of an error message received when the wrong driver file is loaded.

Figure 2-14, Wrong driver file loaded error example

```
Error: cmi code 0x0006 device driver not found
      : error count 0x01 status modifier 0x05 extended status 0x00000000
      : cmi operation 0x0111 IO_INIT: probe, attach, etc.
      : cmd specific modifier 0x01 cmd common modifier 0x30
      : from xinit_driver_module(b)
dev_vscsit: ccu_init failed!
```

Index

A

Associated documents, listed xi

B

boot debugger command 2-38

C

Canada, reporting problems from, telephone number for xii

Cautions, described xi

cd debugger command 2-39

changeunit debugger command 2-39

class 1 tests, host adapter tests 2-17

Command scripts, user-created 1-4

Continental U.S., reporting problems from, telephone number for xii

CONVEX, address, for ordering documents xii

D

daidentity debugger command 2-39

dapseltest debugger command 2-39

darseltest debugger command 2-39

debugger, interactive, boot 2-38

debugger, interactive, cd 2-39

debugger, interactive, changeunit 2-39

debugger, interactive, command descriptions 2-38

debugger, interactive, daidentity 2-39

debugger, interactive, dapseltest 2-39

debugger, interactive, darseltest 2-39

debugger, interactive, dfcselftest 2-39

debugger, interactive, dfdisplod 2-39

debugger, interactive, dfrecvdiag 2-40

debugger, interactive, dfuseltest 2-40

debugger, interactive, dtidentity 2-40

debugger, interactive, echo 2-40

debugger, interactive, erase 2-40

debugger, interactive, fb, fl, fw 2-41

debugger, interactive, ffb, ffl, ffw 2-42

debugger, interactive, fsr, bsr, fsf, bsf 2-42

debugger, interactive, help 2-38

debugger, interactive, laststatus 2-42

debugger, interactive, mb, mw, ml 2-43

debugger, interactive, mmb, mmw, mml 2-44

debugger, interactive, notimeout 2-44

debugger, interactive, pause 2-44

debugger, interactive, quit 2-45

debugger, interactive, reset 2-45

debugger, interactive, rewind 2-45

debugger, interactive, rphys 2-45

debugger, interactive, scsi 2-45

debugger, interactive, scsimm 2-45

debugger, interactive, status 2-46

debugger, interactive, stkload 2-46

debugger, interactive, stkloadmag 2-46

debugger, interactive, stkmode 2-46

debugger, interactive, stkselect 2-46

debugger, interactive, stkstat 2-46

debugger, interactive, stkunload 2-47

debugger, interactive, tracemsgs 2-47

debugger, interactive, unitclr 2-47

debugger, interactive, unload 2-47

debugger, interactive, wEOF 2-47

debugger, interactive, wphys 2-47

dev_vscsit (tape unit and host adapter test) 2-1

dev_vscsit (test parameter menu) 2-9

dev_vscsit (test parameter menu), all options 2-12

dfcselftest debugger command 2-39

dfdisplod debugger command 2-39

dfrecvdiag debugger command 2-40

dfuseltest debugger command 2-40

Diagnostic environment, overview 1-1

Diagnostic shell. See dshell 1-4

Diagnostics, selecting 1-4

Documentation, ordering xii

dshell, commands, summarized 1-4, 1-5

dshell, commands, syntax 1-6

dshell, functions 1-4

dshell, introduction 1-4

dtidentity debugger command 2-40

E

echo debugger command 2-40

EGOS 1-1

erase debugger command 2-40

Error messages, selecting 1-4

Event-Governed Operating System (EGOS), described 1-1

Event-Governed Operating System (EGOS), HIPPI 1-2

Event-Governed Operating System (EGOS), HSP interface 1-2

Event-Governed Operating System (EGOS), Multibus 1-2

Event-Governed Operating System (EGOS), position in environment 1-2, 1-3

Event-Governed Operating System (EGOS), VMEbus interface 1-2

F

fb, fl, fw debugger command 2-41

ffb, ffl, ffw debugger command 2-42

Files, test outputs to 1-4

fsr, bsr, fsf, bsf debugger command 2-42

H

help debugger command 2-38

help-for dev_vscsit prompts 2-9

host adapter identify test 2-18

L

laststatus debugger command 2-42

M

mb, mw, ml debugger command 2-43

Message-Based System (MBS) 1-1

mmb, mmw, mml debugger command 2-44

N

Notational conventions, discussed xi

Notes, described xi

notimeout debugger command 2-44

O

Overview, diagnostic environment 1-1

Overview, dshell 1-4

P

pause debugger command 2-44

Index

Q

quit debugger command 2-45

R

Reporting problems xii
requirements, hardware 2-3
requirements, software 2-4
reset debugger command 2-45
rewind debugger command 2-45
rphys debugger command 2-45

S

Screens, test outputs to 1-4
scsi debugger command 2-45
scsim debugger command 2-45
status debugger command 2-46
stkload debugger command 2-46
stkloadmag debugger command 2-46
stkmode debugger command 2-46
stkselect debugger command 2-46
stkstat debugger command 2-46
stkunload debugger command 2-47

T

TAC, reporting problems to xii
tape subsystem class descriptions 2-17
Technical assistance, discussed xii
test parameter menu 2-9
test parameter menu, all options 2-12
Tests, options, selecting 1-4
Tests, output, selecting 1-4
tracemsgs debugger command 2-47
Trouble reports xii

U

unitclr debugger command 2-47
unload debugger command 2-47
U.S., reporting problems from, telephone number for xii

W

Warnings, described xi
weof debugger command 2-47
wphys debugger command 2-47